Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fujifilm XP125

Fujifilm FinePix XP125 Digital Camera Instruction Manual

Model: XP125

1. Introduction

This manual provides essential instructions for the safe and effective use of your Fujifilm FinePix XP125 Digital Camera. The XP125 is a rugged point-and-shoot camera designed for various environments, featuring a 16.4MP CMOS sensor, 5x optical zoom, and built-in Wi-Fi connectivity. It is constructed to be waterproof, shockproof, freeze-proof, and dustproof, making it suitable for outdoor and adventurous photography.



Figure 1: Front view of the Fujifilm FinePix XP125 Digital Camera, showcasing the lens, flash, and rugged design.

2. Key Features

- **Waterproof:** Submersible up to 50ft (15M).
- **Freeze-proof:** Operates in temperatures down to 14°F (-10°C).
- **Shockproof:** Withstands drops from up to 5.8ft (1.75M).
- **Dustproof:** Protects against sand and other foreign particles.
- **16.4MP CMOS Sensor:** For high-resolution stills and Full HD 1080p video.
- **5x Optical Zoom Lens:** Covers a 28-140mm equivalent focal length range.
- **Optical Image Stabilization:** Minimizes camera shake for sharper images.
- **Built-in Wi-Fi:** For wireless image transfer and remote control.

3. Setup

3.1. Battery Installation

1. Open the battery/memory card compartment cover on the side of the camera. Ensure the lock is fully disengaged.
2. Insert the supplied NP-45S Lithium-ion battery with the correct orientation, matching the arrow on the battery to the indicator inside the compartment.
3. Close the compartment cover securely until it clicks into place and engage the lock.

3.2. Memory Card Insertion

1. With the battery compartment open, locate the memory card slot.
2. Insert an SD, SDHC, or SDXC memory card (sold separately) into the slot until it clicks. Ensure the card is facing the correct direction.
3. Close the compartment cover securely.

3.3. Initial Power On

Press and hold the **ON/OFF** button located on the top of the camera. The camera will power on, and you may be prompted to set the date, time, and language. Follow the on-screen instructions.

4. Operating the Camera

4.1. Camera Controls



Figure 2: Rear view of the Fujifilm FinePix XP125, highlighting the LCD screen and control buttons.

- **Shutter Button:** Press halfway to focus, fully to take a picture.
- **Zoom Lever (W/T):** Controls optical zoom. 'W' for wide-angle, 'T' for telephoto.
- **MENU/OK Button:** Accesses menus and confirms selections.
- **Directional Pad:** Navigates menus and selects options. Also provides shortcuts for flash, self-timer, and macro mode.
- **Playback Button ( ):** Enters playback mode to view photos and videos.
- **DISP/BACK Button:** Changes display information or returns to the previous screen.
- **Wi-Fi Button ( ):** Activates Wi-Fi for connection to smart devices.
- **Video Record Button ( ):** Starts and stops video recording.



Figure 3: Top view of the Fujifilm FinePix XP125, showing the ON/OFF button and dedicated video record button.

4.2. Taking Photos

1. Turn on the camera by pressing the**ON/OFF** button.
2. Point the camera at your subject. Use the zoom lever to adjust the focal length.
3. Press the shutter button halfway down to focus. The focus frame will turn green when focus is achieved.
4. Press the shutter button fully down to take the picture.

4.3. Recording Videos

1. With the camera powered on, press the dedicated**Video Record Button** to start recording.
2. Press the **Video Record Button** again to stop recording.
3. Videos are recorded in Full HD 1080p resolution.

4.4. Wi-Fi Connectivity

The camera's built-in Wi-Fi allows for wireless transfer of images to a smartphone or tablet, and remote control of the camera. To use this feature:

1. Install the Fujifilm Camera Remote app on your smart device.
2. Press the **Wi-Fi Button** on the camera.
3. Follow the instructions in the app and on the camera screen to establish a connection.

5. Maintenance

5.1. Waterproof Care

- Before submerging the camera, ensure the battery/memory card compartment cover is completely closed and locked. Check for any sand, dust, or debris around the seal.
- After use in saltwater, rinse the camera thoroughly with fresh water and wipe it dry with a soft cloth. Do not open the compartment cover until the camera is completely dry.
- Avoid opening the compartment cover in wet or dusty environments.

5.2. General Care

- Clean the lens and LCD screen with a soft, lint-free cloth specifically designed for optical surfaces. Do not use abrasive cleaners.
- Store the camera in a cool, dry place when not in use.
- Avoid exposing the camera to extreme temperatures for extended periods, even though it is freeze-proof.

6. Troubleshooting

If you encounter issues with your camera, please refer to the following common solutions:

- **Camera does not turn on:** Ensure the battery is fully charged and correctly inserted.
- **Memory card error:** Check if the memory card is inserted correctly. Try formatting the card (this will erase all data) or use a different card.
- **Blurry images:** Ensure the lens is clean. Check if the camera is focusing correctly (press the shutter button halfway). Use optical image stabilization in low light or when zooming.
- **Wi-Fi connection issues:** Ensure the Fujifilm Camera Remote app is updated. Restart both the camera and your smart device.

For more detailed troubleshooting, please consult the full user manual available on the Fujifilm support website.

7. Specifications

Feature	Specification
Sensor Type	16.4 MP 1/2.3-inch CMOS (Back-illuminated)
Optical Zoom	5x
Focal Length (35mm equiv.)	28-140mm
Waterproof Rating	Up to 50ft (15M)
Shockproof Rating	Withstands drops from 5.8ft (1.75M)
Freeze-proof Rating	Down to 14°F (-10°C)
Dustproof	Yes
Video Resolution	Full HD 1080p
Display	3.0-inch LCD
Connectivity	Wi-Fi

Battery Type	Lithium Ion (NP-45S)
Dimensions (W x H x D)	Approx. 109.6 x 71.0 x 27.8 mm (4.3 x 2.8 x 1.1 in.)
Weight	Approx. 15.2 ounces (430g) including battery and memory card

8. What's in the Box

The Fujifilm FinePix XP125 Digital Camera package typically includes:

- Fujifilm FinePix XP125 Camera Body
- NP-45S Li-ion Battery
- AC Power Adapter
- USB Cable
- Hand Strap
- Owner's Manual (this document is a summary)

9. Warranty and Support

9.1. Warranty Information

The Fujifilm FinePix XP125 Digital Camera comes with a**1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. For full terms and conditions, refer to the warranty card included with your product or visit the official Fujifilm website.

9.2. Customer Support

For technical assistance, service, or further information regarding your Fujifilm FinePix XP125 camera, please contact Fujifilm customer support. You can find contact details and additional resources on the official Fujifilm website: www.fujifilm.com/us/en/consumer/support

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07JKRB63Y

More documents and user manuals: **https://manuals.plus/**