Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RYOBI P755

Ryobi 18-Volt ONE+ Compact Blower User Manual

Model: P755

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Ryobi 18-Volt ONE+ Compact Blower. Please read this manual thoroughly before using the product.
The Ryobi 18-Volt ONE+ Compact Blower is designed for light-duty cleaning tasks in workshops and job sites. Its compact and lightweight design makes it highly portable. It features a variable speed trigger with three speed settings, allowing for precise control over airflow.

Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before using the appliance.
- Wear appropriate personal protective equipment, including eye protection and hearing protection.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- Keep children and bystanders away while operating a power tool.
- Do not expose power tools to rain or wet conditions.
- Use the correct tool for your application. Do not force the tool.
- Disconnect the battery pack from the tool before making any adjustments, changing accessories, or storing the tool.
- Store idle tools out of reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.

Product Components



Figure 1: Ryobi 18-Volt ONE+ Compact Blower (tool only)

This image displays the Ryobi 18-Volt ONE+ Compact Blower. It features a bright green body with black accents on the handle and nozzle. The Ryobi logo is visible on the side. The blower has a long, tapered black nozzle extending from the front, and a comfortable ergonomic handle with a trigger mechanism at the rear. An air intake vent is visible on the side of the main housing.

1. **Nozzle:** Directs the airflow.
2. **Air Intake Vent:** Where air is drawn into the blower. Keep clear of obstructions.
3. **Handle:** Ergonomically designed for comfortable grip.
4. **Variable Speed Trigger:** Controls the airflow speed.
5. **Battery Port:** For inserting the 18-Volt ONE+ battery (battery sold separately).

Setup

Battery Installation

1. Ensure the blower is turned off and the trigger is not depressed.
2. Align the ribs on the battery pack with the grooves in the blower's battery port.
3. Slide the battery pack into the blower until it clicks securely into place.
4. To remove the battery, press the latch on the battery pack and pull it out.

Note: This product is sold as "tool only" and requires a Ryobi 18-Volt ONE+ battery and charger, which are sold separately.

Operating Instructions

Starting and Stopping

- To start the blower, depress the variable speed trigger.
- To stop the blower, release the variable speed trigger.

Adjusting Air Speed

The blower features a variable speed trigger and three speed settings for optimal control:

- **Low Speed:** For delicate tasks or extended battery life.
- **Medium Speed:** For general cleaning.
- **High Speed:** For maximum air velocity, up to 160 MPH, ideal for stubborn debris.

Adjust the speed by varying the pressure on the trigger or by selecting one of the three speed settings if available on your model (refer to specific product markings).

Usage Tips

- Always direct the nozzle away from yourself and others.
- For best results, use sweeping motions to move debris.
- Avoid operating the blower in dusty environments without proper respiratory protection.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your blower.

- **Cleaning:** Keep the air intake vents clean and free of debris to prevent overheating and maintain airflow. Use a dry cloth to wipe down the exterior. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the blower in a dry, secure location out of reach of children. Remove the battery pack before storing for extended periods.
- **Inspection:** Periodically inspect the blower for any signs of damage, loose parts, or wear. If any damage is found, do not use the tool until it has been repaired.

Troubleshooting

Problem	Possible Cause	Solution
Blower does not start.	Battery not installed correctly or discharged.	Ensure battery is fully seated. Charge or replace battery.
Reduced airflow.	Air intake vents blocked.	Clear any debris from the air intake vents.
Blower stops during operation.	Overheating or low battery.	Allow blower to cool down. Charge or replace battery.

Specifications

- **Brand:** RYOBI
- **Model:** P755
- **Power Source:** Battery Powered (18-Volt ONE+ system)
- **Voltage:** 18 Volts
- **Form Factor:** Handheld
- **Special Features:** Adjustable Speed, Compact Design, Lightweight, Portable
- **Product Dimensions (L x W x H):** 19.8" x 5.25" x 10"

- **Max Air Speed:** 160 Miles per Hour
- **Item Weight:** 2.99 pounds
- **UPC:** 748926425094

Warranty and Support

This product is a Certified Refurbished item, tested and certified to look and work like new. The refurbishing process includes functionality testing, basic cleaning, inspection, and repackaging. It ships with all relevant accessories and a minimum 90-day warranty.
For warranty claims or technical support, please refer to the Amazon Renewed program guidelines or contact Amazon customer service directly. Only select sellers who maintain a high performance bar may offer Certified Refurbished products on Amazon.com.

© 2025 Amazon Renewed. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07JLZ74LK

More documents and user manuals: **https://manuals.plus/**