**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## KDJMDL Easytry3607

# Remote Control User Manual

### For Sharp AC Air Conditioners

Brand: KDJMDL | Model: Easytry3607

## Introduction

This manual provides essential information for the setup, operation, and maintenance of your KDJMDL replacement remote control for Sharp AC Air Conditioners. This remote is designed to be compatible with various Sharp AC models, including CV-P09FL, CV-P09FX, CV-P09MX, CV-P10MX, CV-P12LX, and CRMC-A729JBEZ.
**Important Note:** As a replacement unit, this remote may not support all functions of your original air conditioner remote. Please ensure that this remote matches the model number of your unit for optimal compatibility. This product does not include batteries or a separate printed manual.

## Product Overview




**Figure 1:** Front view of the remote control, displaying the LCD screen at the top and an array of buttons for various functions such as Power, Mode, Temperature adjustment, Fan speed, and Timer settings. The ergonomic design ensures comfortable handling.



**Figure 2:** Rear view of the remote control with the battery cover slid open, revealing the two AAA battery compartments. This view is essential for understanding how to install or replace batteries.

The remote features a clear LCD display for current settings and an intuitive button layout for easy operation. Key buttons include:

- **POWER:** Turns the AC unit on or off.
- **MODE:** Cycles through operating modes (e.g., Cool, Dry, Fan, Auto).
- **TEMP ▲/▼:** Adjusts the temperature setting.
- **FAN:** Changes fan speed.
- **TIMER:** Sets ON/OFF timers.
- **SLEEP:** Activates sleep mode for quiet operation and energy saving.
- **LIGHTS:** Controls the display lights on the AC unit.
- **MEGA COOL:** Activates a powerful cooling function.
- **LOUVERS:** Adjusts the direction of airflow.

## Setup

### Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and remove it (refer to Figure 2).
3. Insert two (2) AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote is ready for use. No complex pairing is typically required for this type of infrared replacement remote; simply point it towards your AC unit.

## Operating Instructions

Ensure there is a clear line of sight between the remote control and the infrared receiver on your Sharp AC unit for proper operation.

### Basic Operation

- **Turning On/Off:** Press the **POWER** button to switch the AC unit on or off.
- **Selecting Mode:** Press the **MODE** button repeatedly to cycle through available operating modes:
  - *COOL:* For cooling the room.
  - *DRY:* For dehumidification.
  - *FAN:* For air circulation without cooling/heating.
  - *AUTO:* The unit automatically selects the operating mode based on room temperature.
- **Adjusting Temperature:** Use the **TEMP ▲** (up) and **TEMP ▼** (down) buttons to set your desired temperature.
- **Adjusting Fan Speed:** Press the **FAN** button to select desired fan speed (e.g., Low, Medium, High, Auto).

### Advanced Functions

- **Timer Function:** Press **TIMER ON** or **TIMER OFF** to set a specific time for the unit to turn on or off. Use the TEMP ▲/▼ buttons to adjust the time, then press the TIMER button again to confirm.
- **Sleep Mode:** Press the **SLEEP** button to activate sleep mode, which adjusts temperature and fan speed for comfortable sleep and energy efficiency.
- **Mega Cool:** Press **MEGA COOL** for rapid cooling. This function typically operates at maximum fan speed and lowest temperature setting for a period.
- **Louvers:** Use the **LOUVERS** button to control the swing or fixed position of the air outlet louvers.
- **Lights:** Press the **LIGHTS** button to turn the display lights on the AC unit on or off.

## Maintenance

### Battery Replacement

Replace batteries when the remote's display becomes dim or the remote no longer responds to button presses. Always replace both batteries simultaneously with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

### Cleaning the Remote

Wipe the remote control with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the remote. Do not use abrasive cleaners, alcohol, or chemical solvents, as these can damage the remote's surface or internal components.

### Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Remote not responding / AC unit not reacting. | ◦ Dead or incorrectly installed batteries.<br>◦ Obstruction between remote and AC unit.<br>◦ Remote is out of range.<br>◦ Infrared sensor on AC unit is blocked or faulty. | ◦ Replace batteries with new AAA alkaline batteries, ensuring correct polarity.<br>◦ Remove any objects blocking the line of sight.<br>◦ Move closer to the AC unit.<br>◦ Check AC unit's sensor for obstructions. Consult AC unit's manual if issue persists. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Some functions do not work. | ◦ The replacement remote may not support all original functions.<br>◦ AC unit model incompatibility. | ◦ Verify the remote's compatibility with your specific AC unit model.<br>◦ Refer to the original AC unit's manual for specific function requirements. |

## Specifications

- **Model:** Easytry3607
- **Brand:** KDJMDL
- **Compatible AC Models:** Sharp CV-P09FL, CV-P09FX, CV-P09MX, CV-P10MX, CV-P12LX, CRMC-A729JBEZ (and others as specified by seller)
- **Power Source:** 2 x AAA Alkaline Batteries (not included)
- **Connectivity:** Infrared (IR)
- **Controller Type:** Button Control
- **Special Feature:** Ergonomic design

## Warranty and Support

Specific warranty information for this replacement remote control is not provided in the product details. For any issues, questions, or support inquiries regarding this product, please contact the seller directly through the platform where the purchase was made. They will be able to provide assistance and information regarding returns or replacements if necessary.

© 2023 KDJMDL. All rights reserved. This manual is for informational purposes only.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B07JMX7KVQ**

More documents and user manuals: **https://manuals.plus/**