Victrola VPRO-2000-SLV

Victrola Pro Series USB Record Player

Model: VPRO-2000-SLV

Introduction

Thank you for purchasing the Victrola Pro Series USB Record Player. This manual provides detailed instructions for setting up, operating, and maintaining your new turntable. Please read this manual thoroughly before use to ensure proper operation and to maximize your listening experience.

Important Safety Information

- Read all instructions before operating the product.
- Keep these instructions for future reference.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.

What's in the Box

- Victrola Pro Series USB Record Player
- Dust Cover
- Power Adapter
- USB Cable

- RCA Cable
- Software CD for Vinyl-to-MP3 Recording (Mac/PC compatible)
- Instruction Manual (this document)

Product Overview

Familiarize yourself with the various components of your Victrola Pro Series USB Record Player.



Figure 1: Front view of the Victrola Pro Series USB Record Player with the clear acrylic dust cover open, showing the platter, tonearm, and controls.



Figure 2: Rear view of the turntable, highlighting the USB OUT, DC 12V power input, and AUDIO OUT (RCA) ports.

Key Components:

- **Platter:** The rotating disc on which records are placed. This model features a stroboscopic aluminum platter.
- **Tonearm:** Holds the cartridge and stylus, which reads the grooves of the record. Features a metal tonearm with anti-skating adjustment.
- **Stylus:** The needle that makes contact with the record. This unit includes a high-quality diamond stylus.
- **Dust Cover:** A clear acrylic cover to protect the turntable from dust when not in use.
- **Speed Selector:** Allows selection between 33 1/3, 45, and 78 RPM speeds.
- **Pitch Control:** Adjusts the playback speed finely. Includes a Quartz lock feature.
- **USB Output:** For connecting to a computer for vinyl-to-MP3 recording.
- **RCA Output:** For connecting to external speakers or an amplifier. Features a Pre-Amp switch.
- **Bluetooth:** Built-in Bluetooth for streaming audio to compatible headphones or speakers.

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future transport or storage.
2. **Placement:** Place the turntable on a stable, level surface away from direct sunlight, heat sources, and excessive dust or vibration.
3. **Dust Cover Installation:** Gently attach the clear acrylic dust cover to the hinges at the back of the turntable.
4. **Power Connection:** Connect the DC 12V power adapter to the DC 12V input port on the back of the turntable (refer to Figure 2). Plug the other end into a wall outlet.
5. **Audio Connection (Optional):**
    - **To External Speakers/Amplifier:** Use the supplied RCA cable to connect the AUDIO OUT ports on the turntable to the audio input of your amplifier or powered speakers. Ensure the Pre-Amp switch on the turntable is set correctly based on your amplifier's input (PHONO or LINE).
    - **Bluetooth Connection:** For wireless audio, ensure your Bluetooth headphones or speakers are in pairing mode. The turntable will automatically enter pairing mode when powered on.
6. **USB Connection (Optional):** To record vinyl to MP3, connect the USB cable from the USB OUT port on the turntable to an available USB port on your computer. Install the included software on your computer.

Operating Instructions

Playing a Record:

1. Place a record on the platter.
2. Select the appropriate speed (33 1/3, 45, or 78 RPM) using the speed selector switch.
3. Remove the stylus protector from the stylus.
4. Lift the tonearm using the cueing lever.
5. Position the tonearm over the desired starting groove of the record.
6. Gently lower the tonearm onto the record using the cueing lever. The record will begin to play.
7. Adjust the volume on your connected audio system or Bluetooth device.
8. To stop playback, lift the tonearm using the cueing lever and return it to the tonearm rest.

Bluetooth Operation:

The Victrola Pro Series turntable features built-in Bluetooth for wireless audio streaming.

1. Ensure the turntable is powered on. It will automatically enter Bluetooth pairing mode.
2. Activate Bluetooth on your external Bluetooth speaker or headphones and set it to pairing mode.
3. Select "Victrola Pro Series" from the list of available devices on your Bluetooth speaker/headphones.
4. Once paired, audio from the turntable will stream wirelessly to your connected device. Adjust volume using the controls on your Bluetooth device or the turntable's adjustable volume control.

Vinyl-to-MP3 Recording:

The turntable allows you to convert your vinyl records into digital MP3 files using the included software and USB cable.

1. Install the provided software on your Mac or PC.

2. Connect the turntable to your computer using the supplied USB cable.
3. Follow the instructions within the software to begin recording your vinyl.

Maintenance

Proper care will ensure the longevity and optimal performance of your turntable.

- **Cleaning the Dust Cover:** Wipe the dust cover with a soft, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Cleaning the Stylus:** Use a soft brush, gently brushing from back to front, to remove any dust or debris from the stylus. Avoid touching the stylus with your fingers.



Figure 3: Close-up view of the turntable's stylus, which should be kept clean for optimal sound quality.

- **Cleaning the Platter:** Use a soft, dry cloth to wipe the platter.
- **General Cleaning:** For the main unit, use a soft, slightly damp cloth. Do not use harsh chemicals.
- **Stylus Replacement:** The stylus has a limited lifespan. If sound quality degrades significantly, consider replacing the stylus. Refer to Victrola's official website or contact support for compatible replacement styli.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No power	Power adapter not connected or faulty outlet.	Ensure power adapter is securely connected to the turntable and a working power outlet.
No sound from speakers	Incorrect audio connection, volume too low, or Pre-Amp switch setting.	Check RCA cable connections. Increase volume on turntable and/or external audio system. Verify Pre-Amp switch setting matches your amplifier's input.
Bluetooth not connecting	External device not in pairing mode or out of range.	Ensure your Bluetooth speaker/headphones are in pairing mode and within range (approx. 30 feet). Try re-pairing.
Skipping or distorted sound	Dirty stylus, dirty record, or turntable not level.	Clean the stylus and record. Ensure the turntable is on a stable, level surface. Adjust anti-skating if available.
Record plays too fast/slow	Incorrect speed selection or pitch control setting.	Verify the speed selector is set to the correct RPM for the record. Adjust the pitch control if necessary.

Specifications

Feature	Detail
Model Name	Victrola Pro Series USB Record Player with 2-Speed Turntable and Dust Cover Silver
Item Model Number	VPRO-2000-SLV
Product Dimensions	17.3 x 5.6 x 14.4 inches
Item Weight	9 Pounds
Color	Silver
Material	Plastic
Connectivity Technology	Wired, Wireless (Bluetooth)
Maximum Rotational Speed	78 RPM (supports 33 1/3, 45, 78 RPM)
Special Features	Bluetooth Connectivity, Vinyl-to-MP3 Recording, Pre-Amp Switch for RCA Output, Stroboscopic Aluminum Platter, Anti-Skating Adjustment, Pitch Control with Quartz Lock

Warranty and Support

For warranty information, technical support, or to purchase replacement parts, please visit the official Victrola website or contact their customer service. Keep your purchase receipt as proof of purchase for warranty claims.

Victrola Official Website: www.victrola.com