Passion-Electro LT20-23H1-6

Passion-Electro Replacement Remote Control for SCHAUB LORENZ LT20-23H1-6 User Manual

1. Introduction

This manual provides comprehensive instructions for the Passion-Electro Replacement Remote Control, specifically designed for SCHAUB LORENZ LT20-23H1-6 television models. This remote control offers full functionality comparable to the original remote and requires no programming, allowing for immediate use upon battery installation.

2. Setup

2.1 Battery Installation

The remote control requires two 1.5V AAA (LR03) batteries. Please note that batteries are not included with this product.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Slide the cover back into place until it clicks securely.



Image: Bottom view of the remote control, illustrating the battery compartment location.



Image: Back view of the remote control, showing the battery compartment.

2.2 Initial Use

No programming or complex setup is required. Once the batteries are correctly installed, the remote control is ready for immediate use with your SCHAUB LORENZ LT20-23H1-6 device.

3. Operating Instructions

This replacement remote control provides access to all functions of your original SCHAUB LORENZ LT20-23H1-6 remote control.

3.1 Basic Operation

- **Power Button:** Press to turn your device on or off.
- **Number Buttons (0-9):** Use to select channels directly.
- **Volume Up/Down (V+/V-):** Adjust the sound level.
- **Channel Up/Down (P+/P-):** Change channels sequentially.
- **Mute Button:** Temporarily silence the audio.
- **Directional Pad (Up, Down, Left, Right) and OK Button:**Navigate menus and confirm selections.
- **Menu Button:** Access the device's main menu.
- **Exit Button:** Exit the current menu or function.

- **Source Button:** Select input sources (e.g., HDMI, AV).

An LED indicator on the remote will light up with each button press, confirming signal transmission to your device.



Image: Front view of the remote control, displaying the button layout.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote's response becomes sluggish, or the LED indicator fails to light up consistently with button presses. Follow the battery installation steps outlined in Section 2.1.

4.2 Cleaning

Clean the remote control with a soft, dry cloth. Do not use liquid cleaners, solvents, or abrasive materials, as these can damage the remote's surface or internal components.

4.3 Storage

Store the remote control in a dry place, away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent potential leakage and damage.

5. Troubleshooting

- **Remote not responding:**
  - Ensure fresh batteries are correctly installed with the proper polarity.
  - Check for any obstructions between the remote control and the device's infrared sensor.
  - Point the remote control directly at the device you wish to operate.
  - Try replacing the batteries with new ones.
- **Some functions not working:**

- Verify that the remote is in the correct mode (e.g., TV, DVD, SAT, AUX) if applicable for your device.
- Ensure your SCHAUB LORENZ LT20-23H1-6 device supports the specific function you are trying to use.

6. Specifications

- **Brand:** Passion-Electro
- **Model:** Replacement Remote Control for SCHAUB LORENZ LT20-23H1-6
- **Battery Type:** 2 x 1.5V AAA (LR03) (not included)
- **Item Weight:** Approximately 100 g
- **ASIN:** B07JWJSLJ7
- **First Available Date:** October 18, 2018

7. Warranty and Support

This product is a new, high-quality replacement remote control designed to offer functionality comparable to the original device remote. As a replacement product, specific warranty terms may vary.
For detailed warranty information or technical support, please refer to the seller from whom you purchased this product or consult your purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question