Bajaj 740076

Bajaj ABS Majesty Slim 2100-Watt Induction Cooktop

Model: 740076

Introduction

This manual provides essential information for the safe and efficient operation of your Bajaj ABS Majesty Slim 2100-Watt Induction Cooktop. Please read these instructions carefully before using the appliance and retain them for future reference.

Important Safety Instructions

- Do not touch the hot surface immediately after cooking. The glass surface retains heat.
- Ensure the appliance is placed on a stable, flat, and heat-resistant surface.
- Do not immerse the cooktop in water or any other liquid.
- Keep children away from the appliance during operation and when it is cooling down.
- Use only induction-compatible cookware.
- Do not place metallic objects such as knives, forks, spoons, or lids on the cooktop surface as they can become hot.
- Unplug the cooktop from the power outlet when not in use and before cleaning.
- Do not operate the appliance with a damaged cord or plug. Contact authorized service personnel for repairs.

Product Overview



This image displays the Bajaj ABS Majesty Slim 2100-Watt Induction Cooktop, highlighting its compact dimensions. The cooktop measures 36.5 cm in length and 29 cm in width, making it suitable for various kitchen spaces. The control panel with feather touch buttons is visible at the bottom.

The Bajaj ABS Majesty Slim Induction Cooktop features a sleek design with feather touch controls for ease of use. It is equipped with a single heating element and a durable Acrylonitrile Butadiene Styrene (ABS) body.

Control Panel Features:

- **On/Off Button:** To power the cooktop on or off.
- **Function Button:** To select various cooking modes and auto-cook menus.
- **Timer/Pre-set Button:** To set cooking duration or activate pre-set functions.
- **+/- Buttons:** To adjust temperature, power, or time settings.
- **LED Display:** Shows selected settings and cooking status.

Setup

1. **Unpacking:** Carefully remove the cooktop from its packaging. Retain packaging materials for future transport or storage.
2. **Placement:** Place the cooktop on a dry, stable, and level surface, ensuring adequate ventilation around the unit. Avoid placing it near heat sources or water.
3. **Power Connection:** Plug the power cord into a standard 220-240 volt AC electrical outlet. Ensure the outlet is properly grounded.
4. **Initial Cleaning:** Wipe the cooktop surface with a soft, damp cloth before first use.

Operating Instructions

Basic Operation:

1. Place an induction-compatible pot or pan centrally on the cooktop surface.
2. Press the **On/Off** button to power on the cooktop. The LED display will illuminate.
3. Select a cooking function using the **Function** button or choose from the pre-set menus.
4. Adjust the power or temperature using the **+/-** buttons.
5. To turn off, press the **On/Off** button again. The fan may continue to run for a short period to cool the unit.

8 Auto Cook Indian Menus:

The cooktop features 8 pre-programmed Indian menus for convenient cooking. Press the **Function** button repeatedly to cycle through these options. The display will show the selected menu. The cooktop will automatically adjust power and time settings for optimal results.

Pre-set Timer Function:

To use the timer:

1. After selecting a cooking function, press the **Timer/Pre-set** button.
2. Use the **+/-** buttons to set the desired cooking duration.
3. The cooktop will operate for the set time and then automatically switch off.

Variable Time, Temperature & Power Selection:

For manual control, you can adjust the power (wattage) or temperature (degrees Celsius) using the **+/-** buttons after selecting a general cooking mode. The LED display will indicate the current setting.

Maintenance and Cleaning

- Always unplug the cooktop and allow it to cool completely before cleaning.
- Wipe the glass surface with a soft, damp cloth and mild detergent. For stubborn stains, use a non-abrasive cleaner specifically designed for induction cooktops.
- Do not use abrasive pads, harsh chemicals, or steel wool, as these can scratch the surface.
- Clean the ventilation openings regularly to prevent dust accumulation, which can affect performance. Use a soft brush or vacuum cleaner.
- Ensure no water enters the internal components.

Troubleshooting

Problem	Possible Cause	Solution
Cooktop does not turn on	No power supply; Power cord not plugged in; Main switch off	Check power outlet; Plug in power cord securely; Turn on main switch
Cooktop beeps and displays an error code	Non-induction compatible cookware; No cookware on surface; Overheating	Use induction-compatible cookware; Place cookware on surface; Allow cooktop to cool down
Cooking process is slow	Low power setting; Cookware not suitable for induction	Increase power setting; Ensure cookware has a flat, magnetic base
Fan continues to run after turning off	Normal cooling process	This is normal; the fan will stop automatically once cooled

If the problem persists after attempting these solutions, please contact customer support.

Specifications

- **Model Number:** 740076
- **Wattage:** 2100 Watts
- **Operating Voltage:** 220 - 240 Volts
- **Controls Type:** Touch
- **Heating Elements:** 1
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Color:** Black
- **Product Dimensions:** 36.5D x 29W x 41H Centimeters
- **Item Weight:** 5.2 Kilograms
- **Special Features:** Portable, Timer
- **Included Components:** Induction Cooktop, Instruction Manual, Warranty Card
- **Country of Origin:** India

Warranty Information

This Bajaj ABS Majesty Slim 2100-Watt Induction Cooktop comes with a **1 Year Warranty** from the date of purchase. Please refer to the included Warranty Card for detailed terms and conditions, including coverage and exclusions. Keep your purchase receipt as proof of purchase for warranty claims.

Customer Support

For any queries, service requests, or technical assistance regarding your Bajaj Induction Cooktop, please contact Bajaj customer support. Refer to the contact information provided on your Warranty Card or visit the official Bajaj website for the latest support details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question