Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 2018102805

Instruction Manual for YING RAY Air Conditioner Remote Control

Model: 2018102805

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your YING RAY Replacement Air Conditioner Remote Control. Please read this manual carefully before use to ensure proper functionality and longevity of your remote control.

Product Overview

The YING RAY Replacement Remote Control is designed to be compatible with various Soleus Air, Danby, and ARCTICAIRE air conditioner models. It offers all the essential functions of the original remote, allowing you to control your air conditioner with ease.





Image: Front view of the YING RAY Replacement Air Conditioner Remote Control, showing its display and button layout.



Image: A visual representation of the YING RAY remote alongside several other compatible remote control models, illustrating its broad compatibility.

Setup

Battery Installation

The remote control requires two "AAA" 1.5V ordinary batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two "AAA" batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote is ready for use without any programming.

Operating Instructions

Button Functions

Button	Function
I/O (Power)	Turns the air conditioner ON or OFF.
MODE	Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
FAN	Adjusts fan speed (e.g., Low, Medium, High, Auto).
SWING	Activates or deactivates the automatic louver swing function.
SLEEP	Activates or deactivates sleep mode for quiet operation and energy saving.
T-ON	Sets the timer for automatic power ON.
T-OFF	Sets the timer for automatic power OFF.
HOUR	Adjusts the hour setting for the timer or clock.
MIN	Adjusts the minute setting for the timer or clock.
+ / -	Increases or decreases the temperature setting. Also used for adjusting timer settings.
C/F	Switches the temperature display between Celsius and Fahrenheit.
RESET	Resets the remote control settings. May require a pointed object to press.

Temperature Display

The remote control display supports both Fahrenheit and Celsius temperature units. Use the C/F button to toggle between these display options as needed.

Maintenance

Cleaning

To maintain the remote control's appearance and functionality, wipe it regularly with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and corrosion. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Solution
Remote not responding to air conditioner.	Check battery orientation and ensure they are fresh. Point the remote directly at the air conditioner's receiver. Ensure there are no obstructions between the remote and the AC unit.
Display is dim or blank.	Replace the batteries with new ones. If the issue persists, contact customer support.
Temperature or timer settings are inaccurate.	Press the RESET button (if available) using a small pointed object. Re-enter desired settings. Note that some remotes may have minor clock inaccuracies as reported by users.

Problem	Solution
Remote does not control my specific AC model.	Verify that your air conditioner model is listed as compatible. If it is and still doesn't work, contact the seller for assistance.

Specifications

- **Model Number:** 2018102805
- **Compatible Devices:** Soleus Air, Danby, ARCTICAIRE Air Conditioners (various models including LX-100, PH5 Series, APAC9036, DPAC120068, etc.)
- **Power Source:** 2 x AAA 1.5V Batteries (not included)
- **Package Dimensions:** 6.18 x 4.53 x 0.87 inches
- **Item Weight:** 1.76 ounces
- **Special Feature:** Ergonomic design

Warranty and Support

This product is designed for reliable performance. For any issues not covered in this manual, or if the remote does not work for your specific air conditioner model despite being listed as compatible, please contact the seller directly for support and warranty information. They will be able to provide further assistance or arrange for a replacement if necessary.
Please retain your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07JYZMH8M

More documents and user manuals: **https://manuals.plus/**