Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RC4875

ALLIMITY RC4875 Universal Remote Control User Manual

Model: RC4875

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your ALLIMITY RC4875 Universal Remote Control. Please read this manual thoroughly before use to ensure proper functionality and to avoid damage. This remote is designed to replace original remote controls for a wide range of TV brands, offering broad compatibility and ease of use.

2. Safety Information

- Keep the remote control out of reach of children.
- Do not expose the remote control to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the remote control to strong impacts.
- Dispose of used batteries properly according to local regulations. Do not mix old and new batteries, or different types of batteries.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage.

3. Package Contents

- 1 x ALLIMITY RC4875 Universal Remote Control

4. Product Overview

The ALLIMITY RC4875 remote control features a standard layout designed for intuitive operation across various television models. Below are images illustrating the remote's design and a description of its key buttons.

Figure 4.1: Front view of the ALLIMITY RC4875 Universal Remote Control, showing all buttons clearly.



Figure 4.2: Angled view of the ALLIMITY RC4875 Universal Remote Control, highlighting its ergonomic design.



Figure 4.3: The ALLIMITY RC4875 Universal Remote Control shown in a typical living room environment, demonstrating its compact size relative to a television.

Button Functions:

- **Power Button (●):** Turns the connected device (TV) on or off.
- **Number Buttons (0-9):** For direct input of channel numbers.
- **Volume Up/Down (V+/V-):** Adjusts the audio volume level.
- **Channel Up/Down (P+/P-):** Changes the television channel.
- **Mute Button ( ):** Mutes or unmutes the audio.
- **Menu Button:** Accesses the main menu of the connected device.
- **OK Button:** Confirms selections within menus or activates functions.
- **Back Button:** Returns to the previous screen or menu.
- **Exit Button:** Exits the current menu or application.
- **Colored Buttons (Red, Green, Yellow, Blue):** These buttons have varying functions depending on the specific device and content being viewed (e.g., teletext, smart TV features).
- **Playback Controls (Rewind, Play/Pause, Fast Forward, Stop, Record):** Used for controlling media playback on compatible devices.
- **LANG Button:** Used for language selection, typically for audio tracks or subtitles.
- **Info Button (i):** Displays information about the current program or content.

5. Setup

5.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two new **Alkaline** batteries (AAA size, not included) into the compartment, ensuring the positive (+) and negative (-) terminals match the markings inside.
4. Slide the battery cover back into place until it clicks securely.

5.2 Initial Setup and Pairing

The ALLIMITY RC4875 Universal Remote Control is designed for immediate use with many compatible devices, often requiring no complex programming. Follow these steps for initial setup:

1. Ensure batteries are correctly installed as per Section 5.1.
2. Point the remote control directly at your television or compatible device.
3. Press any button (e.g., Power, Volume Up) to test if the remote immediately controls your device.
4. If the remote does not immediately respond, press and hold the**Power** button for a few seconds. The remote is designed to automatically detect and pair with compatible televisions during this process. Release the button once your device responds.

5. Test all primary functions (Power, Volume, Channel) to confirm successful pairing.

Note: This remote is pre-programmed for broad compatibility and typically does not require manual code entry for supported models.

6. Operating Instructions

Once set up, operating the ALLIMITY RC4875 is straightforward. Ensure there is a clear line of sight between the remote control and the infrared receiver on your device.

6.1 Basic Functions

- **Power On/Off:** Press the ● Power button once.
- **Volume Control:** Press **V+** to increase volume, **V-** to decrease volume.
- **Channel Change:** Press **P+** to go to the next channel,**P-** to go to the previous channel.
- **Direct Channel Entry:** Use the number buttons (0-9) to enter a specific channel number.
- **Mute:** Press the Mute button to silence the audio. Press again to restore.

6.2 Advanced Functions

- **Menu Navigation:** Use the **Menu** button to access your device's settings. Use the directional pad (if present on your TV) or channel/volume buttons to navigate, and **OK** to select.
- **Input/Source Selection:** Some TVs may respond to a dedicated input button (if present on the remote) or through the main menu.
- **Colored Buttons:** The functionality of the Red, Green, Yellow, and Blue buttons is specific to the content or application on your TV. Refer to your TV's manual for their specific uses.
- **Media Playback:** Use the playback control buttons (Rewind, Play/Pause, Fast Forward, Stop, Record) when watching content from a connected media player or smart TV app.

7. Maintenance and Care

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the surface or internal components.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time.

8. Troubleshooting

Problem	Possible Cause	Solution
Remote is not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and device. Remote is not paired.	Check battery orientation and replace with new Alkaline batteries. Ensure clear line of sight to the device's IR receiver. Try the initial setup/pairing steps again (Section 5.2).

Problem	Possible Cause	Solution
Only some functions work.	Partial compatibility with the device.	While the remote offers broad compatibility, some specific or advanced functions may not be supported by all television models. Verify your TV model is listed among the compatible devices.
Remote response is slow or intermittent.	Low battery power. Interference.	Replace batteries. Ensure no strong light sources (like direct sunlight) are interfering with the IR signal.

9. Specifications

Brand	ALLIMITY
Model Number	RC4875
Connectivity Technology	Infrared (IR)
Number of Buttons	20
Controller Type	Button Control
Maximum Range	10 Meters (approx. 33 feet)
Battery Type	Alkaline (AAA size)
Compatible Devices	Various TV brands including Oceanic, OK., Continental Edison, CELCUS, Bush, OKI, Technika, Finlux, Tucson, AYA, Ansonic, Digihome, and Clayton.
UPC	799862192403

10. Warranty and Support

Warranty information for the ALLIMITY RC4875 Universal Remote Control is not provided within this user manual. For details regarding warranty coverage, returns, or technical support, please refer to your purchase documentation, the seller's website, or contact ALLIMITY customer service directly.

For further assistance, you may also visit the product page on Amazon.com.be:ALLIMITY RC4875 on Amazon.com.be

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07JZ59H7X

More documents and user manuals: **https://manuals.plus/**