Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZIHNIC WH-816

ZIHNIC Bluetooth Headphones (Model WH-816) User Manual

Model: WH-816 | Brand: ZIHNIC

Introduction

Thank you for choosing ZIHNIC Bluetooth Over-Ear Headphones. These headphones are designed to provide an exceptional audio experience with versatile connectivity options and superior comfort. This manual will guide you through the features and functions of your new headphones.



Image: ZIHNIC Bluetooth Over-Ear Headphones in Rose Gold, showcasing the headphones and their protective carrying case.

Key Features:

- **Astonishing Sound Production:** High Definition Stereo with noise reduction technology designed to prevent ambient noises and focus on what you want to hear.
- **Built for Comfortability:** Artificial leather earmuffs, foldable and stretchable design for a perfect fit.
- **Seamless Bluetooth Connection:** Quick and stable pairing with all Bluetooth-enabled devices.
- **Ergonomic Design:** Premium outlook with super soft memory-protein foam leather earmuffs and headbands.
- **Long Battery Life & Dual Mode:** Up to 14 hours of music time, with wired mode option for continuous use.

Setup

1. What's Included:

Before you begin, please ensure all components are present in the package:

- ZIHNIC Bluetooth Headphones
- Protective Premium Case
- USB Charging Cable
- 3.5mm Audio Cable
- User Manual (this document)



Image: The ZIHNIC headphones, their protective case, charging cable, audio cable, and user manual, as included in the package.

2. Charging the Headphones:

For optimal performance, fully charge your headphones before first use.

1. Connect the small end of the USB charging cable to the USB Charging Port on the headphones.
2. Connect the larger end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
3. The LED Indicator will illuminate during charging. It takes approximately 2.5 hours for a full charge.
4. Once fully charged, the LED Indicator will change color or turn off (refer to specific model indicator behavior).

A full charge provides up to 14 hours of music playback.

3. Bluetooth Pairing:

Follow these steps to pair your headphones with a Bluetooth-enabled device:

1. Ensure the headphones are charged.
2. Slide the ON/OFF button to the "ON" position. The headphones will enter pairing mode, indicated by a flashing LED light.
3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "ZIHNIC" from the list of found devices.
5. Once connected, the LED light will stop flashing and remain solid, indicating a successful pairing.
6. If prompted for a password, enter "0000".

The headphones will automatically attempt to reconnect to the last paired device when powered on.

Operating Instructions

Controls Overview:



Image: A detailed diagram illustrating the location and function of the ON/OFF switch, Multifunction button, Volume/Previous, Volume/Next, MP3/FM Mode button, Micro SD/TF card slot, LED Indicator, USB Charging Port, Built-in microphone, and Headphone jack.

Headphone Controls

Button/Port	Function
ON/OFF Switch	Powers the headphones on or off.
Multifunction Button (▶▶/▶)	Short press: Play/Pause music, Answer/End calls. Long press: Reject calls. Double press: Redial last number.
Vol+/Previous	Short press: Increase volume. Long press: Go to previous track.
Vol-/Next	Short press: Decrease volume. Long press: Go to next track.
M (MP3/FM Mode)	Switches between Bluetooth, Micro SD/TF card, and FM radio modes.
Micro SD/TF Card Slot	Insert a Micro SD/TF card to play music directly.
Headphone Jack (3.5mm)	Connect the 3.5mm audio cable for wired listening.
Built-in Microphone	Enables hands-free communication during calls (works only in wireless/Bluetooth mode).

Using Dual Mode (Wireless & Wired):

Your ZIHNIC headphones offer both wireless Bluetooth connectivity and a wired option for continuous listening.



Image: The ZIHNIC headphones demonstrating their wireless functionality with a battery icon, and their wired functionality connected via a 3.5mm audio cable.

- **Wireless Mode:** Connect via Bluetooth as described in the "Bluetooth Pairing" section. Enjoy freedom of movement.
- **Wired Mode:** If the battery runs low or you prefer a wired connection, simply plug the included 3.5mm audio cable into the headphone jack and the other end into your audio source. The headphones will automatically switch to wired mode.

Maintenance

Proper care and maintenance will extend the life of your ZIHNIC headphones.

- **Cleaning:** Use a soft, dry cloth to wipe the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in the provided protective premium case to prevent dust and damage. The foldable design makes them compact for storage.
- **Battery Care:** Avoid fully discharging the battery frequently. Charge the headphones regularly, even if not used for extended periods, to maintain battery health.

- **Environmental Conditions:** Keep headphones away from extreme temperatures, humidity, and direct sunlight.



Image: The ZIHNIC headphones in their folded state, positioned beside their protective carrying case, highlighting their portability and ease of storage.

Troubleshooting

If you encounter issues with your headphones, refer to the following common problems and solutions:

Common Troubleshooting Steps

Problem	Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source and check the LED indicator.

Problem	Solution
Cannot pair via Bluetooth.	• Ensure headphones are in pairing mode (flashing LED). • Make sure Bluetooth is enabled on your device. • Move headphones closer to the device (within 10 meters). • Forget/remove "ZIHNIC" from your device's Bluetooth list and try pairing again. • Restart both the headphones and your device.
No sound or low volume.	• Increase volume on both the headphones and your connected device. • Ensure headphones are properly paired or the 3.5mm cable is securely connected. • If using Micro SD/TF card, ensure the card is inserted correctly and contains compatible audio files.
Poor sound quality or distortion.	• Move closer to the Bluetooth device to avoid interference. • Check the audio source for quality issues. • Ensure the 3.5mm cable is not damaged if in wired mode.
Microphone not working.	Ensure headphones are in wireless (Bluetooth) mode. The microphone does not function in wired mode. Check device settings to ensure ZIHNIC is selected as the audio input.

If the problem persists, please contact customer support.

Specifications

Technical Specifications

Feature	Detail
Model Name	WH-816
Connectivity Technology	Wireless (Bluetooth), Wired (3.5mm Jack)
Wireless Communication Technology	Bluetooth 5.0
Bluetooth Range	10 Meters
Ear Placement	Over Ear
Noise Control	Sound Isolation
Frequency Response	20 Hz - 20 KHz
Impedance	32 Ohm
Battery Life	14-15 Hours (Music Time)
Charging Time	2.5 Hours
Material	Leather (Earmuffs)
Item Weight	0.3 Milligrams
Product Dimensions	6.7 x 6.7 x 3.35 inches

Feature	Detail
Compatible Devices	All Bluetooth or 3.5mm plug cable enabled devices (phones, tablets, PCs, etc.)

Warranty and Support

ZIHNIC stands behind the quality of its products.

- **Warranty:** Your ZIHNIC headphones are covered by a 12-month warranty from the date of purchase. This warranty covers manufacturing defects and ensures 100% customer satisfaction.
- **Customer Support:** For any questions, concerns, or technical assistance, please contact our 24/7 Customer Support service. Refer to your purchase documentation or the ZIHNIC official website for contact details.

We are committed to providing you with an excellent experience.

© 2025 ZIHNIC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07K5214NZ

More documents and user manuals: **https://manuals.plus/**