AEG MBE2657DEM 947608725

AEG MBE2657DEM Microwave Oven Instruction Manual

Model: MBE2657DEM 947608725

With Barbecue Function, 900 Watt, 26 Liter Capacity

1. Introduction

Thank you for choosing the AEG MBE2657DEM Microwave Oven. This appliance is designed to provide efficient and versatile cooking, reheating, and defrosting capabilities, including a grill function for professional results. Please read this manual carefully before using the appliance to ensure safe and optimal operation.



Figure 1.1: Front view of the AEG MBE2657DEM Microwave Oven.

2. Safety Information

Always adhere to the following safety precautions to prevent personal injury or damage to the appliance:

- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the door (e.g., bent), hinges and latches (e.g., broken or loosened), or door seals and sealing surfaces.
- Only qualified service personnel should adjust or repair this oven.
- Ensure the appliance is properly grounded.
- Do not heat liquids or other foods in sealed containers since they are liable to explode.
- Always use microwave-safe cookware.

3. Setup and Installation

3.1 Unpacking

Carefully remove all packaging materials from the microwave oven. Inspect the appliance for any signs of damage. Keep packaging materials out of reach of children.

3.2 Placement and Electrical Connection

The AEG MBE2657DEM is a built-in microwave oven. Ensure the installation space meets the required dimensions for proper ventilation and operation. Refer to the specifications section for detailed dimensions.

- The appliance requires a 230 Volts power supply.
- The total wattage is 1250 watts.
- Ensure the electrical outlet is easily accessible after installation.



Figure 3.1: The microwave oven installed in a kitchen setting.

3.3 Initial Use

Before first use, clean the interior of the microwave with a damp cloth. Place the turntable and turntable support ring inside the oven cavity.

4. Operating Instructions

4.1 Control Panel Overview

The microwave features an intuitive electronic touch door and a smooth glass surface with no physical buttons, making it easy to clean. Operations are controlled via a central knob and touch-sensitive icons.





Figure 4.1: Control Panel.



Figure 4.2: Rotary Control Knob.

4.2 Opening the Door

The microwave features an electronic touch door. To open, simply press the designated touch area on the control panel. This provides quick and convenient access to the oven cavity.



Figure 4.3: Electronic Touch Door Operation.

4.3 Microwave Cooking

To cook with microwave power:

1. Place food in a microwave-safe container on the turntable.
2. Close the door.
3. Select the desired power level using the control knob.
4. Set the cooking time.
5. Press Start.

4.4 Grill Function

The integrated grill function allows you to achieve a professional finish for your dishes, adding crispness and browning. Use the grill rack provided for optimal results.

4.5 Defrost Function

The defrost function allows for quick and even thawing of frozen foods. Select the defrost mode and input the weight or type of food as prompted by the display.



Figure 4.4: Defrosting Example.

5. Maintenance and Cleaning

Regular cleaning ensures the longevity and hygienic operation of your microwave oven. Thanks to its slim design and smooth glass surface, cleaning is made easy.

5.1 Cleaning the Interior

- Wipe the interior cavity, door seals, and door surfaces with a damp cloth after each use.
- For stubborn stains, use a mild detergent or a specialized microwave cleaner. Avoid abrasive cleaners or scouring pads.
- The turntable and turntable support can be removed for cleaning. They are typically dishwasher safe, but check the material for specific care instructions.



Figure 5.1: Interior with Turntable and Grill Racks.

5.2 Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. The stainless steel finish is designed to be anti-fingerprint, making it easier to maintain a clean appearance.

6. Troubleshooting

If you encounter issues with your microwave oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Oven does not start	Door not closed properly; Power cord unplugged; Fuse blown or circuit breaker tripped.	Ensure door is firmly closed; Check power connection; Reset circuit breaker or replace fuse.
Food not heating	Incorrect power level or cooking time set; Microwave-safe cookware not used.	Adjust power level and time; Use appropriate cookware.
Turntable not rotating	Turntable not correctly placed; Debris under turntable.	Reposition turntable; Clean under the turntable.

If the problem persists after attempting these solutions, please contact qualified service personnel.

7. Specifications

Detailed technical specifications for the AEG MBE2657DEM Microwave Oven:

Model Info: MBE2657DEM 947608725

Capacity: 26 Liters

Installation Type: Built-In

Product Dimensions: 15.91"D x 23.46"W x 15.28"H (40.4 cm D x 59.6 cm W x 38.8 cm H)

Item Weight: 39.6 pounds (18 Kilograms)

Wattage: 1250 watts

Voltage: 230 Volts

Color: Stainless Steel With Anti-fingerprint Print

Material Type: Stainless Steel (Exterior), Glass (Interior)

Oven Cooking Mode: Grill, Microwave, Defrost

Special Features: Electronic Watch, Quartz Barbecue, End of cooking with sound signal, Child Safety, LED interior lighting.

Door Hinges: Left

Certification: Energy Star

Included Components: Turntable

8. Warranty and Support

8.1 Warranty Information

This AEG appliance comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, spare parts, or service requests, please contact AEG customer support. Contact details can typically be found on the AEG official website or in the documentation provided with your appliance.

© 2024 AEG. All rights reserved.