MIFA M520

MIFA M520 Bluetooth Speaker User Manual

Model: M520

Introduction

This manual provides detailed instructions for the safe and effective operation of your MIFA M520 Bluetooth Speaker. Please read this manual thoroughly before using the product and retain it for future reference. Understanding the features and functions will ensure optimal performance and longevity of your device.

Package Contents

Please check the package for the following items:

- MIFA M520 Bluetooth Speaker
- Wireless Microphone
- USB Charging Cable
- Auxiliary Audio Cable
- User Manual (this document)

Product Overview

Familiarize yourself with the components of your MIFA M520 speaker.



Figure 1: MIFA M520 Bluetooth Speaker shown alongside its wireless microphone. The speaker features a robust black casing with a front grille and a top handle for portability.



Figure 2: Top panel of the MIFA M520 speaker, displaying various control knobs and buttons, including volume controls, mode selection, and a digital display. The handle is visible at the top.

Control Panel Functions:

- **Power Button:** Press and hold to turn the speaker on or off.
- **Mode Button:** Short press to switch between Bluetooth, Aux, USB, and TF card modes.
- **Volume Knobs:** Rotate to adjust master volume, microphone volume, and echo effect.
- **Play/Pause Button:** Short press to play or pause audio in Bluetooth/USB/TF modes.
- **Previous/Next Track Buttons:** Short press to skip tracks.
- **Microphone Input:** Port for wired microphone (if applicable) or for the wireless microphone receiver.
- **USB Port:** For USB drive playback.
- **TF Card Slot:** For TF (MicroSD) card playback.
- **AUX Input:** 3.5mm jack for connecting external audio devices.
- **Charging Port:** DC 5V input for charging the speaker.

Setup

1. Initial Charging

Before first use, fully charge the MIFA M520 speaker. Connect the provided USB charging cable to the speaker's charging port and the other end to a 5V USB power adapter (not included) or a computer USB port. The charging indicator light will illuminate during charging and turn off when fully charged.

2. Powering On/Off

To power on the speaker, press and hold the**Power Button** for approximately 3 seconds. You will hear an audible prompt. To power off, press and hold the **Power Button** again for 3 seconds.

Operating Instructions

1. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode. If not, short press the**Mode Button** until "Bluetooth" or a Bluetooth icon appears on the display. The speaker will enter pairing mode, indicated by a flashing Bluetooth indicator.
2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "MIFA M520" from the list of found devices.
4. Once paired, the speaker will emit a confirmation tone, and the Bluetooth indicator will stop flashing.
5. You can now play audio from your device through the MIFA M520 speaker.

2. Karaoke Mode with Wireless Microphone

1. Power on the MIFA M520 speaker.
2. Insert the wireless microphone's receiver into the designated microphone input port on the speaker.
3. Power on the wireless microphone. It should automatically connect to the receiver.
4. Adjust the microphone volume and echo effect using the dedicated knobs on the speaker's control panel.
5. Play your desired backing track via Bluetooth, USB, or Aux input, and sing along.

3. TWS (True Wireless Stereo) Pairing (Requires two MIFA M520 speakers)

1. Ensure both MIFA M520 speakers are powered on and in Bluetooth mode, but not connected to any device.
2. On one speaker (this will be the primary speaker), press and hold the**TWS Button** (if available, or a combination of buttons as per specific model instructions).
3. The speakers will attempt to pair with each other. A confirmation tone will sound once TWS pairing is successful.
4. Connect your mobile device to the primary speaker via Bluetooth as described in "Bluetooth Pairing" above. Audio will now play in stereo through both speakers.

Note: Specific TWS pairing instructions may vary. If a dedicated TWS button is not present, refer to the speaker's on-screen prompts or a combination of existing buttons for TWS activation.

4. Auxiliary (AUX) Input

Connect one end of the 3.5mm auxiliary audio cable to the AUX input port on the MIFA M520 speaker and the other end to the audio output jack of your external device (e.g., MP3 player, computer). Short press the **Mode Button** to select AUX mode. Audio will play directly from your connected device.

5. USB/TF Card Playback

Insert a USB flash drive or a TF (MicroSD) card containing audio files into the respective port. The speaker will automatically switch to USB or TF card mode and begin playback. Use the **Play/Pause** and **Previous/Next Track** buttons to control playback.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners, alcohol, or other

chemical solvents, as these may damage the surface.

- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge the speaker regularly, even if not in use for extended periods.
- **Water Exposure:** This speaker is not waterproof. Avoid exposing it to water or excessive moisture.

Troubleshooting

Problem	Solution
Speaker does not power on.	Ensure the speaker is fully charged. Connect the charging cable and try again.
Cannot pair via Bluetooth.	• Ensure the speaker is in Bluetooth pairing mode (flashing indicator). • Make sure Bluetooth is enabled on your device. • Move the speaker closer to your device. • Forget "MIFA M520" from your device's Bluetooth list and try pairing again. • Restart both the speaker and your device.
No sound.	• Check the volume levels on both the speaker and your connected device. • Ensure the correct input mode (Bluetooth, Aux, USB, TF) is selected. • If using Aux, ensure the cable is securely connected.
Microphone not working.	• Ensure the wireless microphone is powered on and paired with the speaker. • Check the microphone volume knob on the speaker. • Ensure the microphone receiver is securely plugged into the speaker's microphone input.

Specifications

Brand	MIFA
Model	M520
Speaker Type	3D
Connectivity Technology	Bluetooth, Wireless
Power Source	Battery Powered
RMS Power Range	50 Watts
Audio Input	Auxiliary
Compatible Devices	Smartphone, Tablet
Mounting Type	Tabletop
Colour	Black

Warranty and Support

The MIFA M520 Bluetooth Speaker comes with a **30-day warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For technical support, warranty claims, or further assistance, please contact MIFA customer service through their official website or the retailer where the product was purchased. Please have your proof of purchase and product model number ready when contacting support.

© 2023 MIFA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question