Spilay Florence

Spilay Florence DIY Miniature Dollhouse Kit Instruction Manual

Brand: Spilay | Model: Florence

1. Introduction

This manual provides comprehensive instructions for assembling, operating, and maintaining your Spilay Florence DIY Miniature Dollhouse Kit. This 1:24 scale model is a creative craft project designed for adults and individuals aged 14 and above. The kit includes all necessary wooden, fabric, and paper components, along with LED lights and a music box, to construct a detailed miniature house.

Please read all instructions carefully before beginning assembly to ensure a smooth and enjoyable building experience. Familiarize yourself with all parts and tools required.



Image 1.1: The fully assembled Spilay Florence DIY Miniature Dollhouse Kit.

2. Safety Information

Warning: Choking Hazard - Small Parts. This kit contains small components that may pose a choking hazard. Not suitable for children under 3 years of age. Adult supervision is recommended for users under 14 years.

- Keep all small parts and tools out of reach of young children and pets.
- Use glues and paints in a well-ventilated area. Refer to the safety instructions of any adhesives or paints used.
- Exercise caution when using sharp tools such as scissors, craft knives, or tweezers.
- Dispose of waste materials responsibly.

3. Package Contents

Your Spilay Florence DIY Miniature Dollhouse Kit includes the following:

- Pre-cut wooden pieces for structural components and furniture.
- Fabric and paper materials for decorations, wallpaper, and upholstery.
- LED lighting components with wiring.
- Music box mechanism.
- Various small accessories and decorative items.
- Detailed English instruction manual with illustrations.

Note: The package does **not** include liquid silicone glue or 2 AAA batteries. These items must be purchased separately as they cannot be shipped by air.

4. Setup and Assembly

Assembly of the Spilay Florence dollhouse requires patience and attention to detail. Follow the provided English manual step-by-step for the best results.

4.1. Required Tools and Materials (Not Included)

- Liquid silicone glue (or similar craft adhesive suitable for wood, paper, and fabric).
- 2 x AAA batteries for LED lights.
- Small scissors or craft knife.
- Tweezers (highly recommended for small parts).
- Ruler and pencil.
- Small screwdriver (for battery compartment).

4.2. General Assembly Steps

1. **Unpack and Organize:** Carefully unpack all components. It is highly recommended to sort parts by type or according to the numbering in the instruction manual. This will prevent confusion and missing pieces during assembly.
2. **Review Instructions:** Read through the entire instruction manual once before starting. Pay close attention to diagrams and specific warnings.
3. **Prepare Components:** Some wooden pieces may require gentle sanding to remove burrs or ensure a perfect fit. Fabric and paper pieces may need to be cut according to templates or measurements provided.
4. **Structural Assembly:** Begin by assembling the main structure of the dollhouse as indicated in the manual. Use glue sparingly but effectively to ensure strong bonds. Allow sufficient drying time for each section before proceeding.
5. **Furniture and Decorations:** Assemble the miniature furniture and decorative elements. These often involve intricate steps and require precision.
6. **Electrical Wiring (LEDs):** Install the LED lighting system according to the diagrams. Ensure all connections are secure. The battery compartment will need 2 AAA batteries installed (see Section 5.1).
7. **Music Box Installation:** Integrate the music box mechanism into the designated area as per the instructions.
8. **Final Touches:** Add all remaining decorative items and ensure all parts are securely attached.



Image 4.1: An exterior view of the Florence dollhouse, showcasing its modern design.

PRODUCT INFORMATION

NAME : FLORENCE

FINISH TIME : 2-3 DAY

FINISHED SIZE : 9.05*3.93*7.87in

MATERIAL: WOOD . PAPER. PLASTIC

FUNCTIONALATTRIBUTES : MODEL/PUZZLE/GIFT/COLLECTION

INCLUDED : ALL FURNITURE . MUSIC BOX .LED

DIFFICULTY: ★★★☆



Image 4.2: Detailed view of the dollhouse interior, including furniture and lighting.



Image 4.3: Close-up of a room inside the Florence dollhouse, highlighting intricate details.

5. Operating Instructions

5.1. LED Lighting

The LED lights in your dollhouse are powered by 2 AAA batteries (not included). Ensure these are installed correctly in the designated battery compartment, observing polarity (+/-).

- Locate the battery compartment, typically found at the base or rear of the dollhouse.
- Open the compartment cover using a small screwdriver if necessary.
- Insert 2 fresh AAA batteries, matching the polarity markings.
- Close the compartment cover securely.

- Activate the lights using the switch provided, usually located near the battery compartment or integrated into the wiring.

5.2. Music Box

The integrated music box plays the tune "Castle in the Sky".

- Locate the winding key or mechanism for the music box, as indicated in your assembly manual.
- Gently turn the key clockwise to wind the mechanism. Do not overwind.
- Release the key to hear the melody.

6. Maintenance

6.1. Cleaning

- Dust the dollhouse regularly with a soft, dry cloth or a soft brush to prevent dust buildup in intricate areas.
- Avoid using liquid cleaners or abrasive materials, as these can damage the delicate components and finishes.

6.2. Storage

- Store the dollhouse in a dry environment, away from direct sunlight and extreme temperatures, to prevent warping or fading of materials.
- If storing for an extended period, remove the AAA batteries to prevent leakage and damage to the electrical components.

7. Troubleshooting

Problem	Possible Cause	Solution
LED lights do not turn on.	Batteries are dead or incorrectly installed. Loose wire connection. Switch is off.	Check and replace AAA batteries, ensuring correct polarity. Inspect all wire connections and re-secure if loose. Ensure the light switch is in the "ON" position.
Music box does not play.	Not wound sufficiently. Mechanism obstruction.	Gently wind the music box key clockwise. Check for any visible obstructions around the music box mechanism.
Parts do not fit together properly.	Incorrect part selection. Minor manufacturing variation (e.g., slight warping).	Double-check the instruction manual to ensure you are using the correct parts for each step. For minor fit issues, gentle sanding or trimming may be required. Do so carefully to avoid damage. If a significant part is warped or damaged, contact customer support.
Missing components.	Oversight during packaging. Misplaced during unpacking.	Thoroughly check all packaging materials and your workspace. If a part is genuinely missing, contact Spilay customer support with details of the missing component.

8. Specifications



Image 8.1: Product dimensions and features overview.

Model Name:	Florence
Brand:	Spilay
Scale:	1:24
Finished Dimensions (L x W x H):	23 cm x 10 cm x 20 cm (9.05 in x 3.93 in x 7.87 in)
Weight:	1.2 kg (2.6 lbs)
Materials:	Wood, Paper, Fabric

Power Source (LEDs):	2 x AAA Batteries (not included)
Music Box Tune:	Castle in the Sky
Recommended Age:	14 years and up
UPC:	192242498797
ASIN:	B07K8T35QW

9. Warranty and Customer Support

Spilay is committed to providing high-quality products and customer satisfaction. If you encounter any issues during assembly, find missing parts, or have questions regarding your kit, please do not hesitate to contact Spilay customer support.

For the best support and to ensure complete product accessories and after-sales service, it is recommended to purchase Spilay products directly from authorized retailers or the official Spilay store.

We aim to resolve any problems as quickly as possible to ensure you have a positive experience with your Spilay dollhouse kit.

© 2026 Spilay. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question