Tefal FV9845

Tefal Ultimate Pure Steam Iron FV9845 User Manual

Model: FV9845

Introduction

This manual provides essential instructions for the safe and efficient use of your Tefal Ultimate Pure Steam Iron, Model FV9845. Please read all instructions carefully before first use and retain for future reference.



Image: The Tefal Ultimate Pure Steam Iron, Model FV9845, in black and rose gold finish.

Safety Instructions

- Always ensure the voltage indicated on the iron corresponds to your mains voltage.
- Do not leave the iron unattended while it is switched on.
- Keep the iron and its cord out of reach of children.
- Never immerse the iron, power cord, or plug in water or any other liquid.
- Unplug the iron before filling with water, cleaning, or after each use.
- Use the iron only for its intended purpose.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

Product Overview

The Tefal Ultimate Pure Steam Iron FV9845 features advanced technology for efficient ironing.

- **Durilium Airglide Autoclean Soleplate:** Designed for smooth gliding and easy maintenance.
- **Micro-Calc Filter:** An exclusive 2-in-1 filter system that delivers 100% filtered steam to prevent calc stains on fabric.
- **Powerful Steam Output:** Provides continuous steam and a strong steam boost for stubborn wrinkles.
- **Large Water Tank:** 350ml capacity for extended ironing sessions.
- **Smart Auto-Off:** Enhances safety and energy efficiency by automatically shutting off the iron when left idle.
- **Long Power Cord:** A 3-meter cord for convenient use.



Image: Close-up of the Durilium Airglide Autoclean Soleplate, highlighting the pointed tip for reaching corners, 100% active steam holes for maximum distribution, and a round bottom to prevent creasing.

Setup

1. **Unpacking:** Carefully remove the iron from its packaging. Retain all packaging materials for potential future transport or storage.
2. **First Use:** Before first use, operate the iron for a few minutes without steam to eliminate any manufacturing residues. A slight odor or light smoke may occur, which is normal and will dissipate.
3. **Filling the Water Tank:**
    - Ensure the iron is unplugged.
    - Open the water tank inlet cover.
    - Fill the 350ml water tank with tap water up to the MAX level. Do not overfill.
    - Close the water tank inlet cover securely.



Image: A user filling the large 350ml water tank of the iron, demonstrating its capacity for extended use.

4. **Connecting to Power:** Plug the 3-meter power cord into a suitable electrical outlet. Ensure the outlet voltage matches the iron's specifications.

Operating Instructions

1. **Temperature Setting:** Adjust the temperature dial according to the fabric type. Allow the iron to heat up until the indicator light turns off, signaling the desired temperature has been reached.
2. **Steam Ironing:**
    - Once heated, select the desired steam level using the steam control.
    - For continuous steam, move the iron across the fabric.
    - For stubborn creases, press the steam boost button to deliver a powerful burst of steam (up to 260g/min).



Image: The iron emitting a powerful burst of steam, illustrating its 3100W steam performance for effective wrinkle removal.

3. **Dry Ironing:** For dry ironing, ensure the steam control is set to the 'no steam' position.
4. **Vertical Steaming:** The iron can be used for vertical steaming of hanging garments or curtains. Hold the iron vertically a few centimeters from the fabric and press the steam boost button.
5. **Smart Auto-Off Feature:** For safety and energy saving, the iron will automatically switch off if left motionless:
    - After 30 seconds if left on its side or soleplate.
    - After 8 minutes if left on its heel.

    To restart, simply move the iron.



Image: The iron resting on an ironing board, with an overlay indicating the 30-second auto-off when on its side and 8-minute auto-off when on its heel, highlighting the smart auto-off safety feature.

6. **Power Cord Management:** The extra-long 3-meter power cord provides flexibility during ironing. Ensure it is not tangled or obstructing movement.



Image: A person ironing with the Tefal Ultimate Pure, showcasing the convenience of the extra-long 3-meter power cord.

Maintenance

1. **Cleaning the Soleplate:**
    - Allow the iron to cool completely.
    - Wipe the soleplate with a damp cloth. Do not use abrasive cleaners or metallic scouring pads.
    - The Durilium Airglide Autoclean soleplate is designed for easy cleaning.
2. **Emptying the Water Tank:** After each use, unplug the iron and empty any remaining water from the tank.
3. **Micro-Calc Filter Cleaning:** The exclusive 2-in-1 micro-calc filter prevents limescale buildup.
    - Regularly remove and rinse the filter under running water.
    - Ensure the filter is completely dry before reinserting.
    - This process helps maintain 100% filtered steam and prevents calc stains on your linen.



Image: A close-up view of the Micro-Calc filter being removed and cleaned, showing accumulated limescale and emphasizing the importance of regular maintenance for pure steam.

4. **Storage:** Store the iron upright on its heel in a safe, dry place after it has cooled down and the water tank is empty.

Troubleshooting

If you encounter issues with your iron, please refer to the following common solutions:

- **Iron not heating:** Check if the iron is properly plugged into a working power outlet. Ensure the temperature dial is set to a fabric setting and not 'off'.
- **No steam or insufficient steam:**
  - Check if the water tank is filled.
  - Ensure the iron has reached the correct temperature for steam generation (indicator light off).
  - Verify the steam control is set to a steam position.
  - Clean the micro-calc filter if it appears clogged.
- **Water leaking from the soleplate:**

- The temperature setting might be too low for steam production, causing water to drip. Increase the temperature.
- Do not use the steam boost function too frequently in quick succession.
- Ensure the water tank is not overfilled.

- **White flakes on clothes:** This indicates limescale buildup. Clean the micro-calc filter as described in the Maintenance section.

If the problem persists, please contact customer support.

Specifications

Feature	Specification
Brand	Tefal
Model Number	FV9845
Color	Black & Rose Gold
Product Dimensions	32.7 x 16.8 x 0.1 cm
Item Weight	1.45 kg
Power / Wattage	3100 watts
Voltage	310 Volts
Steam Boost	260g/min
Water Tank Capacity	350ml
Power Cord Length	3 meters
Special Features	Limescale Prevention, Corded, High-Pressure Steam, Removable Tank
Soleplate Type	Durilium Airglide Autoclean

Warranty and Support

Tefal is committed to providing quality appliances. This product is designed for durability and repairability.

- **Repairability:** Tefal provides technical spare parts for almost all products for 15 years after purchase.
- **Customer Support:** For any questions, concerns, or service requests not covered in this manual, please contact your local Tefal customer service. Refer to the official Tefal website for contact information specific to your region.



Image: An emblem indicating Tefal's commitment to 15 years of repairability at a fair price, supported by 6200 approved repairers worldwide.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question