Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit AKB73615702

ZdalaMit AKB73615702 Replacement Remote Control Instruction Manual

For LG Blu-ray Disc DVD Players

1. Introduction

This manual provides instructions for the ZdalaMit AKB73615702 replacement remote control. This remote is designed to function with various LG Blu-ray Disc and DVD player models without requiring any programming or pairing.
Compatible LG Blu-ray/DVD Player Models:

- BH7420P
- BH7520T
- BP620N
- BP620
- BP620C
- BH7220B
- BP520

2. Setup

2.1 Battery Installation

The remote control requires two (2) 1.5V AAA alkaline batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Battery compartment with AAA batteries inserted.

2.2 Initial Use

No programming or pairing is required for this replacement remote control. Once batteries are correctly installed, the

remote is ready for immediate use with compatible LG Blu-ray Disc DVD players.

3. Operating Instructions

Point the remote control directly at your LG Blu-ray Disc DVD player. Ensure there are no obstructions between the remote and the player.



Figure 2: Front view of the remote control.

3.1 Key Functions

The remote control features standard buttons for Blu-ray and DVD player operation:

- **Power ():** Turns the player on or off.
- **Open/Close:** Opens or closes the disc tray.
- **Number Buttons (0-9):** For direct track selection or input.
- **Clear:** Clears current input.
- **Repeat:** Repeats playback.
- **Playback Controls:** Play, Pause, Stop, Fast Forward, Rewind, Skip Forward, Skip Back.
- **Title/Popup:** Accesses the disc's title or popup menu.
- **Home:** Returns to the player's home menu.
- **Info/Menu:** Displays information or accesses the main menu.
- **Navigation Pad (Up, Down, Left, Right, Enter):** Navigates menus and confirms selections.
- **Back:** Returns to the previous screen or menu.
- **Subtitle:** Selects subtitle options.
- **Disc Menu:** Accesses the disc's main menu.
- **Color Buttons (Red, Green, Yellow, Blue):** Functionality varies by disc or player menu.
- **AV/Input:** Selects audio/video input source.
- **Music ID:** (Specific function, refer to player manual).
- **Audio:** Selects audio tracks or modes.
- **Vol+** / **Vol-:** Adjusts volume.
- **PR/CH ^** / **PR/CH v:** Changes channels (if player supports TV control).
- **Mute:** Mutes audio output.

4. Maintenance

4.1 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these may damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's response becomes inconsistent or stops working. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries or different types of batteries.

4.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote control and the LG player.
  - Confirm the remote is pointed directly at the player's infrared sensor.
- **Specific buttons not working:**
  - This remote is pre-programmed for the listed LG models. If a specific button does not function, it may indicate

that the feature is not supported by your particular LG player model or disc.

6. Specifications

Model	AKB73615702
Brand	ZdalaMit
Power Supply	2 x 1.5V AAA Alkaline Batteries
Dimensions	6 x 2 x 0.5 inches (approximately)
Weight	2.12 ounces (without batteries)
Compatibility	LG Blu-ray Disc DVD Players (BH7420P, BH7520T, BP620N, BP620, BP620C, BH7220B, BP520)
Special Feature	Pre-programmed, no setup required

7. Support

For any questions or assistance regarding your ZdalaMit AKB73615702 replacement remote control, please contact the seller or manufacturer directly.

© 2025 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07KBVH67R

More documents and user manuals: **https://manuals.plus/**