**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## uehba RC-1120

# uehba RC-1120 Replacement Remote Control User Manual

For Denon AV Receiver Models: AVR-590, AVR-591, AVR390, DHT590BA, AVR-1610, AVR-391

## 1. Introduction

This manual provides instructions for the uehba RC-1120 Replacement Remote Control. This remote is designed to function as a direct replacement for original Denon AV Receiver remote controls, offering seamless operation without the need for complex programming.

**Compatible Denon AV Receiver Models:**

- AVR-590
- AVR-591
- AVR390
- DHT590BA
- AVR-1610
- AVR-391




*Image 1.1: The RC-1120 remote control displayed with a Denon AV receiver, highlighting its compatibility with various models.*

## 2. Setup: Battery Installation

The RC-1120 remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

**Important:** Ensure batteries are inserted with correct polarity. Do not mix old and new batteries, or different types of batteries.



Need 2x AAA batteries

(not included)

*Image 2.1: View of the remote's battery compartment with the cover removed, illustrating the correct placement for two AAA batteries.*

## 3. Operating Instructions

### 3.1. Initial Use

The uehba RC-1120 remote control is designed for immediate use with compatible Denon AV Receivers. No programming or setup is required. Once batteries are installed, the remote is ready to operate your device.




*Image 3.1: The RC-1120 remote control in use, emphasizing its plug-and-play functionality.*

### 3.2. Basic Functions

Point the remote control directly at the infrared sensor on your Denon AV Receiver. Ensure there are no obstructions between the remote and the receiver.

- **Power On/Off:** Use the **TV POWER** button (top right) or the **OFF/ON/SOURCE** buttons (top left) to control the power of your receiver.
- **Volume Control:** Use the **VOLUME +/-** buttons (right side of navigation cluster) to adjust the audio level.
- **Mute:** Press the **MUTE** button (above volume) to silence the audio. Press again to unmute.
- **Input Selection:** Use the dedicated input buttons (e.g.,**DVD**, **TV**, **TUNER**, **V.AUX**, **iPod**, **SPEAKERS**, **HDP**, **DVR**, **VCR**, **SAT/CBL**) to switch between different audio/video sources connected to your receiver.
- **Navigation:** Use the **MENU**, **ENTER**, and arrow (▲ ▼ ◀ ▶) buttons to navigate menus on your connected display.
- **Playback Controls:** Buttons like **SKIP+**, **SKIP-**, **PLAY/PAUSE** (||), **STOP** (■), **REWIND** (<<), **FAST FORWARD** (>>) control media playback.






*Image 3.2: Detailed view of the RC-1120 remote control's button layout for easy identification of functions.*

## 4. Maintenance

- **Cleaning:** To clean the remote, wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's performance degrades or it stops responding. Always replace both batteries at the same time.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.

## 5. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Remote not working or intermittent operation. | • Dead or weak batteries.<br>• Incorrect battery polarity.<br>• Obstruction between remote and receiver.<br>• Remote not pointed directly at receiver. | • Replace batteries with new AAA batteries.<br>• Check battery orientation (+/-).<br>• Remove any objects blocking the signal path.<br>• Ensure the remote is aimed directly at the receiver's IR sensor. |
| Specific functions not responding. | • Receiver not in correct input mode.<br>• Function not supported by your specific receiver model. | • Select the appropriate input source on the remote.<br>• Refer to your Denon AV Receiver's original manual for supported functions. |

## 6. Specifications

| | |
|---|---|
| **Model Name** | RC-1120 |
| **Brand** | uehba |

| | |
|---|---|
| **Connectivity Technology** | Infrared (IR) |
| **Compatible Devices** | Denon AV Receivers (AVR-590, AVR-591, AVR390, DHT590BA, AVR-1610, AVR-391) |
| **Power Source** | 2 x AAA Batteries (not included) |
| **Special Feature** | No Programming Required |
| **Maximum Range** | 10 meters (approx. 33 feet) |
| **Color** | Black |
| **Item Weight** | 73 g (approx. 2.57 oz) |
| **UPC** | 717877423824 |

## 7. Warranty and Support

### 7.1. Warranty Information

This uehba RC-1120 remote control comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or battery leakage.

### 7.2. Customer Support

If you encounter any issues or have questions regarding your uehba RC-1120 remote control, please contact the seller or retailer from whom you purchased the product. Provide your purchase details and a description of the issue for assistance.

For general inquiries, you may also refer to the product listing page onAmazon.com.

© 2023 uehba. All rights reserved.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07KC8VYLJ**

More documents and user manuals: **https://manuals.plus/**