ALLIMITY RC-1115 RC-1120 RC1120

ALLIMITY RC-1115 / RC-1120 Remote Control User Manual

Replacement Remote Control for Denon AV Surround Receivers

1. Introduction

This manual provides comprehensive instructions for the ALLIMITY RC-1115 / RC-1120 Replacement Remote Control. This remote is designed to operate various Denon AV Surround Receiver models, offering a direct replacement without the need for complex setup procedures. Please read this manual thoroughly to ensure proper use and longevity of your remote control.

2. Product Overview

The ALLIMITY RC-1115 / RC-1120 is a dedicated replacement remote control, replicating the functionality and layout of the original Denon remote. It features a standard button array for power, input selection, volume control, menu navigation, and specific functions for audio/video playback.





Figure 2.1: Front view of the RC-1115 remote control, displaying its full button layout including power, input selectors, numerical keys, navigation, volume, and iPod controls.




CD
1
2
3
CD-R/TAPE
4
5
6
AUX
7
8
9
PRESETS
BAND
TUNER
0
D.INPUTS
TEST
STATUS
DIMMER
SURROUND
PARAMETER
SETUP
VOLUME
MEMO/
ENTER
CH SEL
TONE
NIGHT
STEREO
SEARCH
MUTE
SURROUND
CHANNEL
iPod
REPEAT
RANDOM
RC-1115

Figure 2.2: Angled view of the RC-1115 remote, providing a perspective of its contours and button placement from the top-right.





Figure 2.3: Side profile of the RC-1115 remote, illustrating its ergonomic curve and overall thickness.



Figure 2.4: Top-down angled view of the RC-1115 remote, providing a clear look at the upper section of buttons including power and input selectors.



Figure 2.5: The RC-1115 remote control as it appears in its sealed plastic packaging, ready for shipment.

3. Setup

This remote control is designed for immediate use with compatible Denon AV Surround Receivers. No programming or complex setup is required.

3.1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.

Note: *Always use new alkaline batteries for optimal performance. Do not mix old and new batteries, or different types of batteries.*

4. Operating Instructions

The ALLIMITY RC-1115 / RC-1120 remote control is compatible with the following Denon AV Surround Receiver models: AVR-2807, AVR-2808, AVR-2809, AVR-590, DHT590BA, and AVR-1610. Its functions mirror those of the original remote.

4.1. Basic Functions

- **Power ON/OFF:** Press the **ON** or **OFF** buttons located at the top right and left corners to power your receiver on or off.
- **Input Selection:** Use the dedicated input buttons (e.g.,**DVD**, **VCR(iPod)**, **V.AUX**, **EXT.IN**, **CD**, **CD-R/TAPE**, **AUX**, **TUNER**) to switch between connected audio/video sources.
- **Volume Control:** Press the **VOLUME +** to increase volume and **VOLUME -** to decrease volume.
- **Mute:** Press the **MUTE** button to temporarily silence the audio output. Press again to restore sound.
- **Numerical Keypad:** Use the number buttons (0-9) for direct input, such as selecting radio presets or specific tracks.

4.2. Advanced Functions

- **Menu Navigation:** Use the directional arrow buttons (**Up**, **Down**, **Left**, **Right**) and the **MENU/ENTER** button in the center to navigate your receiver's on-screen menu.
- **Setup:** Press the **SETUP** button to access the receiver's setup menu.
- **Display Information:** Use **STATUS** or **DIMMER** buttons to adjust display settings or view system information.
- **Surround Modes:** The **SURROUND** button allows you to cycle through various surround sound modes. Use **SURROUND PARAMETER** to adjust specific settings within the selected mode.
- **iPod Controls:** If your receiver supports iPod connectivity, use the dedicated**PLAY/PAUSE**, **STOP**, **SKIP**, **REPEAT**, and **RANDOM** buttons for media playback.

5. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's range decreases or it stops responding. Always replace both batteries simultaneously.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote control and the receiver's infrared sensor.
  - Confirm that the remote is pointed directly at the receiver.
- **Limited range:**

- Replace the batteries.
- Ensure no strong light sources (e.g., direct sunlight, fluorescent lights) are interfering with the IR signal.

- **Certain buttons not working:**
  - Verify that the remote is compatible with your specific Denon receiver model.
  - Clean the remote's surface, especially around the non-working buttons, to remove any debris.

7. Specifications

Feature	Detail
Model Numbers	RC-1115, RC-1120, RC1120
Product Dimensions	2 x 0.6 x 7 inches
Item Weight	0.81 ounces
Batteries Required	2 x AAA batteries
Connectivity Technology	Infrared (IR)
Special Features	Ergonomic, No Programming Required
Max Number of Supported Devices	18 (referring to the number of functions/commands)
Compatible Devices	Denon Home Theater AV Receivers (AVR-2807, AVR-2808, AVR-2809, AVR-590, DHT590BA, AVR-1610)

8. Warranty and Support

Specific warranty information for this ALLIMITY replacement remote control is not provided in the product details. For any support inquiries or warranty claims, please refer to the seller or retailer from whom the product was purchased.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question