Camp4 70669

Camp4 Portable Gas Oven with Ignition Safety User Manual

Model: 70669

Introduction

This manual provides essential information for the safe and efficient operation of your Camp4 Portable Gas Oven with Ignition Safety, Model 70669. Designed for outdoor and camping use, this appliance combines a two-burner cooktop with a functional oven, offering versatility for various cooking needs. Please read this manual thoroughly before initial use and retain it for future reference.



An image showing the Camp4 portable gas oven, featuring two top burners and a lower oven compartment with a clear glass door and an internal thermometer. The unit is silver and black with a lid that opens to reveal the burners.

Setup

1. Unpacking and Inspection

- Carefully remove all packaging materials.
- Inspect the appliance for any signs of damage during transit. Do not use if damaged.
- Ensure all components are present: main unit, burner grates, oven rack.

2. Placement

- Place the oven on a stable, level, non-combustible surface.
- Ensure adequate ventilation. Do not use in enclosed spaces.
- Maintain a safe distance from walls, curtains, and other flammable materials (minimum 30 cm from sides and rear, 100 cm from top).

3. Gas Connection

- This appliance is designed for use with **LPG (Liquefied Petroleum Gas)**. Ensure your gas cylinder and regulator are compatible.
- Connect the gas hose to the appliance's gas inlet and to the regulator on the gas cylinder. Ensure all connections are tight.
- Use only approved gas hoses and regulators.
- **Leak Test:** Before first use and after every gas cylinder change, perform a leak test. Apply a soapy water solution to all gas connections. Bubbles indicate a leak. If a leak is detected, turn off the gas supply immediately, tighten connections, and re-test. Do not use the appliance if a leak persists.

4. Initial Burn-Off

- Before cooking, operate the burners and oven at maximum setting for approximately 15 minutes to burn off any manufacturing residues. This may produce a slight odor, which is normal. Ensure good ventilation during this process.

Operating Instructions

1. Igniting the Top Burners

1. Ensure the gas cylinder valve is open.
2. Push in and turn the desired burner control knob counter-clockwise to the "HIGH" position.
3. The integrated ignition safety system will automatically spark. Hold the knob in for a few seconds after ignition to allow the thermocouple to heat up and activate the flame failure device.
4. If the burner does not ignite, release the knob and repeat the process.
5. Once lit, adjust the flame by turning the knob between "HIGH" and "LOW" settings.
6. To turn off, turn the knob clockwise to the "OFF" position.

2. Using the Oven

1. Open the gas cylinder valve.
2. Push in and turn the oven control knob counter-clockwise to the desired temperature setting.
3. The oven burner will ignite automatically via the integrated ignition safety system. Hold the knob in for a few seconds after ignition to allow the thermocouple to heat up.
4. Monitor the internal oven thermometer to reach the desired temperature.
5. Place food inside the oven using the provided rack.

6. To turn off, turn the oven control knob clockwise to the "OFF" position.

3. Safety Precautions During Operation

- Always use the appliance in a well-ventilated area. Never use indoors or in tents.
- Do not leave the appliance unattended while in use.
- Keep children and pets away from the hot appliance.
- The appliance surfaces will become hot during use. Use oven mitts or gloves when handling.
- If you smell gas, immediately turn off the gas supply at the cylinder, extinguish all open flames, and ventilate the area. Do not operate the appliance until the source of the leak is found and rectified.
- Ensure the gas cylinder is upright and stable during use.
- Do not obstruct the ventilation openings of the appliance.

Maintenance

1. Cleaning

- Always ensure the appliance is cool and the gas supply is turned off before cleaning.
- **Exterior:** Wipe with a damp cloth and mild detergent. Do not use abrasive cleaners or scouring pads.
- **Burners and Grates:** Remove grates and burner caps. Clean with warm soapy water. Ensure they are completely dry before reassembling. Clear any clogged burner holes with a fine wire or needle.
- **Oven Interior:** Wipe down with a damp cloth and mild detergent. For stubborn stains, a non-abrasive oven cleaner designed for gas ovens can be used, following the product instructions.
- Do not immerse the appliance in water.

2. Storage

- Store the appliance in a dry, well-ventilated area, away from direct sunlight and extreme temperatures.
- Disconnect the gas cylinder and store it separately in a safe, well-ventilated location.

3. Regular Checks

- Periodically inspect the gas hose for cracks, cuts, or wear. Replace if damaged.
- Check all gas connections for tightness regularly.

Troubleshooting

Problem	Possible Cause	Solution
Burner/Oven does not ignite.	Gas cylinder empty or valve closed. Gas hose kinked or blocked. Ignition electrode dirty or damaged. Thermocouple not heating sufficiently.	Check gas supply and open valve. Straighten hose or clear blockage. Clean electrode or contact service. Hold knob in longer after ignition.

Problem	Possible Cause	Solution
Flame is weak or uneven.	Low gas pressure. Burner ports clogged. Incorrect gas type.	Check gas cylinder level. Clean burner ports. Ensure correct LPG supply.
Smell of gas.	Gas leak from connections or hose. Incomplete combustion.	Immediately turn off gas, ventilate, perform leak test. Do not use until fixed. Ensure adequate ventilation.
Oven not reaching desired temperature.	Oven door not fully closed. Low gas pressure. Incorrect temperature setting.	Ensure door is sealed. Check gas cylinder level. Adjust knob to higher setting.

If problems persist after attempting these solutions, contact a qualified service technician or the manufacturer's support.

Specifications

- **Brand:** Camp4
- **Model Number:** 70669
- **ASIN:** B07KFGVCKN
- **Material:** Stainless Steel, Aluminum
- **Power Source:** Gas Powered (LPG)
- **Ignition:** Integrated Ignition Safety System
- **Product Type:** Portable Gas Oven with 2-Burner Cooktop

Note: Specifications are subject to change without notice.

Warranty Information

Specific warranty details for the Camp4 Portable Gas Oven are not provided within this manual. For information regarding warranty coverage, terms, and conditions, please refer to the documentation included with your purchase or visit the official Camp4 website. Retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, spare parts, or service inquiries, please contact your retailer or the manufacturer directly. Contact information can typically be found on the product packaging, the manufacturer's official website, or your purchase receipt.

Online Resources: You may find additional support, FAQs, and product information on the Camp4 official website.

© 2023 Camp4. All rights reserved. This manual is for informational purposes only.