Griffin APPSPBT02

Griffin APPSPBT02 Portable Bluetooth Speaker User Manual

Model: APPSPBT02

Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Griffin APPSPBT02 Portable Bluetooth Speaker. Please read this manual carefully before using the device to ensure optimal performance and to prevent damage.

Product Overview

The Griffin APPSPBT02 is a portable Bluetooth speaker designed for wireless audio playback. It features Bluetooth 4.2 connectivity, a 6W speaker, and supports playback from USB drives and Micro SD cards. It also includes an FM radio function and a hands-free calling feature.



Figure 1: Griffin APPSPBT02 Portable Bluetooth Speaker. This image displays the black, oval-shaped speaker with a textured grille on the front. On the top surface, control buttons for mode, volume down/previous track, play/pause, volume up/next track, and power are visible. A black carrying strap is attached to the right side of the speaker.

Key Features:

- Bluetooth 4.2 for stable wireless connection.

- 6 Watts of audio output power.
- Supports audio playback from USB drives and Micro SD cards.
- Integrated FM radio function.
- Hands-free calling capability.
- Up to 3 hours of playback on a single charge.
- Compact and portable design with a carrying strap.

Setup

1. Initial Charging

Before first use, fully charge the speaker. Connect the provided USB charging cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will illuminate during charging and turn off once fully charged. A full charge typically takes approximately 2-3 hours.

2. Powering On/Off

- **To Power On:** Press and hold the **Power button** (often marked with a power symbol or 'M' for Mode, depending on the specific button layout) for a few seconds until you hear an audible prompt or see an indicator light.
- **To Power Off:** Press and hold the **Power button** again for a few seconds until the speaker powers down.

Operating Instructions

1. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode. If not, press the **Mode button** (often labeled 'M') to switch to Bluetooth mode. The speaker will indicate it is ready for pairing (e.g., a flashing LED or an audible prompt).
2. On your smartphone or tablet, enable Bluetooth and search for available devices.
3. Select "APPSPBT02" from the list of found devices.
4. Once paired, the speaker will provide an audible confirmation, and the LED indicator will typically stop flashing.
5. You can now play audio from your device through the speaker. The effective operating range is up to 10 meters.

2. USB/Micro SD Playback

1. Insert a USB drive or Micro SD card containing audio files into the respective port on the speaker.
2. The speaker should automatically switch to USB or Micro SD mode and begin playing audio. If not, press the **Mode button** ('M') to cycle through modes until you reach the desired playback source.
3. Use the **Play/Pause button** to control playback.
4. Use the **Volume Up/Next Track** (**+**) and **Volume Down/Previous Track** (**-**) buttons for track navigation (short press) and volume adjustment (long press).

3. FM Radio Function

1. Power on the speaker and press the **Mode button** ('M') to switch to FM radio mode.
2. To automatically scan and save available FM stations, press and hold the **Play/Pause button**. The speaker will scan and store stations.
3. Once scanning is complete, use the **Volume Up/Next Track** (**+**) and **-** (**Volume Down/Previous Track**) buttons to navigate between saved stations.

4. Hands-free Calling

1. When the speaker is paired with your smartphone via Bluetooth, incoming calls will be routed through the speaker.
2. To answer an incoming call, press the **Play/Pause button** once.

3. To end a call, press the **Play/Pause button** once again.
4. To reject an incoming call, press and hold the **Play/Pause button** for a few seconds.

Maintenance

- Keep the speaker away from water, moisture, and extreme temperatures.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid dropping the speaker or subjecting it to strong impacts.
- When not in use for extended periods, store the speaker in a cool, dry place and charge it periodically to maintain battery health.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in Bluetooth pairing mode. Turn on Bluetooth on your device. Move device closer to speaker (within 10m).
No sound during playback.	Volume too low; incorrect mode selected; audio source paused.	Increase speaker and device volume. Ensure correct mode (Bluetooth, USB, Micro SD) is selected. Check if audio is playing on the source device.
FM radio reception is poor.	Weak signal; environmental interference.	Relocate the speaker to an area with better reception. Ensure no large metal objects are nearby.

Specifications

- **Model:** APPSPBT02
- **Bluetooth Version:** 4.2
- **Operating Distance:** Up to 10 meters
- **Output Power:** 6 Watts
- **Speaker Frequency Response:** 100 Hz - 20 kHz
- **Playback Sources:** Bluetooth, USB, Micro SD, FM Radio
- **Battery:** 3.7V / 1200 mAh internal rechargeable battery
- **Playback Time:** Up to 3 hours (approximate, varies with volume and content)
- **Special Features:** Hands-free function, Portable
- **Compatible Devices:** Smartphones, Tablets
- **Dimensions (approximate):** 19.4 x 8.8 x 4.8 cm
- **Weight (approximate):** 381 grams

Warranty and Support

For warranty information and technical support, please refer to the documentation provided with your purchase or contact your

retailer. Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question