Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sceptre 142021270009C

Sceptre TV Remote Control U500-CV (Model 142021270009C) User Manual

For Compatible Models: U500CV-UMK, U550CV-U

Introduction

This manual provides comprehensive instructions for the Sceptre TV Remote Control, model 142021270009C. It covers essential information regarding setup, operation, maintenance, troubleshooting, and product specifications. This remote is specifically designed for seamless compatibility with Sceptre U500CV-UMK and U550CV-U series televisions.

Product Overview



Figure 1: Sceptre TV Remote Control (Model 142021270009C). This image displays the full layout of the remote control, featuring various buttons for power, channel, volume, navigation, and input selection, with the Sceptre logo prominently displayed at the bottom right.

Setup

1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the diagrams inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

2. Initial Use

This remote control is designed for immediate use with compatible Sceptre televisions (U500CV-UMK, U550CV-U) and does not require any programming. Once batteries are correctly installed, it should function directly with your TV.

Operating the Remote Control

The remote control features 25 buttons, each with specific functions. Below is a description of common buttons and their uses:

- **Power (Power)**: Turns the television on or off.
- **Source (Source)**: Selects the input source (e.g., HDMI, AV, Component).
- **Mute (Mute)**: Mutes or unmutes the TV audio.
- **Number Buttons (0-9)**: Directly enter channel numbers.
- **CC (Closed Caption)**: Toggles closed captions on or off.
- **MTS (Multi-channel Television Sound)**: Selects audio modes (e.g., Stereo, SAP).
- **Info (Info)**: Displays program information or current status.
- **Guide (Guide)**: Accesses the electronic program guide (if supported by the TV/broadcast).
- **Navigation Buttons (Up, Down, Left, Right, Enter)**: Used to navigate through menus and confirm selections.
- **Menu (Menu)**: Opens the TV's main settings menu.
- **Exit**: Exits the current menu or screen.
- **Aspect**: Changes the screen aspect ratio.
- **VOL +/-**: Adjusts the volume level.
- **CH +/-**: Changes the television channel.
- **Freeze**: Freezes the current image on screen.
- **Sleep**: Sets a sleep timer for the TV.
- **Fav +/-**: Navigates through favorite channels.
- **Add/Del**: Adds or deletes channels from the favorite list.
- **MHL**: Selects Mobile High-Definition Link input.
- **USB**: Selects USB input for media playback.
- **Picture**: Accesses picture settings.
- **Sound**: Accesses sound settings.
- **Media Playback Controls (Play/Pause, Fast Forward, Rewind, Stop)**: Used for controlling media playback from USB or other connected sources.
- **Mode**: Cycles through various display modes.
- **SoundBar**: Toggles soundbar control (if applicable and connected).
- **Color Buttons (A, B, C, D)**: These buttons (Red, Green, Yellow, Blue) have context-sensitive functions that vary depending on the TV menu or specific applications.

Maintenance

- **Cleaning**: Use a soft, dry cloth to gently clean the remote control. Avoid using liquid cleaners, solvents, or abrasive materials, as these can damage the remote's surface or internal components.
- **Battery Replacement**: Replace batteries when the remote's operational range decreases significantly or it becomes unresponsive. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries or different battery types.
- **Storage**: If the remote control will not be used for an extended period, it is recommended to remove the batteries to prevent potential leakage and damage to the device.

Troubleshooting

- **Remote not responding or intermittent response**:

- Ensure the batteries are inserted correctly with the positive (+) and negative (-) terminals aligned as indicated.
- Replace old batteries with a fresh pair of AAA alkaline batteries.
- Verify that there are no physical obstructions between the remote control and the TV's infrared sensor.
- Point the remote directly at the TV's infrared sensor, typically located on the front panel of the television.

- **Specific buttons not working**:
  - Clean the remote control, paying close attention to the unresponsive buttons, to remove any dirt, dust, or debris that might be interfering with their function.
  - If only certain buttons remain unresponsive after checking batteries and cleaning, the remote control may be faulty and require replacement.

Specifications

Feature	Detail
Brand	Sceptre
Model Number	142021270009C
Compatible Devices	Sceptre Televisions (U500CV-UMK, U550CV-U)
Connectivity Technology	Infrared
Number of Buttons	25
Battery Type	AAA Alkaline (2 required)
Special Feature	Ergonomic design
UPC	034722603874

Warranty and Support

Warranty Information

This Sceptre remote control comes with a 90-day limited warranty. Please retain your proof of purchase for any warranty claims.

Customer Support

For further assistance or troubleshooting not covered in this manual, please refer to your Sceptre television's user manual or contact Sceptre customer support directly. If this is a renewed product, you may also contact the seller for specific support related to your purchase.

© 2026 Sceptre. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07KHSMNYH

More documents and user manuals: **https://manuals.plus/**