Chefman RJ07-45-SS

Chefman 4.5 Liter Deep Fryer User Manual

Model: RJ07-45-SS | Brand: Chefman

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Chefman 4.5 Liter Deep Fryer. Please read all instructions carefully before first use and retain for future reference.

The Chefman Jumbo Deep Fryer is designed for home use, offering a large 4.5-liter capacity suitable for frying substantial portions of various foods, including French fries, doughnuts, fried chicken, homemade chips, and mozzarella sticks. It features adjustable temperature control, an integrated timer, and a viewing window for convenient and precise cooking.

Key features include:

- XL 4.5-liter capacity for large batches.
- Adjustable temperature control up to 375°F (190°C).
- Integrated timer for precise cooking.
- Splatter-proof viewing window on the lid.
- Removable oil container and dishwasher-safe frying basket for easy cleaning.
- Magnetic breakaway power cord for safety and convenient storage.
- Charcoal air filter to help reduce odors.



Image: The Chefman 4.5 Liter Deep Fryer, showcasing its stainless steel exterior and a basket filled with freshly fried French fries.

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for storage or shipping if needed.
2. **Component Identification:** Familiarize yourself with the parts: the main unit (stainless steel housing), removable oil container, heating element with control panel, frying basket, basket handle, and lid with viewing window and charcoal filter.
3. **Initial Cleaning:** Before first use, wash the removable oil container, frying basket, and lid in warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth. Ensure the heating element and control panel are never submerged in water.
4. **Assembly:**
    - Place the removable oil container securely into the main unit.
    - Insert the heating element with the control panel into the designated slot at the back of the main unit, ensuring it is firmly seated.
    - Attach the basket handle to the frying basket.
    - Place the frying basket into the oil container.

- Position the lid on top of the unit.

5. **Placement:** Place the deep fryer on a stable, heat-resistant, and dry surface, away from the edge of the countertop and out of reach of children. Ensure adequate ventilation around the unit.
6. **Power Connection:** Connect the magnetic breakaway power cord to the deep fryer's receptacle and then plug it into a standard 120V AC electrical outlet. Ensure the connection is secure.



Image: An exploded view illustrating the various components of the deep fryer, including the lid, removable basket handle, large fry basket, 4.5-quart oil container, and breakaway magnetic cord.

Operating Instructions

1. **Add Oil:** Pour cooking oil into the removable oil container. Ensure the oil level is between the MIN and MAX fill lines indicated inside the container. Do not overfill or underfill.

2. **Preheating:**
    - Set the desired temperature using the temperature control dial (e.g., 350°F for most frying).
    - The "Heating" indicator light will illuminate, indicating the fryer is heating the oil.
    - Once the oil reaches the set temperature, the "Heating" light will turn off. This indicates the fryer is ready for use.
3. **Prepare Food:** Ensure food items are dry before frying to prevent excessive splattering and to achieve crispier results. Do not overload the frying basket.
4. **Frying:**
    - Carefully lower the frying basket containing the food into the hot oil.
    - Place the lid on the fryer. The viewing window allows you to monitor the cooking process without opening the lid, reducing splatters and heat loss.
    - Set the desired cooking time using the timer dial. The timer will automatically turn off the heating element when the time expires.
    - For best results, follow recommended cooking times and temperatures for specific food types.
5. **Draining:** Once cooking is complete, carefully lift the frying basket and hook it onto the basket clip on the side of the fryer. This allows excess oil to drain back into the container.
6. **Serving:** Carefully remove the food from the basket and place it on a paper towel-lined plate to absorb any remaining oil before serving.
7. **Turning Off:** After use, turn both the temperature and timer dials to the "OFF" position. Unplug the unit from the wall outlet and allow it to cool completely before cleaning or storing.

Perfectly Done Dishes

Adjustable temperature dials and an integrated timer makes deep frying easy for anyone



Image: A detailed view of the control panel, highlighting the adjustable temperature and integrated timer dials for precise frying.



Image: A top-down perspective of the deep fryer, emphasizing its XL 4.5-quart capacity, ideal for frying large quantities of food.

Maintenance and Cleaning

Proper maintenance and cleaning will extend the life of your deep fryer and ensure optimal performance.

1. **Cool Down:** Always allow the deep fryer and oil to cool completely before attempting to clean. This can take several hours.
2. **Oil Disposal/Storage:** Once cooled, carefully remove the oil container. You can filter and store the oil for future use in an airtight container, or dispose of it properly according to local regulations.
3. **Cleaning Removable Parts:** The removable oil container, frying basket, and lid are dishwasher-safe for convenient cleaning. Alternatively, wash them in warm, soapy water, rinse thoroughly, and dry completely.
4. **Cleaning Heating Element & Control Panel:** Wipe the heating element and control panel with a damp cloth. Do

NOT immerse the heating element or control panel in water or any other liquid. Ensure no water enters the electrical components.

5. **Exterior Cleaning:** Wipe the exterior stainless steel housing with a damp cloth and dry thoroughly. Do not use abrasive cleaners or scouring pads, as they may damage the finish.
6. **Charcoal Air Filter:** The charcoal air filter in the lid helps reduce odors. Replace the filter periodically as needed (replacement filters sold separately).
7. **Magnetic Breakaway Cord:** The magnetic cord is designed for easy detachment, aiding in both safety and simplified cleanup and storage.



Image: The deep fryer demonstrating its easy-drain feature, where the basket clips to the side, allowing excess oil to drip back into the container.

Troubleshooting

If you encounter issues with your Chefman Deep Fryer, please consult the following common problems and solutions:

Problem	Possible Cause	Solution
Fryer does not turn on.	Not plugged in securely; power outlet issue; magnetic cord not properly connected.	Ensure the power cord is fully inserted into both the fryer and the wall outlet. Check if the outlet is functional by plugging in another appliance. Verify the magnetic cord connection is secure.
Oil not heating up.	Temperature dial not set; heating element not properly seated; unit not powered on.	Ensure the temperature dial is set to a desired temperature. Confirm the heating element is correctly installed and the unit is plugged in and powered on.
Food is not crispy.	Oil temperature too low; basket overloaded; food not dry enough.	Allow oil to reach the set temperature before adding food. Do not overload the basket; fry in smaller batches. Ensure food is patted dry before frying.
Excessive splattering.	Food contains too much moisture; oil level too high.	Pat food dry thoroughly before frying. Ensure oil level is within MIN/MAX lines.
Lid does not attach securely.	Design feature (lid is designed to be loose, not hinged).	The lid is designed to rest on top of the fryer and is not hinged or attached to the base. This allows for easy removal and cleaning.

Specifications

Model Name: XL Deep Fryer w/Basket Strainer

Brand: Chefman

Material: Stainless Steel

Color: Stainless Steel

Product Dimensions: 12"D x 6.25"W x 11.25"H

Item Weight: 7.13 Pounds

Wattage: 1700 watts

Oil Capacity: 4.5 Liters

Item Model Number: RJ07-45-SS

UPC: 816458023337

Manufacturer: Chefman

Date First Available: November 14, 2018

Warranty and Support

Your Chefman 4.5 Liter Deep Fryer is backed by a**1-year assurance** provided by Chefman. This warranty covers defects in material and workmanship under normal use and conditions.

For detailed warranty information, product registration, or technical support, please refer to the official Chefman website or contact their customer service. You can also find a comprehensive User Guide in PDF format for this product here.

Please retain your proof of purchase for warranty claims.

© 2023 Chefman. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question