ALLIMITY RCA4995RC, RCA4995, RC4995, RC-4995

ALLIMITY Replacement Remote Control User Manual

Model: RCA4995RC, RCA4995, RC4995, RC-4995

Introduction

This user manual provides comprehensive instructions for the ALLIMITY Replacement Remote Control. Designed as a direct replacement for various Gogen, Edenwood, Telefunken, Continental Edison, DIGIQUEST, QILIVE, and Haier TV models, this remote offers seamless functionality without the need for complex programming. Please read this manual carefully to ensure proper use and longevity of your remote control.

Product Overview

The ALLIMITY Replacement Remote Control is an ergonomic, infrared-based device designed to replicate the functions of your original TV remote. It features a standard layout with dedicated buttons for common functions, including a Netflix button for quick access to streaming services.



Figure 1: Front view of the ALLIMITY Replacement Remote Control, showing all buttons including the Netflix button at the top.



Figure 2: Angled view of the remote control, highlighting its ergonomic design.



Figure 3: A different angled view, showing the slim profile of the remote.

Compatible Devices

This remote control is compatible with a wide range of TV models from various brands. Below is a list of some compatible models:

- **Edenwood:** ED2400HD, ED3905HD, ED5502UHD, ED3204HD, ED4301UHD/2, ED3205HD, ED5500UHD, ED3904HD, ED5501UHD, ED6501UHD, ED4803FHD, ED65021UHD, ED43FHD, G919E4AB1WT453393, ED4304FHD, ED4300UHD, ED6500UHD, ED6502UHD, ED4903FHD, ED3206HDWH.
- **Telefunken:** H49N03CW16, TE43SMB35Z2K, TFA55297WUHD18R, TFLS24WF17B, TE32269B38Y2H, TE32287B35T2D, TE32SMS27T2D, TE50292S26Y26Y2 P, TE43472S29Y2K, TE49269S31Y2P, H65N03CW16-2, TE39SMB35Z2H, TE48282S29Y2K, TE49292S26Y2P, TE28275B40Y2A, TE482S25Z2K, SMB35Z2D, TFK55D297UHWB18, TFL43UHD17BC, TE40292S31Y2P, TFLS32HD28B17, TE32269B38Y2D, TE39472B38Y2D, TE49UHS24Z2P.
- **Continental Edison:** CELED39S0117B3, CELED55PREMB3, CELED49S0116B3, CELED48S0117B3, CELED65PREMB3, CELED49K0317B3, CELED32S0817B3, CELED43K0817B3, CELED4340S04.B3, CELED49PREMB3, CELED43PREM2B3.

- **DIGIQUEST:** DDGE32NETFLIX/EDGE-DVBT2/S2, DGE39NETFLIX-FHD-DVBT2/S2, DGE55NETFLIX/EDGE-UHD-DVBT2/S2.
- **QILIVE:** 10107931 (Q.43-371), 10107932 (Q.49-371).
- **Haier:** LDH32V180S.
- **Other:** Onwa ONWALED48FHSTV17SMART, XD-ENJOY XD43SF3VSAT.



Figure 4: The ALLIMITY remote control shown in a typical usage scenario with a television.

Setup

The ALLIMITY Replacement Remote Control is designed for immediate use with compatible TV models. No complex programming or code entry is required.

Inserting Batteries

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert two AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery cover securely.

Once batteries are inserted, the remote control is ready to operate your compatible television.

Operating Instructions

The remote control functions are intuitive and mirror those of your original TV remote. Point the remote directly at your television's infrared receiver for optimal performance.

Key Functions

Button	Function
Power ( )	Turns the television On or Off.
Netflix	Direct access to the Netflix application.
Number Buttons (0-9)	Direct channel selection.
TV / Source	Switches between input sources (HDMI, AV, etc.).
BACK	Returns to the previous screen or menu.
MENU	Opens the main menu of the television.
Navigation (Up, Down, Left, Right, OK)	Navigates through menus and confirms selections.
Volume (+/-)	Adjusts the volume level.
Channel (P+/-)	Changes the television channel.
Mute ( )	Mutes or unmutes the television audio.
Info (*i*)	Displays information about the current program or input.
EXIT	Exits the current menu or application.
EPG	Accesses the Electronic Program Guide.
TXT	Opens Teletext.
Colored Buttons (Red, Green, Yellow, Blue)	Context-sensitive functions within menus or applications.
Media Playback Controls (Rewind, Play/Pause, Fast Forward, Stop)	Controls media playback for compatible devices or content.
LANG.	Changes audio language or track.
SUBT.	Toggles subtitles On or Off.

Maintenance

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA alkaline).
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote, expose it to extreme temperatures, direct sunlight, or moisture. Keep it away from strong magnetic fields.

Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

Problem	Possible Cause / Solution
Remote is not working.	◦ Check if batteries are inserted correctly with correct polarity (+/-). ◦ Replace old or dead batteries with new AAA alkaline batteries. ◦ Ensure there are no obstructions between the remote and the TV's infrared sensor. ◦ Make sure you are within the effective range (up to 10 meters) and pointing directly at the TV.
Some buttons are not responding.	◦ This remote is a replacement and may not support all advanced functions of certain smart TVs or specific brand features not present on the original remote it replaces. ◦ Ensure the button is clean and not stuck. ◦ Try replacing batteries.
Remote works intermittently.	◦ Batteries may be low. Replace them. ◦ Ensure consistent line of sight to the TV. ◦ Check for strong light sources (e.g., direct sunlight, fluorescent lights) that might interfere with the IR signal.

Specifications

Feature	Detail

Feature	Detail
Brand	ALLIMITY
Model Numbers	RCA4995RC, RCA4995, RC4995, RC-4995
Connectivity Technology	Infrared
Special Features	Ergonomic design
Compatible Devices	Gogen, Edenwood, Telefunken, Continental Edison, DIGIQUEST, QILIVE, Haier TVs (specific models listed in Product Overview)
Number of Buttons	20
Controller Type	Button Control
Maximum Range	10 Meters
Battery Description	AAA Alkaline (2 required)
UPC	768111031930

Warranty and Support

For warranty information or technical support, please refer to the retailer or the manufacturer's official website. Keep your purchase receipt as proof of purchase.
This product is designed for reliable performance. If you encounter any issues not covered in the troubleshooting section, please contact customer service for assistance.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question