Porseme F1-500ml Giant

Porseme 500ml Essential Oil Diffuser Instruction Manual

Model: F1-500ml Giant

Brand: Porseme

1. Introduction

Thank you for purchasing the Porseme 500ml Essential Oil Diffuser. This ultrasonic humidifier is designed to disperse essential oils and provide a soothing mist, enhancing the atmosphere of your home, office, or yoga space. Featuring a unique 3D glass design and user-friendly controls, this manual provides detailed instructions for safe and effective operation, maintenance, and troubleshooting.

2. Safety Information

Please read all safety instructions carefully before using the diffuser to prevent injury or damage to the product.

- Ensure the base is upright and not inverted when wet.
- Fill water below the 'Max' line to avoid mist issues and potential leaks.
- Securely attach the lid to prevent water leakage during operation.
- Regularly clean the atomizer with a soft cloth to maintain optimal performance.
- Empty and dry the water tank when the diffuser is not in use for extended periods.
- Always follow proper essential oil usage guidelines; do not use corrosive or unknown liquids.
- Keep the diffuser out of reach of children and pets.
- Do not place the diffuser on unstable surfaces or near heat sources.
- Unplug the diffuser from the power outlet before cleaning or refilling.

3. Package Contents

Verify that all items are present in the package:

- Porseme 500ml Essential Oil Diffuser (Base and Glass Cover)
- DC Power Adapter
- Instruction Manual

4. Product Overview



Figure 4.1: Porseme 500ml Essential Oil Diffuser. This image displays the diffuser's overall appearance, highlighting its unique 3D glass cover and wood grain base.



Figure 4.2: Diffuser Features and Dimensions. This image illustrates the diffuser's capacity, mist settings, lighting options, and physical dimensions (5.9 inches height, 7.2 inches diameter).

The Porseme 500ml Essential Oil Diffuser consists of a durable wood-grain patterned base and a hand-blown 3D glass cover. The base houses the water reservoir, ultrasonic atomizer, and control buttons. The glass cover fits securely over the base, allowing the mist and LED lights to create a captivating visual effect.

Components:

- **Glass Cover:** Hand-blown with a 3D firework effect, providing ambient lighting.
- **Base:** Contains the water tank, ultrasonic plate, and control panel.
- **Mist Button:** Controls mist output and timer settings.
- **Light Button:** Controls LED light colors and modes.
- **Water Tank:** 500ml capacity for water and essential oils.
- **Air Outlet:** Where the mist is released.
- **DC Power Jack:** For connecting the power adapter.

5. Setup

1. Place the diffuser on a flat, stable surface away from direct sunlight or heat sources.
2. Remove the glass cover from the base.
3. Connect the DC power adapter to the power jack on the bottom of the diffuser base. Do not plug into a wall outlet yet.
4. Fill the water tank with clean tap water up to the 'Max' fill line (500ml capacity). Do not overfill.
5. Add 3-5 drops of your preferred essential oil directly into the water tank. Adjust the amount based on desired scent intensity.
6. Replace the glass cover securely onto the base, ensuring it is properly aligned.
7. Plug the power adapter into a standard electrical outlet.

6. Operating Instructions

Mist Control:

The mist button controls the mist output and timer settings.

- Press the **Mist** button once for continuous mist mode (approximately 15 hours run time).
- Press the **Mist** button a second time for interval mist mode (mist for 30 seconds, then pause for 30 seconds; approximately 21 hours run time).
- Press the **Mist** button a third time to turn off the mist function.

Light Control:

The light button controls the LED illumination.



Figure 6.1: LED Light Modes. This image displays the diffuser cycling through its 7 different LED light colors, demonstrating the visual effects.

- Press the **Light** button once to turn on the LED lights. The colors will cycle automatically through 7 soothing colors.
- Press the **Light** button again to fix the light to a specific color. Continue pressing to cycle through the available colors.
- Press and hold the **Light** button for 2 seconds to turn off the LED lights.

Automatic Shut-Off:

The diffuser is equipped with a waterless auto-off safety feature. When the water level in the tank is too low or runs out, the diffuser will automatically shut off to prevent overheating and ensure safety.

7. Maintenance

Regular cleaning is essential for optimal performance and longevity of your diffuser.

Cleaning the Diffuser:

1. Unplug the diffuser from the power outlet and remove the glass cover.
2. Carefully pour out any remaining water from the water tank, avoiding the air outlet side.
3. Wipe the inside of the water tank with a soft, clean cloth.
4. For stubborn residue, add a small amount of white vinegar to the water tank and let it sit for 10-15 minutes. Then, gently wipe clean with a soft cloth.
5. Gently clean the ultrasonic atomizer plate (the small disc in the center of the tank) with a cotton swab dipped in rubbing alcohol or white vinegar. Do not scratch the plate.
6. Rinse the tank with clean water, ensuring no residue remains.
7. Dry all parts thoroughly before reassembling or storing.

Note: Do not immerse the diffuser base in water. Do not use harsh detergents, abrasive cleaners, or corrosive chemicals.

8. Troubleshooting

If you encounter issues with your diffuser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No mist or low mist output	Insufficient water; water level too high; ultrasonic plate dirty; air outlet blocked; diffuser not level.	Add water (below MAX line); remove excess water; clean ultrasonic plate; ensure air outlet is clear; place on a flat surface.
No light or flickering light	Light function off; loose connection; malfunction.	Press Light button to activate; check power connection; contact customer support if issue persists.
Water leakage	Lid not securely attached; overfilling water; diffuser tilted.	Ensure lid is properly sealed; do not exceed MAX fill line; keep diffuser upright.
Diffuser automatically shuts off prematurely	Water level too low; waterless auto-off activated.	Refill water tank. This is a safety feature.

9. Specifications

Feature	Detail
Model Name	F1-500ml Giant
Capacity	500 Milliliters
Product Dimensions	7"L x 7"W x 6"H
Item Weight	1.81 Pounds
Power Source	Corded Electric
Wattage	12 watts
Coverage Area	500-1000 Square Feet

Feature	Detail
Special Feature	Automatic Shut-Off, Cool Mist
Light Source Type	LED (7 colors)
Material	Hand-blown 3D Glass, BPA Free

10. Warranty and Support

Warranty Information:

The Porseme 500ml Essential Oil Diffuser comes with a manufacturer's warranty for 12 months from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

Customer Support:

For any questions, technical assistance, or warranty claims, please contact Porseme customer support. Refer to the contact information provided on the product packaging or the official Porseme website. Please have your model number (F1-500ml Giant) and purchase date ready when contacting support.

© 2024 Porseme. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question