Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BCXY CS-H110SL

Replacement Battery User Manual

Model: CS-H110SL | Brand: BCXY

1. Introduction

This manual provides essential information for the safe and effective use of your BCXY replacement battery, model CS-H110SL. This high-quality Li-Polymer battery is designed to provide reliable power for compatible IRIVER MP3 players. Please read this manual thoroughly before installation and use to ensure optimal performance and safety.

2. Compatible Models

This replacement battery is compatible with the following IRIVER MP3 player models and battery part numbers:

- IRIVER H110
- IRIVER H120
- IRIVER H140
- IRIVER H320
- IRIVER H340 MP3 Player

Compatible Battery Part Number: IRIVER DA2WB18D2

3. Important Safety Information

Failure to follow these safety instructions may result in fire, electric shock, injury, or damage to the battery or device. Keep these instructions in a safe place for future reference.

- **CAUTION:** WARRANTY VOID IF LABEL IS REMOVED.
- DO NOT ATTEMPT TO DISASSEMBLE, OPEN, OR SERVICE THE BATTERY PACK.
- REPLACE ONLY WITH THE BATTERY PACK DESIGNATED FOR THIS PRODUCT.
- DO NOT CRUSH, PUNCTURE, OR SHORT EXTERNAL CONTACTS.
- DO NOT DISPOSE OF IN FIRE OR WATER.
- DO NOT STORE ABOVE 60°C (140°F).
- **ATTENTION:** NEW BATTERY PACK MUST BE FULLY CHARGED BEFORE USE.
- TO REDUCE RISK OF FIRE OR BURNS, READ INSTRUCTIONS IN OPERATING GUIDE BEFORE USING THE BATTERY.

- Limited Charge Voltage: 4.2V±0.05V.

This product is RoHS approved for toxic-free materials and holds CE and ISO9001 Certificates for quality assurance.

4. Setup and Installation

Battery replacement in MP3 players often requires technical expertise and specialized tools. It is highly recommended that installation be performed by a qualified technician to avoid damage to the device or the battery.

1. **Preparation:** Ensure the MP3 player is powered off and disconnected from all power sources. Gather necessary tools (e.g., small screwdrivers, prying tools).
2. **Access Battery Compartment:** Carefully open the MP3 player casing to access the existing battery. Refer to your specific MP3 player's service manual for detailed instructions on opening the device.
3. **Disconnect Old Battery:** Gently disconnect the old battery from the device's mainboard. Note the orientation of the connector.
4. **Install New Battery:** Connect the new BCXY replacement battery, ensuring the connector is properly aligned and secured. Place the battery into its designated compartment.
5. **Secure Casing:** Carefully reassemble the MP3 player casing, ensuring all clips and screws are properly secured.



Image 1: Top view of the BCXY replacement battery, displaying its specifications and safety warnings.

5. Operating Instructions

After successful installation, the new battery requires initial conditioning for optimal performance.

- **Initial Charge:** As per safety instructions, the new battery pack must be fully charged before its first use. Connect your MP3 player to its original charger and allow it to charge completely. This may take several hours.
- **First Cycles:** For the first 3-5 charge cycles, allow the battery to fully discharge before recharging it completely. This helps calibrate the battery's charge indicator and optimize its lifespan.
- **Regular Use:** Once conditioned, you can charge the battery as needed. Avoid frequently draining the battery to 0% to prolong its overall life.



Image 2: Angled view of the BCXY replacement battery, highlighting the connector wires for installation.

6. Maintenance and Storage

Proper maintenance and storage can significantly extend the life of your battery.

- **Temperature:** Store the battery in a cool, dry place, away from direct sunlight and extreme temperatures. Do not store above 60°C (140°F).
- **Charge Level for Storage:** If storing the battery for an extended period, ensure it is charged to approximately 50-60% capacity. Avoid storing a fully charged or completely depleted battery.
- **Regular Check:** If stored for a long time, periodically check the battery's charge level and recharge it to 50-60% every few months.
- **Cleaning:** Keep the battery and its contacts clean and free from dust or debris. Use a dry, soft cloth for cleaning.



Image 3: Bottom view of the BCXY replacement battery, displaying manufacturing details.

7. Troubleshooting

If you encounter issues with your new battery, consider the following common solutions:

- **Battery Not Charging:**
  - Ensure the charger and charging cable are functioning correctly.
  - Verify that the battery connector is securely seated in the MP3 player.

- Confirm the MP3 player's charging port is clean and undamaged.

- **Short Battery Life:**
  - Ensure the battery has completed 3-5 full charge/discharge cycles for calibration.
  - Check for excessive background processes or high screen brightness on the MP3 player that might drain the battery faster.
  - Verify that the battery is not exposed to extreme temperatures during use.

- **Device Not Powering On:**
  - Ensure the battery is fully charged.
  - Confirm the battery is correctly installed and connected.
  - If the issue persists, the problem might be with the MP3 player itself, not the battery.

If troubleshooting steps do not resolve the issue, please refer to the Customer Support section.

8. Product Specifications

Feature	Detail
Model Number	CS-H110SL
Battery Type	Li-Polymer
Capacity	1700mAh
Voltage	3.7V
Dimensions (L x W x H)	87.44 x 49.91 x 3.52mm (3.44 x 1.96 x 0.14 inches)
Weight	2.47 ounces
Certifications	ISO9001, RoHS, CE



Image 4: Angled bottom view of the BCXY replacement battery, illustrating its compact design.

9. Warranty Information

The manufacturer provides a warranty for this product. Please note that the**WARRANTY IS VOID IF THE LABEL IS REMOVED** from the battery pack. For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact the seller/manufacturer directly.

10. Customer Support

If you have any questions, require technical assistance, or experience issues not covered in this manual, please contact the seller or manufacturer of the BCXY replacement battery. Provide your product model number (CS-H110SL) and details of your inquiry for prompt assistance.

For general inquiries, you may visit the BCXY Store on Amazon:BCXY Amazon Store

© 2025 BCXY. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07KSBW8BD

More documents and user manuals: **https://manuals.plus/**