UMAY A512

UMAY 512 Walking Pad Instruction Manual

Model: A512 | Brand: UMAY

1. Introduction

Thank you for choosing the UMAY 512 Walking Pad. This ultra-quiet under-desk treadmill is designed to help you integrate physical activity into your daily routine, whether at home or in the office. This manual provides essential information for safe and effective use, including setup, operation, maintenance, and troubleshooting. Please read this manual thoroughly before operating the device and retain it for future reference.

2. Product Overview

The UMAY 512 Walking Pad is a compact and portable fitness device featuring a brushless motor for quiet operation and a shock absorption system for user comfort. It is designed for walking and light jogging, offering various speed levels and monitoring programs to track your progress.

Key Features:

- **Space-Saving Design:** Lightweight and foldable for easy storage under desks or beds.
- **Adjustable Speed:** Speed levels from 0.6 to 4 MPH to suit various fitness levels.
- **Ultra-Quiet Operation:** Brushless motor ensures minimal noise, ideal for shared spaces.
- **Shock Absorption:** Designed to reduce impact on knees and ankles during use.
- **Remote and App Control:** Convenient control via a remote or the SPAX App.
- **LED Display:** Tracks time, distance, speed, and calories burned.



Figure 2.1: UMAY 512 Walking Pad in operation. This image shows the compact design and the LED display.

3. Setup

3.1 Unpacking and Placement

The UMAY 512 Walking Pad requires no assembly. Carefully remove the unit from its packaging. Place the walking pad on a flat, stable surface. Ensure there is adequate space around the device for safe operation. Its compact design allows it to be placed under a desk, bed, or work table.

3.2 Moving the Device

The walking pad is equipped with two folding wheels for easy portability. To move, gently lift one end of the unit until it rests on the wheels, then roll it to your desired location.



Figure 3.1: The UMAY 512 Walking Pad demonstrating its space-saving storage options, including under a sofa and upright against a wall, highlighting its portability with wheels.

3.3 Power Connection

Connect the power cord to the walking pad and then to a standard electrical outlet. Ensure the power switch located at the rear of the unit is in the 'ON' position.

4. Operating Instructions

4.1 Remote Control Operation

The UMAY 512 Walking Pad is primarily controlled via the included remote. Ensure the remote has a working CR2032 Lithium Battery (included).

- **Power On:** Press the 'ON' button on the remote. The LED display will show a countdown before the belt starts moving at the lowest speed.
- **Adjust Speed:** Use the '+' button to increase speed and the '-' button to decrease speed. The maximum speed is 4 MPH.
- **Change Display Mode:** Press the 'MODE' button to cycle through different display metrics: Speed, Time, Distance, and Calories.
- **Power Off:** Press the 'OFF' button on the remote. The belt will gradually slow down and stop, and the display will show 'REST'.




Figure 4.1: The remote control for the UMAY 512 Walking Pad, with buttons for speed adjustment, mode selection, and power. The LED display shows various workout metrics.

4.2 SPAX App Control

For enhanced functionality, connect your walking pad to the SPAX App via Bluetooth. The app offers additional features such as class videos, professional coaching, and data recording. Follow the in-app instructions for pairing and usage.

- **Download App:** Search for 'SPAX App' on your mobile device's app store.
- **Bluetooth Connection:** Turn on Bluetooth on your device, go to the profile section in the app, and click

'Equipment'.

- **Add Treadmill:** Click 'Add New Tread' and then 'Searching for Tread'.
- **Start Workout:** Once connected, go to the 'Just Run' section to begin your workout.



Figure 4.2: A visual guide to connecting the UMAY 512 Walking Pad to the SPAX App, detailing the steps from enabling Bluetooth to starting a 'Just Run' session.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your UMAY 512 Walking Pad.

5.1 Lubrication

The walking belt requires periodic lubrication to reduce friction and wear. Use the provided lubricant (or a compatible treadmill lubricant) as instructed in the included manual. Typically, this involves applying lubricant under the walking belt every few months, depending on usage frequency.

5.2 Belt Adjustment

If the walking belt becomes misaligned or feels loose/tight, it may require adjustment. Refer to the detailed instructions in the included user manual for proper belt centering and tension adjustment using the provided tools.

5.3 Cleaning

Wipe down the walking pad with a damp cloth after each use to remove sweat and dust. Avoid using abrasive cleaners or solvents that could damage the surface. Keep the area around the motor clean and free of debris.




Figure 5.1: An internal view of the UMAY 512 Walking Pad, highlighting its brushless motor and cooling system, which contribute to its quiet operation and durability.

6. Troubleshooting

If you encounter any issues with your UMAY 512 Walking Pad, please refer to the following common solutions:

- **Device Not Powering On:** Ensure the power cord is securely plugged into both the unit and the wall outlet. Check that the main power switch at the rear of the walking pad is in the 'ON' position. Verify the remote control battery is functional.
- **Belt Not Moving:** After powering on, ensure you press the 'ON' button on the remote to initiate the countdown and start the belt. If the belt is slipping, it may require tension adjustment (refer to Section 5.2).
- **Unusual Noises:** A squeaking or sputtering noise may indicate a need for lubrication (refer to Section 5.1) or belt adjustment. If the noise persists, discontinue use and contact customer support.
- **Error Codes:** If an error code appears on the LED display (e.g., 'E01'), consult the comprehensive troubleshooting section in the included user manual for specific solutions related to the code.
- **Remote Control Unresponsive:** Replace the CR2032 battery in the remote control. Ensure there are no obstructions between the remote and the walking pad's sensor.

For issues not covered here, please consult the full user manual or contact UMAY customer support.

7. Specifications

Specification	Detail
Brand	UMAY
Model Name	A512
Product Dimensions (LxWxH)	53.7"D x 24"W x 5.9"H
Item Weight	55 Pounds
Material	Alloy Steel, Acrylonitrile Butadiene Styrene (ABS)
Maximum Speed	4 Miles per Hour
Minimum Speed	0.6 Miles per Hour
Maximum Weight Recommendation	265 Pounds
Deck Length	41 Inches
Deck Width	16 Inches
Motor Horsepower	2.5 Horsepower (Max), 1.5 Horsepower (Input)
Display Type	LED
Control Program Name	SPAX App
Included Components	Lubricant, Tools, User Manual
Special Features	Compact Design, Portable, Shock Absorbent, Timer, Wheeled

8. Safety Information

To ensure safe operation and prevent injury, please adhere to the following safety guidelines:

- Always read the entire user manual before first use.
- Place the walking pad on a level, stable surface.
- Ensure adequate clear space around the device during operation.
- Do not exceed the maximum user weight of 265 pounds.
- Wear appropriate athletic footwear. Avoid using the device barefoot or in socks.
- Keep children and pets away from the walking pad during operation.
- Do not use the device if it is damaged or malfunctioning.
- Unplug the walking pad from the power outlet when not in use or before cleaning/maintenance.
- The device is intended for residential use only.

9. Warranty and Support

The UMAY 512 Walking Pad comes with a 1-year manufacturer's warranty. For warranty claims, technical support, or any questions regarding your product, please refer to the contact information provided in your included user manual. Ensure you retain your proof of purchase for warranty validation.

© 2023 UMAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question