Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro H39N2110S

Passion-Electro Replacement Remote Control for HISENSE H39N2110S TV - User Manual

Introduction

This manual provides essential information for the proper use and maintenance of your Passion-Electro replacement remote control, specifically designed for the HISENSE H39N2110S television model. This remote offers full functionality comparable to the original remote control without requiring any programming.

Setup

Battery Installation

The remote control requires two 1.5V AAA (LR03) batteries. These batteries are not included with the product.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Rear view of the Passion-Electro remote control, highlighting the battery compartment cover.

First Use

Once the batteries are correctly installed, the remote control is ready for immediate use. No programming or setup is required. Simply point the remote control towards your HISENSE H39N2110S TV and begin operating it.

Operating Instructions

This replacement remote control is designed to replicate the full functionality of your original HISENSE H39N2110S TV remote. The button layout is intuitive and similar to standard television remote controls.



Image: Angled top view of the Passion-Electro remote control, displaying the full array of buttons including power, channel, volume, navigation, and colored function keys.

Common Functions

- **Power Button:** Turns the television on or off.
- **Channel Up/Down:** Changes the television channel.
- **Volume Up/Down:** Adjusts the sound volume.
- **Mute Button:** Silences the television audio.
- **Number Buttons (0-9):** Directly selects channels.
- **Menu/Settings:** Accesses the television's main menu or settings.
- **Navigation Buttons (Up, Down, Left, Right) and OK:**Used to navigate through menus and confirm selections.
- **Source/Input:** Switches between different input sources (HDMI, AV, etc.).
- **Colored Function Buttons:** (Red, Green, Yellow, Blue) These buttons typically correspond to specific functions within certain TV menus or applications. Refer to your TV's manual for their exact usage.

For specific functions related to your HISENSE H39N2110S TV, please consult your television's original user manual.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Exposure:** Do not expose the remote control to direct sunlight, extreme temperatures, high humidity, or water.

Troubleshooting

Problem	Possible Cause	Solution
Remote control not responding.	• Dead or incorrectly inserted batteries. • Obstruction between remote and TV. • Remote control sensor on TV is blocked. • Remote control is too far from the TV.	• Replace batteries with new ones, ensuring correct polarity. • Remove any objects blocking the line of sight between the remote and the TV. • Ensure the TV's infrared sensor is not covered. • Move closer to the TV.
Buttons are not working correctly.	• Low battery power. • Dirt or debris under buttons.	• Replace batteries. • Gently clean the remote surface and around buttons with a soft, dry cloth.

Specifications

Brand	Passion-Electro
Compatible Devices	HISENSE H39N2110S Television
Connectivity Technology	Infrared
Special Features	No programming required
Controller Type	Button Control
Color	Black
Battery Type	2 x AAA (LR03) (not included)
Manufacturer	Passion-Electro
Country of Origin	China

Warranty and Support

Specific warranty information for this product is not provided in the available details. For any questions regarding warranty, technical support, or product assistance, please contact the seller directly through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07KVN4Z4W

More documents and user manuals: **https://manuals.plus/**