Disney Princess 210381-SOC

Disney Princess Style Collection Gourmet Smart Kitchen Instruction Manual

Model: 210381-SOC

1. Introduction and Overview

The Disney Princess Style Collection Gourmet Smart Kitchen is an interactive play kitchen designed to enhance imaginative play. This kitchen features seven interactive appliances with lights, sounds, and phrases, providing a realistic cooking experience for young users. It comes with over 20 accessories to get started with culinary adventures.



Image: The Disney Princess Style Collection Gourmet Smart Kitchen, showcasing its various components including the refrigerator, stove, microwave, oven, sink, and dishwasher.

2. Safety Information

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

- Adult assembly is required.
- Keep small parts away from young children during assembly.
- Ensure all components are securely fastened before play.
- Do not immerse electronic parts in water. Wipe clean only.

3. Package Contents

The Gourmet Smart Kitchen includes the following items:

- 1 x Kitchen Unit (requires assembly)

- 1 x Pot
- 1 x Flipping Fry Pan
- 2 x Spoons
- 2 x Forks
- 2 x Knives
- 2 x Plates
- 1 x Cup
- 2 x Ice Cubes
- 1 x Fried Egg
- 1 x Bacon Strip
- 1 x Pancake
- 1 x Hard Boiled Egg
- 1 x Spatula
- 1 x Serving Spoon
- 1 x Cake Pan
- 1 x Dish Rack
- 1 x Carton of Almond Milk (play item)



Image: A collection of the 20+ play accessories included with the kitchen, such as utensils, plates, food items, and cookware.

4. Setup and Assembly

Adult assembly is required for this product. Please follow the detailed instructions provided in the separate assembly guide included in the packaging. Ensure all parts are accounted for before beginning assembly.

- **Battery Installation:** The kitchen requires 3 AA batteries (not included) for its interactive features. Locate

the battery compartment, typically on the back or underside of the main unit, and insert the batteries according to the polarity indicators.

- **Placement:** Place the assembled kitchen on a flat, stable surface.



Image: Packaging dimensions for the Gourmet Smart Kitchen, indicating the size of the box.

Your browser does not support the video tag.

Video: An overview of the Disney Princess Style Collection Gourmet Smart Kitchen, demonstrating its features and components.

5. Operating Instructions

The Gourmet Smart Kitchen features several interactive appliances:

5.1. Stovetop

- Place the included pot or flipping fry pan on the stovetop burner.
- The stovetop will recognize the cookware and activate corresponding sizzle or boiling sounds and lights.
- Use the flipping fry pan to interact with the pancake or fried egg accessories, triggering phrases to flip them.



Image: A close-up view of the interactive stovetop, showing a pancake in the frying pan and the illuminated burner.

5.2. Microwave and Oven

- The microwave and oven doors can be opened and closed.
- The microwave features lights and sounds when operated.
- The oven provides cooking prompts and sounds.

5.3. Dishwasher

- Open the dishwasher door to reveal the built-in dish rack.
- Place play dishes in the rack.
- The dishwasher features washing sounds and indicates when the cleaning cycle is complete.



Image: The open dishwasher door, showing the removable dish rack with play plates and cutlery inside.

5.4. Faucet and Sink

- Turn the handle on the faucet to activate water sounds.
- The sink area can be used for pretend washing of dishes.



Image: A detailed view of the sink and faucet, with a dish rack positioned for drying play dishes.

5.5. Refrigerator

- The French door refrigerator can be opened to store play food items.
- It includes a play ice dispenser that dispenses the included ice cubes.
- The refrigerator indicates when the door is left open with a sound prompt.

5.6. Overhead Hood

- The overhead hood features a fan sound for realistic play.

6. Maintenance

- **Cleaning:** Wipe all surfaces with a damp cloth and mild soap. Do not use abrasive cleaners. Ensure electronic components are not exposed to excessive moisture.
- **Battery Replacement:** When sounds or lights become faint or stop working, replace the 3 AA batteries. Refer to the battery compartment for correct placement.
- **Storage:** Store the kitchen in a dry, cool place away from direct sunlight when not in use.

7. Troubleshooting

- **No Sound/Lights:**
  - Check if batteries are correctly installed and not depleted. Replace if necessary.
  - Ensure the appliance is properly activated (e.g., pot on stovetop, door closed for microwave).
- **Appliance Not Responding:**
  - Verify that the specific play accessory (pot, pan) is correctly placed on the sensor.
  - If the issue persists, try removing and re-inserting batteries to reset the electronics.
- **Loose Parts:** Regularly check all connections and fasteners to ensure the kitchen remains stable and safe for play. Tighten any loose parts as needed.

8. Specifications

Feature	Detail
Product Dimensions	25.5 x 17.5 x 25.5 inches
Item Weight	32.9 pounds
Model Number	210381-SOC
Recommended Age	36 months - 6 years
Batteries Required	3 AA batteries (not included)
Manufacturer	Jakks Pacific Inc.
Interactive Features	Lights, Sounds, Phrases for 7 appliances

9. Warranty and Support

For warranty information or product support, please refer to the documentation included with your purchase or contact Jakks Pacific Inc. directly. Contact details can typically be found on the product packaging or their official website.