Disney Princess 229841-SOC

Disney Princess Style Collection Fresh Prep Gourmet Kitchen Instruction Manual

Model: 229841-SOC

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Disney Princess Style Collection Fresh Prep Gourmet Kitchen. Please read all instructions carefully before use to ensure safe and enjoyable play.

The Fresh Prep Gourmet Kitchen is an interactive play kitchen designed for children aged 36 months to 6 years, featuring realistic sounds, lights, and a unique steam effect for an immersive cooking experience.

Safety Information

WARNING: Adult assembly and supervision are required.

- Keep small parts away from children during assembly to prevent choking hazards.
- Ensure all screws and fasteners are securely tightened before play.
- Do not allow children to climb on the kitchen unit.
- Use only the recommended batteries (3 AA) and ensure correct polarity.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the toy is not used for an extended period.

Package Contents

Verify that all items listed below are present in your package before beginning assembly.



Main Kitchen Unit



Over 35 Play Accessories

Detailed Accessory List:

- Pasta Night Meal Box (includes Pasta Box, 1 Serving of Spaghetti, 3 Florets of Broccoli, 2 Garlic Bread Slices, 1 Serving of Meatballs, Can of Tomato Sauce)
- Interactive Recipe Card
- Fry Pan, Pot, Lid
- Oven Rack, Fridge Shelf
- Herb Garden Box (with 3 Rosemary Sprigs, 3 Parsley Sprigs, 3 Basil Leaves)
- Trash Can
- Olive Oil Bottle, Brush, Sponge, Cutting Board, Knife, Serving Spoon, Spatula, Ramekin
- Dish Rack, Colander
- 2 Dinner Plates, 2 Spoons, 2 Forks, 2 Knives, Glass, 2 Ice Cubes

Setup Instructions

Adult assembly is required. Please follow these steps carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, flat surface.
2. **Identify Parts:** Refer to the included assembly diagram (not provided in this manual) to identify each component.
3. **Assemble Main Structure:** Follow the step-by-step instructions provided with your product for assembling the main kitchen frame, refrigerator, and oven units. Ensure all connections are secure.

4. **Install Batteries:** Locate the battery compartments for the interactive features (stovetop, microwave, tablet, faucet, dishwasher). Insert 3 AA batteries (not included) into each compartment, ensuring correct polarity (+/-). Secure the battery covers.
5. **Attach Accessories:** Place the herb garden, cutting board, and other fixed accessories in their designated spots.
6. **Final Check:** Before allowing play, double-check all connections and battery installations.



Product Packaging (Front)



Product Packaging (Side)

Operating Instructions

Your Fresh Prep Gourmet Kitchen features several interactive elements for realistic play.

1. Realistic Steam Stovetop

Place the pot or fry pan on the stovetop burner. The burner will recognize the cookware and activate boiling or sizzling sounds. For the realistic steam effect, ensure the water reservoir (if applicable, refer to product-specific instructions for location) is filled with a small amount of water. The steam will then be generated during play.



Realistic steam effect on the stovetop burner.

Your browser does not support the video tag.

Video demonstrating the interactive features of the kitchen, including stovetop sounds and steam.

2. Interactive Tablet & Recipe Card

Insert the included recipe card into the interactive tablet slot. Press the button on the tablet to hear step-by-step instructions for preparing your meal. The tablet recognizes the recipe card to provide relevant guidance.



The interactive tablet reads recipe cards for guided play.

3. Microwave with Lights and Sounds

Open the microwave door, place play food inside, and close the door. Press the buttons on the microwave panel to activate cooking sounds and interior lights.



Microwave lights up and makes sounds when in use.

4. Faucet with Water Sounds

Turn the handle on the faucet to hear realistic water sounds, simulating washing dishes or filling pots.



Faucet produces realistic water sounds.

5. Dishwasher with Sounds

Load the dish rack with play dishes and place it inside the dishwasher. Close the door and press the dishwasher button to hear dishwashing sounds.



Dishwasher makes sounds for realistic cleaning play.

6. Other Features

- **Herb Garden:** Use the included herb sprigs for pretend cooking.
- **Cutting Board:** The cutting board fits over the sink for additional prep space.
- **Recycling & Trash Bin:** Utilize the flip-top bin for sorting play recycling and trash.
- **Color-Changing Noodles:** Place the play noodles in icy water to observe a color change.

Maintenance

- **Cleaning:** Wipe down all surfaces with a damp cloth and mild soap. Do not immerse electronic components in water.
- **Battery Replacement:** Replace batteries when sounds and lights become dim or stop functioning. Refer to the "Setup Instructions" for battery installation.
- **Storage:** Store the kitchen in a cool, dry place away from direct sunlight when not in use.

Troubleshooting

Problem	Solution
No sounds or lights from interactive features.	• Check if batteries are installed correctly with proper polarity. • Replace old or depleted batteries with new AA batteries. • Ensure battery compartment covers are securely closed.
Stovetop steam not working.	• Ensure the water reservoir is filled with a small amount of water. • Verify that the pot or fry pan is correctly placed on the burner.
Interactive tablet not reading recipe cards.	• Ensure the recipe card is fully inserted into the designated slot. • Check tablet batteries.

Specifications

Model Number: 229841-SOC

Product Dimensions: 25.5 x 17.5 x 25.5 inches (L x W x H)

Item Weight: 5.51 pounds

Recommended Age: 36 months - 6 years

Batteries Required: 3 AA batteries (not included for initial setup)

Manufacturer: Jakks Pacific Inc.

Release Date: August 31, 2023

Warranty and Support

For warranty information or technical support, please contact the manufacturer, Jakks Pacific Inc., directly. Refer to their official website or product packaging for contact details.
Please retain your purchase receipt as proof of purchase for any warranty claims.

© 2026 Disney Princess. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question