Disney Princess Dough.Q-123

Disney Princess Singing Jasmine & Rajah Doll Instruction Manual

Introduction

This manual provides essential information for the safe and proper use of your Disney Princess Singing Jasmine & Rajah doll. The doll is designed to celebrate the story of Disney's Aladdin, featuring Princess Jasmine in her iconic blue outfit with gold details, accompanied by her friend Rajah. Jasmine sings her signature song 'A Whole New World' in multiple languages.

What's Included

Your Disney Princess Singing Jasmine & Rajah doll package includes the following components:

- 1 Jasmine Doll
- 1 Doll Outfit (attached)
- 1 Doll Headband
- 1 Doll Lamp
- 1 Pair of Doll Earrings
- 1 Doll Necklace
- 1 Rajah Figure



The Jasmine doll is shown alongside her complete set of accessories: the Rajah figure, a golden magic lamp, a golden necklace, and a pair of golden earrings. This illustrates all components included with the product.

Setup

Battery Installation

The Jasmine doll requires 2 x AAA batteries for its singing function. These batteries are included with the product. To install or replace batteries:

1. Locate the battery compartment on the back of the doll.

2. Using a small Phillips head screwdriver (not included), unscrew the battery compartment cover.
3. Insert 2 new AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the cover and secure it with the screw.

Warning: Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Dispose of used batteries responsibly.

Accessory Attachment

Gently place the headband on Jasmine's head. The necklace can be placed around her neck, and the earrings can be inserted into the designated holes on her ears. The magic lamp and Rajah figure are standalone accessories for imaginative play.



This image displays the Disney Princess Jasmine doll in her iconic teal outfit, accompanied by the Rajah tiger figure and a golden magic lamp accessory. Jasmine's right arm is raised, and she wears a headband, necklace, and earrings.

Operating Instructions

Activating Singing Feature

To hear Princess Jasmine sing 'A Whole New World', locate the activation button on the doll's back. Press this button firmly to play the song. The doll sings in 10 different languages: English, French, Castilian Spanish, German, Italian, Swedish, Finnish, Norwegian, Danish, and Brazilian Portuguese.

Changing Languages

To cycle through the available languages, press the activation button on the doll's back repeatedly. Each press will switch to the next language in the sequence. Continue pressing until you reach your desired language.

Maintenance

Cleaning

To clean the doll and accessories, gently wipe them with a soft, damp cloth. Do not immerse the doll in water, as this can damage the electronic components. Avoid using harsh chemicals or abrasive cleaners.

Storage

Store the doll and its accessories in a cool, dry place away from direct sunlight and extreme temperatures. If the doll will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

Troubleshooting

- **Doll is not singing:**
  Ensure that the batteries are correctly installed and are not depleted. Replace batteries if necessary. Make sure the activation button on the doll's back is being pressed firmly.
- **Sound is distorted or too low:**
  This may indicate low battery power. Replace the batteries with fresh ones.
- **Difficulty changing languages:**
  Ensure you are pressing the activation button on the doll's back. Press and release the button clearly for each language change.

Specifications

Model Number	Dough.Q-123
Brand	Disney Princess
Dimensions (L x W x H)	7.75 x 4.75 x 15 inches (19.68 x 12.06 x 38.1 cm)
Item Weight	700 Grams
Material	Plastic
Batteries Required	2 x AAA (included)
Recommended Age	36 months (3 years) and up

UPC	192995223530

Safety Information

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

This product contains small parts that may pose a choking hazard to young children. Adult supervision is recommended during play. Keep packaging materials away from children.

Warranty

This product is sold without a manufacturer's warranty. Please refer to the retailer's return policy for any issues with the product upon purchase.

Support

For further assistance or inquiries regarding your Disney Princess Singing Jasmine & Rajah doll, please contact the retailer where the product was purchased. For general product information, you may visit the official Disney Princess website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question