Cirbic 26

Cirbic Talking Clock Model 26 User Manual

For Visually Impaired and Elderly Users

1. Product Overview

The Cirbic Talking Clock Model 26 is designed to assist individuals with visual impairments, blindness, or the elderly by providing clear, audible time and date announcements. Its large, high-contrast button ensures ease of use, and it includes an alarm function with audio instructions for setting.

Key Features:

- Large, high-contrast button for easy activation.
- Audible time announcement with a single press.
- Audible date announcement with a second press.
- Easy-to-set alarm with audio guidance.
- North American accent male voice.
- Adjustable volume (High/Low).



The Cirbic Talking Clock features a large, easy-to-press blue button on a black base.

2. Setup Instructions

2.1 Battery Installation

1. Locate the battery compartment on the underside of the clock.
2. Using a small Phillips screwdriver, carefully remove the screw securing the battery compartment cover.
3. Remove the cover.
4. Insert three (3) AAA batteries (not included) into the compartment, ensuring correct polarity (+/-).
5. Replace the battery compartment cover and secure it with the screw.



The large button is designed for easy activation, providing audible time and date announcements.

2.2 Volume Adjustment

On the underside of the clock, locate the 'High/Low' switch. Slide the switch to your preferred volume setting.

3. Operating Instructions

3.1 Announcing Time and Date

1. To hear the current time, press the large blue button once. The clock will announce the time (e.g., "The time is 5:40 PM").
2. To hear the current date, press the large blue button a second time immediately after the time announcement. The clock will announce the date (e.g., "The date is February 18th").



The clock's compact and round design makes it suitable for various placements.

3.2 Setting Time and Alarm

The clock features a 'SET' button on its underside for configuration. Audio instructions will guide you through the process when this button is pressed.

1. Press and hold the 'SET' button on the underside of the clock until you hear an audio prompt.
2. Follow the audio instructions to set the current time (hour and minute). The large blue button will typically be used to advance values, and the 'SET' button to confirm.
3. Continue following the audio instructions to set the current date (month, day, year).
4. The clock will then guide you through setting the alarm time.
5. Once all settings are confirmed, the clock will exit setup mode.



A clear top-down view of the clock, emphasizing the large, accessible blue button.

4. Maintenance

- **Cleaning:** Wipe the clock with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the sound becomes faint or the clock stops functioning. Always replace all three AAA batteries at the same time.
- **Storage:** If storing the clock for an extended period, remove the batteries to prevent leakage.
- **Environment:** Keep the clock in a dry environment, away from extreme temperatures and direct sunlight.

5. Troubleshooting

- **No Sound/Faint Sound:** Check if the batteries are correctly installed and have sufficient power. Replace batteries if necessary. Ensure the volume switch is not set to 'Low' or is not obstructed.
- **Incorrect Time/Date:** Re-enter the setup mode using the 'SET' button and follow the audio instructions to correct the time and date.

- **Alarm Not Functioning:** Verify that the alarm has been set correctly during the setup process.
- **Intermittent Operation:** Ensure the battery contacts are clean and free from corrosion. If issues persist after battery replacement, contact customer support.

6. Specifications

Feature	Detail
Brand	Cirbic
Model Number	26
Color	Blue
Display Type	Digital (Audible)
Power Source	Battery Powered
Batteries Required	3 AAA batteries (not included)
Frame Material	Acrylonitrile Butadiene Styrene
Item Weight	3.52 ounces
Package Dimensions	4.61 x 4.21 x 1.3 inches

7. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Cirbic website. Keep your purchase receipt as proof of purchase.

© 2024 Cirbic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question