KEMEI 2M_KM-6630

Kemei 4 in 1 Nose Hair Beard Eyebrow Rechargeable Electric Trimmer User Manual

Model: KM-6631 (2M_KM-6630)

Product Overview

The Kemei 4-in-1 Electric Trimmer is a versatile grooming tool designed for precise trimming of nose hair, ear hair, eyebrows, and beards. Its lightweight design and powerful rotary cutting system ensure efficient and comfortable grooming.



Image: The Kemei 4-in-1 Electric Trimmer, showcasing the main unit, nose trimmer head, beard trimmer head, eyebrow trimmer head, detail trimmer head, charging cable, and cleaning brush.

Key Features:

- **4-in-1 Functionality:** Includes interchangeable heads for nose, ear, beard, and eyebrow trimming.
- **Washable Blades:** Trimmer heads are waterproof for easy cleaning.
- **Rechargeable Design:** Cordless operation for convenience.
- **Portable:** Compact design suitable for travel.
- **Efficient Cutting System:** Rotary cutting system designed to capture hairs from top and sides.



Image: The Kemei trimmer body with three different attachment heads (nose, beard, eyebrow) displayed alongside it, highlighting its multi-functional design.

Safety Information

- Always fully charge the trimmer before first use.
- Keep blades clean and dry to prevent skin irritation or infection.
- Exercise caution when using near eyes and ears.
- Avoid contact with water sources when charging or using the trimmer.
- Do not disassemble the main unit.
- Keep out of reach of children.

Setup and Charging

Before first use, ensure the trimmer is fully charged. This typically takes 8 hours.

1. **Connect the Charging Cord:** Insert the charging cord into the charging port at the base of the trimmer.
2. **Plug into Power Source:** Connect the USB end of the charging cord to a compatible USB power adapter (not supplied) or a USB port.
3. **Charge Fully:** Allow the trimmer to charge for approximately 8 hours for a full charge. The indicator light (if present) may show charging status.



Image: A close-up view of the Kemei trimmer's charging port and the accompanying USB charging cable, illustrating how to connect for power.

Attaching and Changing Trimming Heads:

The Kemei trimmer comes with multiple interchangeable heads for different grooming needs.

1. **To Attach:** Align the desired trimming head with the main body of the trimmer and gently twist or push until it clicks securely into place.

2. **To Detach:** Gently twist or pull the trimming head away from the main body.

Operating Instructions

Ensure the trimmer is fully charged before use for optimal performance.

1. **Power On:** Slide the power switch located on the main body upwards to turn on the trimmer.
2. **Select Head:** Choose the appropriate trimming head for your grooming task.
3. **Nose and Ear Hair Trimming:**
    - Gently insert the nose/ear trimmer head into the nostril or ear canal.
    - Move the trimmer in a circular motion to trim unwanted hair. Do not insert too deeply.
4. **Beard and Eyebrow Trimming:**
    - Attach the beard or eyebrow trimming head.
    - For beard, move the trimmer against the direction of hair growth for an even trim.
    - For eyebrows, use caution and trim stray hairs carefully, possibly using a comb to guide.
5. **Sideburns Trimming:**
    - Use the precision trimmer head for shaping sideburns.
    - Move the trimmer downwards in a controlled manner.
6. **Power Off:** Slide the power switch downwards to turn off the trimmer after use.



Image: An illustrative diagram highlighting the Kemei trimmer's internal motor for strong speed (6500 rotations per minute) and its three-dimensional curved head design, which is designed to catch hair from all angles without hurting the skin.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your Kemei trimmer.

1. **Detach Trimming Head:** After each use, turn off the trimmer and detach the trimming head.
2. **Rinse Blades:** The trimming heads are waterproof. Rinse the blades under running water to remove hair clippings and debris.
3. **Use Cleaning Brush:** For stubborn hair or debris, use the provided cleaning brush to gently brush away particles from the blades and inside the head.
4. **Dry Thoroughly:** Allow the trimming head to air dry completely before reattaching it to the main body or storing. Do not use a cloth on the blades as it may damage them.
5. **Clean Main Body:** Wipe the main body of the trimmer with a dry or slightly damp cloth. Do not submerge the main

body in water.

6. **Storage:** Store the trimmer and its accessories in a cool, dry place, away from direct sunlight and moisture.



Image: The Kemei trimmer being splashed with water, visually representing its washable head feature for easy cleaning under running water.

Troubleshooting

Problem	Possible Cause	Solution
Trimmer pulls hair instead of cutting.	Low battery or improper technique.	Ensure the trimmer is fully charged. When trimming, take it close to the skin and move slowly.
Trimmer does not turn on.	Battery is depleted or power switch is off.	Charge the trimmer for 8 hours. Check if the power switch is in the "ON" position.

Problem	Possible Cause	Solution
Trimming head is difficult to attach/detach.	Incorrect alignment or debris.	Ensure the head is aligned correctly with the main body. Check for any debris obstructing the connection and clean if necessary.
Reduced trimming performance.	Blades are dirty or dull.	Clean the trimming head thoroughly. If performance does not improve, consider contacting customer support for replacement parts if available.

Specifications

Feature	Detail
Model	KM-6631 (2M_KM-6630)
Brand	KEMEI
Color	Black
Charging Time	8 hours
Battery Time	60 minutes
Power Source	Battery Powered
Blade Material	Stainless Steel
Special Features	Cordless, Portable, Rechargeable, Waterproof (heads only)
Accessories Included	1 x Trimmer Main Unit, 4 x Interchangeable Trimming Heads (Nose, Beard, Eyebrow, Detail), 1 x Cleaning Brush, 1 x Charging Cord
Parcel Dimensions	19.3 x 13.46 x 3.3 cm
Item Weight	159 g

Warranty and Support

For information regarding product warranty, please refer to the documentation included with your purchase or contact the manufacturer directly.

If you require technical support or have questions not covered in this manual, please contact KEMEI customer service through their official website or the retailer from whom you purchased the product.

Note: Specific warranty terms and support contact details may vary by region and retailer.

© 2023 KEMEI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question