Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beurer FC55

Beurer FC55 Electric Body Scrubber User Manual

Model: FC55 | Brand: Beurer

Product Overview

The Beurer FC55 Electric Body Scrubber is designed for thorough cleansing and exfoliation of the entire body. This waterproof device features two speed settings and comes with two distinct brush attachments to cater to different skin needs, leaving your skin feeling soft and radiant. Its cordless and rechargeable design ensures convenience and flexibility for use in the shower or bath.



Image: The Beurer FC55 Electric Body Scrubber, its long handle, and the two included brush attachments are displayed alongside its product packaging. This image illustrates the complete product set.

Key Features:

- **Thorough Cleansing & Exfoliation:** Designed to leave skin soft, radiant, and prepared for skincare routines.
- **Waterproof Design (IPX7):** Suitable for use in the shower or bath for a pleasant cleansing and massage experience.
- **Removable Handle:** Allows for convenient use on the entire body, including hard-to-reach areas like the back.
- **Two Brush Attachments:** Includes a soft cleansing brush and a deep exfoliation brush, suitable for all skin types.
- **Two Speed Levels:** Offers adjustable intensity for deeper cleansing or gentle treatment.
- **Rechargeable Battery:** Provides approximately 60 minutes of use on a full charge.

Safety Information

Please read this entire instruction manual carefully before using the Beurer FC55 Electric Body Scrubber. Retain this manual for future reference. Failure to follow these instructions may result in injury or damage to the device.

- Do not immerse the charging base in water.
- Ensure the device is fully dry before charging.
- Do not use the device on irritated, damaged, or infected skin.
- Consult a physician before use if you have skin conditions, severe acne, or are undergoing medical treatment.
- Keep out of reach of children.
- Only use original Beurer accessories and replacement parts.
- Do not attempt to repair the device yourself. Contact authorized service personnel for repairs.

Package Contents

Verify that all items listed below are present in your package:

- Beurer FC55 Electric Body Scrubber (main unit)
- Removable long handle
- Soft brush attachment
- Exfoliating brush attachment
- Charging cable (USB)
- Instruction manual

Setup and Initial Use

1. Charging the Device:

Before first use, fully charge the Beurer FC55 for approximately 2 hours. Connect the charging cable to the device and a suitable USB power source. The charging indicator light will show the charging status.

2. Attaching the Brush Head:

Select your desired brush attachment (soft or exfoliating). Align the brush head with the main unit and gently press until it clicks into place. The brush heads attach magnetically for secure fit and easy removal.



Image: This image displays the two distinct brush attachments included with the Beurer FC55: a soft cleansing brush and a deep exfoliation brush, highlighting their different bristle patterns.

3. Attaching the Handle (Optional):

For extended reach, especially for your back, attach the clear long handle to the main unit. Align the connection points and push firmly until it locks securely. The handle can be easily removed for handheld use.



Image: The Beurer FC55 main unit is shown alongside its transparent, removable long handle, demonstrating the modular design for versatile use.

Operating Instructions

Using the Scrubber:

1. **Prepare your skin:** Wet your skin and apply your preferred body wash or cleanser directly to the brush head or your body.
2. **Power On:** Press the power button on the main unit to turn on the device. It will start at the lower speed setting.
3. **Adjust Speed:** Press the power button again to switch to the higher speed setting. Press a third time to turn the device off.
4. **Cleanse:** Gently move the brush in circular motions over your body. Do not apply excessive pressure, as this may cause the brush to slow down or stop. The device is designed for gentle yet effective cleansing.
5. **Target Areas:** Use the long handle for hard-to-reach areas like your back. For areas like arms, legs, and chest, you

can detach the handle and use the main unit directly in your hand.



Image: A woman is shown comfortably using the Beurer FC55 Electric Body Scrubber with its long handle while relaxing in a bubble bath, demonstrating its waterproof capability and ease of use for reaching the back.



Image: This image shows a woman effectively using the Beurer FC55 Electric Body Scrubber on her upper back with the long handle attached, highlighting its utility for reaching difficult areas.



Image: A visual representation of the Beurer FC55's two-stage rotation feature, indicating the direction of brush movement for effective cleansing.

Maintenance and Cleaning

Regular cleaning ensures the longevity and hygienic use of your Beurer FC55.

- **After each use:** Remove the brush attachment from the main unit. Rinse both the brush head and the main unit under running water to remove any soap residue and skin particles.
- **Deep Cleaning:** For thorough disinfection, wash the brush heads with antibacterial hand soap. Ensure all bristles are clean.
- **Drying:** Shake off excess water and allow the brush heads and main unit to air dry completely before storing or recharging. Do not use a towel on the bristles as this can damage them.
- **Storage:** Store the device and attachments in a clean, dry place away from direct sunlight.
- Do not use abrasive cleaning agents or harsh chemicals, as these can damage the device's surface or bristles.



Image: The Beurer FC55 main unit and an exfoliating brush head are shown with water droplets, emphasizing the product's waterproof capabilities and ease of cleaning.

Troubleshooting

If you encounter issues with your Beurer FC55, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device for at least 2 hours.
Brush head stops or slows down during use.	Excessive pressure applied; battery low.	Reduce pressure on the skin. Ensure the device is fully charged.
Brush head does not attach securely.	Improper alignment or debris.	Ensure the brush head is correctly aligned with the main unit and free of debris. Press firmly until it clicks.

Problem	Possible Cause	Solution
Device not charging.	Charging cable or power source issue.	Check the charging cable connection. Try a different USB power source. Ensure the device is dry.

If the problem persists after trying these solutions, please contact Beurer customer support.

Specifications

- **Model:** FC55
- **Power Source:** Battery Powered (Rechargeable Lithium Ion)
- **Battery Life:** Approximately 60 minutes of use per charge
- **Charging Time:** Approximately 2 hours for a full charge
- **Waterproof Rating:** IPX7 (suitable for immersion up to 1 meter for 30 minutes)
- **Product Dimensions:** 16 x 3.9 x 3.9 inches (with handle)
- **Weight:** 1.2 Pounds
- **Material:** Plastic
- **Color:** Pink



Image: A visual representation of the Beurer FC55 Electric Body Scrubber's dimensions, indicating its length (16 inches), width (3.9 inches), and weight (1.2 pounds).

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Beurer website. You can also find additional support and FAQs on the Beurer Store on Amazon.
For a downloadable PDF version of the user manual, please visit:User Manual (PDF)

© 2024 Beurer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07L5H9VHR

More documents and user manuals: **https://manuals.plus/**