RetroGameBoyz MSX MSX 2 Controller

RetroGameBoyz MSX MSX 2 Controller Instruction Manual

Model: MSX MSX 2 Controller

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your RetroGameBoyz MSX MSX 2 Controller. Designed for use with MSX and MSX 2 computer systems, this controller offers a reliable way to experience retro gaming. Please read this manual thoroughly before use.



Image: The RetroGameBoyz MSX MSX 2 Controller, showcasing its design with a directional pad and two action buttons.

1. Setup

1.1 Unpacking

Carefully remove the controller from its packaging. Ensure all components are present. The package should contain one RetroGameBoyz MSX MSX 2 Controller.

1.2 Connecting the Controller

Locate the controller port on your MSX or MSX 2 computer system. This controller features a standard 9-pin D-sub connector. Align the connector with the port and gently push it in until it is securely seated.



Image: The controller's coiled cable and 9-pin D-sub connector, illustrating the connection interface.

No additional drivers or software are required for operation with compatible MSX systems.

2. Operating Instructions

2.1 Basic Controls

The RetroGameBoyz MSX MSX 2 Controller is designed for 2-button MSX games. It features a directional pad (D-pad) and two action buttons, labeled 'A' and 'B'.



Image: A hand demonstrating the use of the directional pad on the controller, highlighting its ergonomic design.

- **Directional Pad (D-pad):** Used for movement and navigation within games and menus.
- **Button B:** Functions as Action Button 1 in most compatible games.
- **Button A:** Functions as Action Button 2 in most compatible games.
- **Start Button:** Configured to move right in menu selections.
- **Select Button:** Configured to move left in menu selections.

Button assignments may vary slightly depending on the specific game. Refer to your game's instructions for precise control mapping.

3. Maintenance

3.1 Cleaning

To clean the controller, use a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the controller's internal components. Do not use harsh chemicals or abrasive cleaners.

3.2 Storage

Store the controller in a cool, dry place away from direct sunlight and extreme temperatures. Avoid wrapping the cable too tightly to prevent damage.

4. Troubleshooting

Problem	Possible Cause	Solution
Controller not responding	Loose connection; incompatible game/system; faulty port.	Ensure the controller is securely plugged into the MSX/MSX 2 port. Test with another game or system if available. Verify the game supports a 2-button controller.
Buttons or D-pad unresponsive	Dirt/debris under buttons; internal component issue.	Clean the controller as described in the Maintenance section. If the issue persists, contact customer support.
Incorrect button mapping	Game-specific configuration.	Refer to the game's instruction manual for controller setup and button remapping options. The controller's default mapping is B=Action 1, A=Action 2, Start=Right, Select=Left.

5. Specifications

Model: MSX MSX 2 Controller

Brand: RetroGameBoyz

Compatibility: MSX, MSX 2 Computer Systems (2-button games)

Connector: 9-pin D-sub

Cable Length: Approximately 10 ft

Buttons: Directional Pad, Action Button A, Action Button B, Start, Select

Material: Durable plastic casing, Gold-plated PCB contacts

Color: Black

6. Customer Support

For further assistance, technical support, or warranty inquiries, please contact RetroGameBoyz customer service through their official website or the retailer where the product was purchased. Please have your product model number (MSX MSX 2 Controller) and purchase information ready when contacting support.

© 2023 RetroGameBoyz. All rights reserved.