**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## GRIFEMA G4002-2

# GRIFEMA G4002-2 Kitchen Faucet User Manual

Model: G4002-2 | Chrome / Black Finish

### Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your GRIFEMA G4002-2 kitchen faucet. Please read these instructions carefully before installation and retain them for future reference. Proper installation and care will ensure optimal performance and longevity of your faucet.

### Product Features

- **Durable Ceramic Disc Cartridge:** Engineered for wear resistance, ensuring leak-free operation.
- **Flexible Spout:** Rotates 360 degrees and is highly flexible for convenient use during daily kitchen tasks.
- **Robust Construction:** Features a solid brass body with lead-free waterways for safety and durability.
- **Elegant Design:** Aesthetically pleasing with a minimalist charm.
- **Cold Start (Kelogic System):** Designed for energy savings, ensuring only cold water flows when the lever is in the central position, activating the water heater only when hot water is specifically selected.

### Package Contents

Verify that all components are present before beginning installation:

- 1 x GRIFEMA G4002-2 Kitchen Faucet (Chrome / Black)
- 2 x Water Supply Hoses (40 cm length)
- 1 x Installation Kit (mounting hardware)




**Image:** All components included in the GRIFEMA G4002-2 kitchen faucet package, laid out for inspection. This includes the faucet body, two flexible water supply hoses, and a bag containing mounting hardware.

## Setup and Installation

This faucet is designed for single-hole installation. Professional installation is recommended.

### Pre-Installation Checks:

- Ensure your sink has a single mounting hole of appropriate size.
- Confirm sufficient clearance under the sink for mounting hardware and hose connections.
- Turn off the main water supply before starting installation.




**Image:** A diagram illustrating the key dimensions of the GRIFEMA G4002-2 kitchen faucet. Measurements include a total height of 401mm (15.8 inches), a spout height of 246mm (9.7 inches), and a spout reach of 216mm (8.5 inches).

### Installation Steps:

1. **Prepare the Sink:** Clean the mounting area on the sink or countertop.
2. **Mount the Faucet:** Insert the faucet body into the mounting hole. From underneath the sink, secure it with the provided washer and mounting nut from the installation kit. Tighten firmly but do not overtighten.
3. **Connect Water Supply Lines:** Attach the hot and cold water supply hoses to the corresponding inlets on the faucet body. Connect the other ends of the hoses to your hot and cold water supply valves. Ensure all connections are hand-tight, then use a wrench for a final quarter-turn.
4. **Test for Leaks:** Slowly turn on the main water supply. Check all connections for any signs of leakage. If leaks occur, tighten the connections slightly until they stop.
5. **Flush the Faucet:** Remove the aerator from the spout. Turn on both hot and cold water for a few minutes to flush out any debris from the lines. Turn off the water, reattach the aerator, and test the flow.

## Operating Instructions

### Water Flow and Temperature Control:

The single lever handle controls both water flow and temperature. Lift the handle to increase water flow. Move the handle left for hot water and right for cold water.



**Image:** The GRIFEMA G4002-2 kitchen faucet in operation, with water flowing from the flexible black spout into a sink. A hand is shown washing a lemon under the stream of water, demonstrating the faucet's functionality.

### Flexible Spout:

The faucet features a highly flexible spout that can be rotated 360 degrees and bent in various directions, providing versatility for washing large pots, cleaning the sink, or filling containers.




**Image:** A collage of four images demonstrating the flexibility and adjustability of the GRIFEMA G4002-2 faucet's spout. The spout is shown bent into different positions, highlighting its ability to be adjusted to various angles and shapes for diverse kitchen tasks.




**Image:** The GRIFEMA G4002-2 kitchen faucet in use, with the flexible black spout directed towards a plate being rinsed in the sink. This illustrates the practical application of the flexible spout for washing dishes.

### Cold Start (Kelogic System):

The Kelogic system ensures that when the faucet handle is in the central position, only cold water flows. This prevents the water heater from activating unnecessarily, contributing to energy savings.




**Image:** A diagram explaining the 'Cold Start, Kelogic' feature of the GRIFEMA G4002-2 faucet. It shows that when the handle is in the central position, only cold water is used, saving energy by not activating the water heater unless the handle is moved to the left for hot water. Icons for water savings, energy savings, and low noise are also present.

### Water Saving Aerator (NEOPERL):

The integrated NEOPERL aerator helps to optimize water flow while reducing water consumption, contributing to water savings without compromising performance.




**Image:** The GRIFEMA G4002-2 kitchen faucet with an inset showing the 'Water Saving Aerators' by NEOPERL. The image highlights the aerator's function in controlling water flow, indicated by the text 'flow, stop and go', and its contribution to water conservation.

## Maintenance

Regular cleaning and proper care will maintain the appearance and functionality of your faucet.

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, ammonia, bleach, or acid-based cleaners, as these can damage the finish.
- **Aerator Cleaning:** If water flow decreases, the aerator may be clogged. Unscrew the aerator from the spout, clean any debris, and rinse it before reattaching.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Low Water Flow | Clogged aerator; partially closed shut-off valves; low water pressure in the household. | Clean or replace the aerator. Ensure shut-off valves are fully open. Consult a plumber if household water pressure is consistently low. |
| Leaks from Spout | Worn ceramic disc cartridge; debris in cartridge. | Contact customer support for a replacement cartridge or professional assistance. |
| Leaks from Base | Loose mounting nut; improper sealing. | Tighten the mounting nut under the sink. Ensure proper sealing during installation. |
| Difficulty Adjusting Temperature | Cartridge issue. | Contact customer support for assistance. |

## Specifications

| Attribute | Detail |
|---|---|
| **Brand** | GRIFEMA |
| **Model Number** | G4002-2 |
| **Product Dimensions (L x W x H)** | 40.1 x 21.6 x 5 cm (15.8 x 8.5 x 2 inches) |
| **Weight** | 1.77 Kilograms |
| **Color** | Chrome / Black |
| **Style** | Kitchen Mixer Faucet |
| **Finish** | Chromed |
| **Material** | Brass + Silicone Gel |
| **Installation Method** | Single-hole (Monotrou) |
| **Number of Handles** | 1 |
| **Spout Height** | 246 Millimeters (9.7 inches) |
| **Spout Reach (Depth)** | 8.5 Inches (216 Millimeters) |
| **Hose Length** | 40 Centimeters |
| **Special Features** | Lead-free, Flexible Spout, Cold Start (Kelogic) |
| **Components Included** | 1 x Kitchen Faucet, 2 x Supply Hoses, 1 x Installation Kit |

## Warranty

The GRIFEMA G4002-2 kitchen faucet comes with a **5-year limited warranty** from the manufacturer. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

For specific terms and conditions, refer to the warranty information provided with your product or contact GRIFEMA customer service.

## Support

If you encounter any issues not covered in this manual or require further assistance, please contact GRIFEMA customer support. When contacting support, please have your model number (G4002-2) and purchase information readily available. For more information, visit the official GRIFEMA website or contact your retailer.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B07L75PLGL**

More documents and user manuals: **https://manuals.plus/**