Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro F9000HD

Passion-Electro Replacement Remote Control for FUJIONKYO F9000HD SAT/DTT

User Instruction Manual

Introduction

Thank you for choosing the Passion-Electro Replacement Remote Control. This remote is designed to function as a direct replacement for your original FUJIONKYO F9000HD SAT/DTT remote, offering comparable functionality without the need for complex programming. Simply insert the batteries, and it's ready for use.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) AAA (LR03) 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Rear view of the remote control, showing the battery compartment. Ensure correct battery orientation when inserting.

2. Initial Use

This replacement remote control requires no programming. Once the batteries are correctly installed, it is ready to operate your FUJIONKYO F9000HD SAT/DTT device. Point the remote directly at your device and begin using it.

Operating Instructions

The remote control features a standard layout for easy navigation and control of your device. Below are common functions:



Figure 2: Top-down angled view of the remote control, highlighting the main navigation and colored function buttons.

- **Power Button (Power):** Turns your device on or off.
- **Mute Button (MUTE):** Mutes or unmutes the audio.
- **Volume Up/Down (VOL+/-):** Adjusts the audio volume.

- **Channel Up/Down (CH+/-):** Changes the channel.
- **Numeric Keypad (0-9):** Directly enter channel numbers.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Menu Button (MENU):** Accesses the main menu of your device.
- **Exit Button (EXIT):** Exits the current menu or function.
- **Info Button (INFO):** Displays program information.
- **EPG Button (EPG):** Accesses the Electronic Program Guide.
- **Colored Function Buttons (Red, Green, Yellow, Blue):** These buttons typically correspond to specific functions displayed on your screen within menus or applications.



Figure 3: Another angled view of the remote control, highlighting the numeric keypad and other function buttons like MUTE, POWER, TV, MENU, EXIT, SHIFT, AUX, DVD, and BAT.

Maintenance

1. Cleaning

To clean your remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or excessive moisture, as these can damage the remote.

2. Battery Replacement

Replace batteries when the remote's performance degrades or it stops responding. Always replace both batteries at the same time with new ones of the same type (AAA 1.5V). Do not mix old and new batteries or different battery types.

3. Storage

When not in use for extended periods, it is advisable to remove the batteries to prevent leakage, which can damage the remote's internal components. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

- **Remote not responding:**

- Check if the batteries are inserted correctly with the correct polarity.
- Replace the batteries with fresh ones.
- Ensure there are no obstructions between the remote control and your device.
- Make sure you are within the effective range of the device.

- **Specific buttons not working:**
  - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris that might be interfering with their function.
  - If cleaning and battery replacement do not resolve the issue, the remote may be faulty.

Specifications

Feature	Detail
Brand	Passion-Electro
Model Compatibility	FUJIONKYO F9000HD SAT/DTT
Battery Type	2 x AAA (LR03) 1.5V (not included)
Item Weight	Approximately 100 g
Special Feature	No programming required; functions like original remote



Figure 4: Side profile of the remote control, illustrating its ergonomic design.



Figure 5: Bottom view of the remote control, highlighting the battery compartment cover.

Warranty and Support

This product is covered by a standard manufacturer's warranty. For warranty claims, technical support, or any questions regarding your remote control, please contact your retailer or the manufacturer directly. Please refer to your purchase documentation for specific warranty terms and contact information.

© 2025 Passion-Electro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07L9GX3XG

More documents and user manuals: **https://manuals.plus/**