Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Techwood ES-3203C

Techwood ES-3203C Double Infrared Ceramic Hot Plate Instruction Manual

MODEL: ES-3203C

Thank you for choosing the Techwood Double Infrared Ceramic Hot Plate. This manual provides essential information for safe and efficient use of your appliance.

Important Safety Instructions

Please read all instructions carefully before using the appliance and retain for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always place the hot plate on a stable, heat-resistant surface.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical hazards, do not immerse the cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- All Techwood products have relevant safety certificates and are protected by US Product Liability Insurance.

Product Overview

The Techwood ES-3203C is a portable double infrared ceramic hot plate designed for versatile cooking. Its compact and lightweight design makes it suitable for various environments, including homes, offices, dorms, RVs, and camping.



Image: Techwood ES-3203C Double Infrared Ceramic Hot Plate in silver finish.

Key Features:

- **Dual Infrared Ceramic Burners:** Two independent cooking zones for simultaneous cooking.
- **Anti-Scald Handles:** Solid stainless steel riveted handles designed to stay cool during cooking for safe transport.
- **Durable Construction:** Timeless stainless steel body with a crystallite glass ceramic panel for durability and easy cleaning.
- **Adjustable Temperature Control:** Individual thermostatic knobs for precise heat adjustment from low to max.
- **Indicator Lights:** Visual indicators to show when each burner is active.
- **Non-Slip Feet:** Provides additional grip and stability to prevent accidental movement.



Image: Detailed view highlighting cast iron material, easy control knobs, 1800W infrared cooktop, indicator lights, non-slip feet, and easy cleanup features.

Setup

Before first use, ensure the hot plate is placed on a flat, stable, and heat-resistant surface with adequate ventilation around it. Ensure the power cord is not obstructed or touching any hot surfaces.

1. Unpack the hot plate and remove all packaging materials.
2. Wipe the ceramic surface and stainless steel body with a damp cloth to remove any dust.
3. Ensure the control knobs are in the "OFF" position before plugging the appliance into a standard 120V electrical outlet.

Operating Instructions

The Techwood hot plate is compatible with all types of cookware, including aluminum, copper, cast iron, non-magnetic stainless steel, and glass. This versatility allows you to use your existing pots and pans efficiently.





Image: Illustration showing various types of cookware compatible with the infrared burner, including frying pans, ceramic cookware, stainless steel cookware, glass cookware, and teapots.

Cooking with the Hot Plate:

1. Place your desired cookware (pot or pan) onto the ceramic burner.
2. Turn the individual control knob for the desired burner clockwise to select the desired heat setting (1-5, then Max). The indicator light will illuminate, signifying the burner is active.
3. The infrared ceramic cooktop heats up quickly. Adjust the temperature as needed for your cooking task (e.g., warming sauces, scrambling eggs, grilling cheese, boiling water, simmering).
4. The dual burners allow you to cook two different foods simultaneously, optimizing your cooking time.

5. After cooking, turn the control knob counter-clockwise to the "OFF" position. The indicator light will turn off.
6. Allow the hot plate to cool completely before handling or cleaning. The ceramic surface will remain hot for some time after use.



Image: Close-up of the dual dial adjustable heat controls, showing settings from Off to Max, with examples of dishes like soup, steak, and fries.

Official Product Video:

Video: A demonstration of the Techwood Infrared Ceramic Hot Plates in use, showcasing its heating capabilities and suitability for various cooking tasks.

Maintenance and Cleaning

Proper maintenance ensures the longevity and optimal performance of your Techwood hot plate.

1. Always unplug the hot plate from the power outlet and allow it to cool completely before cleaning.

2. Wipe the ceramic panel and stainless steel body with a clean, damp cloth. For stubborn stains, a mild detergent can be used.
3. Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the surface.
4. Ensure no water or liquids enter the internal components of the hot plate.
5. The non-slip feet should also be kept clean to maintain stability.



INDICATOR LIGHTS

Indicator lights let you know exactly when the hot plate on or off

NON-SLIP FEET

The non-slip feet provide additional grip and stability to prevent slipping





EASY CLEANUP

Premium design and cast iron surface for easy to clean

Image: Illustration demonstrating the easy cleanup process of the hot plate, highlighting its premium design and cast iron surface.

Troubleshooting

If you encounter issues with your Techwood hot plate, refer to the following common troubleshooting tips:

- **Appliance does not turn on:** Ensure the power cord is securely plugged into a working electrical outlet. Check if the control knob is turned to an active heat setting.
- **Inconsistent heating:** Verify that the cookware is flat-bottomed and making full contact with the burner surface.

Ensure the selected temperature setting is appropriate for the task.

- **Slow heating:** Allow sufficient time for the burner to reach the desired temperature, especially when boiling water. Ensure the power outlet is providing adequate voltage.
- **Smoke or odor during first use:** A small amount of smoke or odor may occur during the initial use as protective coatings burn off. This is normal and should dissipate quickly. Ensure adequate ventilation.

If problems persist, please contact Techwood customer support.

Specifications

Model Number	ES-3203C
Brand	Techwood
Color	Silver
Material	Stainless Steel
Heating Elements	2
Wattage	1800 watts
Power Source	Electric
Controls Type	Infrared (Dial)
Product Dimensions	7.9"D x 19.8"W x 3.9"H
Item Weight	7.39 pounds (3.36 Kilograms)
Included Components	Hot Plate, User Manual
UPC	659516583462, 735279781335

Warranty and Support

All Techwood products are designed and manufactured to high-quality standards. For any questions, concerns, or warranty claims, please refer to the contact information provided in your user manual or visit the official Techwood website.

Techwood products are protected by US Product Liability Insurance. Please retain your proof of purchase for warranty purposes.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07M5JKSWQ

More documents and user manuals: **https://manuals.plus/**