Glade 306979

Glade Automatic Spray Sensual Sandalwood & Jasmine Diffuser Instruction Manual

Model: 306979

1. Product Overview

The Glade Automatic Spray Diffuser with Sensual Sandalwood & Jasmine fragrance is designed to provide continuous, long-lasting freshness in your home. This battery-operated device automatically releases a fine mist of fragrance at set intervals, creating a welcoming atmosphere. The starter kit includes one diffuser and one refill.

The unique formula quickly fills the room with freshness and a variety of incredible scents. The elegant design of the automatic spray diffuser blends seamlessly with your home decor. Experience the essence of a prestigious spa day with distant notes of bergamot and jasmine intertwined with warm amber and sandalwood.



Image 1: Glade Automatic Spray Diffuser and refill.



Image 2: Illustration indicating fragrance infused with essential oils.

2. Safety Information

Please read and follow all safety instructions carefully before use.

- Avoid direct skin contact with undiluted essential oils.
- Keep out of reach of children and pets.
- Ensure good ventilation during use.
- Do not expose to temperatures exceeding 50°C (122°F).
- Do not spray near an open flame or any other ignition source.
- Do not puncture or incinerate the container.
- Use only as directed. Intentional misuse by deliberately concentrating and inhaling the contents can be harmful or fatal.
- Persons suffering from perfume sensitivity should be cautious when using this product.
- A partially synthetic fragrance. Dangerous. Observe precautions for use.
- Contains Benzyl Salicylate, Linalool. May produce an allergic reaction.



Image 3: "Air Intérieur Contrôlé A+" certification logo, indicating safe indoor air quality.

3. Setup and Installation

Follow these steps to set up your Glade Automatic Spray Diffuser:

1. **Install Batteries:** Open the diffuser by pressing the button at the top. Insert 2 AA batteries (included) into the designated slots, ensuring correct polarity.
2. **Insert Refill:** Use the locking system to insert the fragrance refill can into the diffuser. Ensure it clicks securely into place.
3. **Position the Diffuser:** Place the diffuser in your desired location, ensuring it is on a stable surface and away from direct sunlight or heat sources.

Your browser does not support the video tag.

Video 1: This video demonstrates how to open the diffuser, install batteries, and insert the fragrance refill. It also shows how to set the spray frequency.



Image 4: Hands opening the diffuser to access the battery and refill compartment.



Image 5: Hands inserting a Glade fragrance refill into the automatic diffuser.

4. Operation

Once set up, your Glade Automatic Spray Diffuser is ready for use.

1. **Set Spray Frequency:** Use the switch inside the diffuser to select your desired spray interval: 9, 18, or 36 minutes. You can also set it to "Off" to temporarily stop spraying.
2. **Automatic Spray:** The diffuser will automatically release a fine mist of fragrance at the selected interval.
3. **Boost Function (Optional):** Press the "Boost" button on the front of the diffuser to release an extra burst of fragrance on demand.



Image 6: A finger adjusting the switch to select the spray frequency (9, 18, 36 minutes, or Off).

5. Maintenance

- **Refill Replacement:** Each refill provides up to 60 days of freshness. When the fragrance diminishes or the can is empty, replace it with a new Glade Automatic Spray refill. Ensure the diffuser is turned "Off" before replacing the refill.
- **Battery Replacement:** When the diffuser stops spraying or the indicator light (if present) signals low battery, replace the 2 AA batteries.
- **Cleaning:** Wipe the exterior of the diffuser with a soft, damp cloth as needed. Do not immerse the device in water.

6. Troubleshooting

Problem	Possible Cause	Solution
Diffuser not spraying	• Batteries are dead or incorrectly installed. • Refill can is empty or incorrectly inserted. • Frequency switch is set to "Off".	• Replace batteries or ensure correct polarity. • Replace refill can or re-insert correctly. • Set the frequency switch to 9, 18, or 36 minutes.
Weak or no scent	• Refill can is nearly empty. • Room is too large for a single diffuser. • Diffuser is placed in an area with poor air circulation.	• Replace refill can. • Consider using multiple diffusers for larger spaces. • Relocate the diffuser to an area with better air circulation. • Use the Boost button for an immediate burst of fragrance.

7. Specifications

Model Number: 306979

Brand: Glade

Fragrance: Sensual Sandalwood & Jasmine

Power Source: 2 AA Batteries (included)

Product Dimensions (L x W x H): 2.54 x 2.54 x 2.54 cm

Weight: 540 grams

Refill Capacity: 269 ml (approx. 270 Millilitres)

Automatic Spray Intervals: 9, 18, or 36 minutes

Refill Duration: Up to 60 days (based on 36-minute setting)

Recommended Use: Creating a pleasant and fragrant atmosphere in various rooms (living room, bedroom, bathroom) for daily or special use.

Special Features: Spray system, automatic operation, long-lasting refill.

Manufacturer: SC Johnson

8. Warranty and Support

For warranty information, technical support, or to contact customer service, please refer to the official Glade website or the contact information provided on the product packaging.
Visit the Glade Store on Amazon

© 2026 Glade. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question