Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi EN560.B, EN560B, F521.BK, F521.SI

De'Longhi Nespresso Lattissima Touch Lid and Milk Tube

INSTRUCTION MANUAL

INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your original De'Longhi Nespresso replacement lid and milk tube. This accessory is designed for use with De'Longhi Nespresso Lattissima Touch capsule coffee machines, specifically compatible with models EN560.B, EN560B, F521.BK, and F521.SI. Please read this manual thoroughly before use to ensure optimal performance and longevity of your product.

PRODUCT OVERVIEW

The De'Longhi Nespresso Lattissima Touch Lid and Milk Tube is a genuine replacement part designed to restore or enhance the milk frothing capabilities of your compatible coffee machine. It consists of two primary components:

- **Lid:** The main housing unit that attaches to the milk carafe, containing the frothing mechanism and control knob.
- **Milk Tube:** A clear, flexible tube that connects the lid to the milk carafe, drawing milk for frothing.



Figure 1: Front view of the De'Longhi Nespresso Lattissima Touch Lid and Milk Tube. This image shows the main black lid unit with a control knob on the right side and the clear milk tube extending from the left.



Figure 2: Top-down view of the De'Longhi Nespresso Lattissima Touch Lid and Milk Tube. This image provides a clearer view of the top surface, including a barcode and product information, alongside the detached clear milk tube.

Setup and Installation

Follow these steps to correctly install the replacement lid and milk tube onto your De'Longhi Nespresso Lattissima Touch machine's milk carafe:

1. **Prepare the Milk Carafe:** Ensure your milk carafe is clean and empty before attaching the new lid and tube.
2. **Attach the Milk Tube:** Insert the clear milk tube firmly into the designated port on the underside of the lid. Ensure it is securely seated to prevent leaks.
3. **Place Lid on Carafe:** Align the lid with the top of the milk carafe. Press down gently until it clicks into place, forming a secure seal.
4. **Connect Carafe to Machine:** Slide the assembled milk carafe with the new lid into the designated slot on your Lattissima Touch coffee machine until it locks securely.
5. **Initial Rinse:** Before first use, it is recommended to perform a rinse cycle with water to clean the internal components. Refer to your coffee machine's main manual for specific rinse instructions.

Operating Instructions

Once the lid and milk tube are correctly installed, you can use your Lattissima Touch machine's milk frothing function:

1. **Fill Milk Carafe:** Fill the milk carafe with fresh, cold milk up to the MAX level indicator.
2. **Select Froth Level:** Use the control knob on the lid to select your desired milk froth consistency (e.g., less froth for

hot milk, more froth for cappuccino).

3. **Place Cup:** Position a cup under the coffee spout and milk frother nozzle.
4. **Start Beverage Preparation:** Select your desired milk-based beverage (e.g., Cappuccino, Latte Macchiato) on your Lattissima Touch machine. The machine will automatically draw milk, froth it, and dispense it into your cup.
5. **After Use:** After preparing a milk-based beverage, always perform the "Clean" function on your Lattissima Touch machine to rinse the milk system. This is crucial for hygiene and preventing blockages.

Maintenance and Cleaning

Regular cleaning of the lid and milk tube is essential for maintaining hygiene and ensuring consistent milk frothing performance. Always clean the components immediately after each use.

Daily Cleaning:

1. **Perform "Clean" Function:** After each milk preparation, press the "Clean" button on your Lattissima Touch machine. This will flush hot water through the milk system.
2. **Remove Lid and Tube:** Detach the milk carafe from the machine, then carefully remove the lid and the clear milk tube.
3. **Rinse Components:** Rinse the lid and milk tube thoroughly under warm running water. Ensure no milk residue remains.
4. **Air Dry:** Allow the components to air dry completely before reassembling or storing.

Weekly Deep Cleaning:

1. **Disassemble:** Fully disassemble the lid by removing any detachable parts as per your coffee machine's main manual (e.g., the frothing nozzle).
2. **Wash with Detergent:** Wash all disassembled parts (lid, milk tube, frothing nozzle) with warm water and a mild dishwashing detergent. Use a small brush if necessary to clean hard-to-reach areas.
3. **Rinse Thoroughly:** Rinse all parts thoroughly to remove any soap residue.
4. **Dishwasher Safe:** Refer to your coffee machine's main manual to confirm if these components are dishwasher safe. If so, they can be placed on the top rack.
5. **Reassemble:** Ensure all parts are completely dry before reassembling.

Troubleshooting

If you experience issues with your milk frothing system, consult the table below for common problems and solutions:

Problem	Possible Cause	Solution
No milk froth or poor froth quality	◦ Milk carafe or lid not properly attached. ◦ Milk tube clogged or not fully inserted. ◦ Milk residue buildup in the frothing mechanism. ◦ Using non-cold or unsuitable milk (e.g., skim milk may froth less). ◦ Control knob set incorrectly.	◦ Ensure carafe and lid are securely locked. ◦ Check milk tube for blockages and proper insertion. ◦ Perform deep cleaning of the lid and tube. ◦ Use fresh, cold, semi-skimmed or whole milk. ◦ Adjust the control knob to a higher froth setting.

Problem	Possible Cause	Solution
Milk leaking from the lid or tube connection	◦ Lid not securely attached to the carafe. ◦ Milk tube not fully inserted into the lid. ◦ Damaged seal or component.	◦ Re-attach the lid, ensuring it clicks into place. ◦ Push the milk tube firmly into its port. ◦ Inspect for visible damage; if damaged, replacement may be necessary.
"Clean" light remains on after cleaning	◦ Cleaning cycle not completed or insufficient. ◦ Milk residue still present.	◦ Run the "Clean" cycle again. ◦ Perform a deep clean of the lid and tube.

For issues not listed here, or if problems persist, please refer to your main De'Longhi Nespresso Lattissima Touch machine manual or contact customer support.

Specifications

Feature	Detail
Product Type	Replacement Lid and Milk Tube
Brand	De'Longhi
Compatible Models	De'Longhi Nespresso Lattissima Touch (EN560.B, EN560B, F521.BK, F521.SI)
Material	Plastic
Dimensions (L x W x H)	Approximately 6 x 7 x 9 cm (2.36 x 2.76 x 3.54 inches)
Weight	Approximately 70 grams (0.15 lbs)
Components Included	Lid + Milk Tube

Warranty and Support

This product is an original De'Longhi replacement part. For specific warranty information regarding this accessory, please refer to the warranty documentation provided with your original De'Longhi Nespresso Lattissima Touch coffee machine, or visit the official De'Longhi website.

For technical support, spare parts, or service inquiries, please contact De'Longhi customer service through their official channels. Ensure you have your coffee machine's model number and serial number ready when contacting support.

You can often find contact information and support resources on the official De'Longhi website: www.delonghi.com

© 2024 De'Longhi. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07M9LJSM5

More documents and user manuals: **https://manuals.plus/**