Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit RMT-AH103U

ZdalaMit RMT-AH103U Replacement Remote Control Instruction Manual

For Sony Soundbar Models HT-CT80 and SA-CT80

1. Introduction

This manual provides instructions for the ZdalaMit RMT-AH103U replacement remote control. This remote is designed to function as a direct replacement for the original remote controls of Sony Soundbar models HT-CT80 and SA-CT80. No programming or pairing is required for its operation.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA 1.5V alkaline batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Battery compartment with cover removed, showing battery placement.

Once batteries are installed, the remote is ready for use. No additional programming or pairing is necessary.

3. Operating Instructions

This section describes the functions of the buttons on your ZdalaMit RMT-AH103U remote control.



Figure 2: Front view of the remote control with button layout.

- **Power (I/O)**: Turns the soundbar on or off.
- **AUDIO**: Selects the audio input source.

- **USB**: Selects the USB input source.
- **OPTICAL**: Selects the Optical input source.
- **ANALOG**: Selects the Analog input source.
- **Volume (+/-)**: Increases or decreases the main volume level.
- **Mute (speaker icon)**: Mutes or unmutes the sound.
- **SW (+/-)**: Adjusts the subwoofer volume level.
- **CLEAR AUDIO+**: Activates or deactivates the Clear Audio+ sound mode.
- **VOICE**: Enhances dialogue clarity.
- **SURROUND**: Activates or deactivates surround sound mode.
- **NIGHT**: Optimizes sound for low-volume listening at night.
- **Playback Controls (Rewind, Play/Pause, Fast Forward)**: Controls media playback when applicable (e.g., USB input).

Ensure there is a clear line of sight between the remote control and the soundbar's infrared receiver for optimal performance.

4. Maintenance

4.1 Battery Replacement

Replace the batteries when the remote control's response becomes inconsistent or stops working. Refer to Section 2.1 for battery installation instructions. Always replace both batteries at the same time with new AAA 1.5V alkaline batteries.

4.2 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the remote's surface or internal components.

5. Troubleshooting

- **Remote not responding**:
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the soundbar's infrared receiver.
  - Confirm you are within the effective operating range (approximately 33 feet).
- **Specific buttons not working**:
  - Verify that the soundbar is powered on and functioning correctly.
  - Some functions may only be available with specific input sources or soundbar modes.

6. Specifications

Model Name	RMT-AH103U
Compatible Soundbar Models	Sony HT-CT80, SA-CT80
Brand	ZdalaMit
Power Supply	2 x AAA 1.5V Alkaline Batteries

Connectivity Technology	Infrared (IR)
Maximum Range	Approximately 33 feet (10 meters)
Button Quantity	18
Dimensions (L x W x H)	6.35" x 0.99" x 0.55" (16.13 cm x 2.51 cm x 1.40 cm)
Item Weight	1.5 Ounces (42.5 grams)

7. Warranty and Support

7.1 Warranty Information

This product comes with a 1-year warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper battery installation.

7.2 Customer Support

If you encounter any issues or have questions regarding your ZdalaMit RMT-AH103U replacement remote control, please contact the seller or manufacturer for assistance. Refer to your purchase documentation for specific contact details.

© 2026 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07MCSBBSQ

More documents and user manuals: **https://manuals.plus/**