Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Stihl B07MDSPDDQ

Stihl 36" Chainsaw Bar Scabbard Cover Instruction Manual

Model: 0000-792-9179

Product Overview

The Stihl 0000-792-9179 bar scabbard is designed to provide essential protection for your chainsaw bar during transport and storage. This durable cover helps prevent damage to the bar and chain, and also protects users from accidental contact with the sharp chain. It is specifically sized for 36-inch chainsaw bars.



An orange plastic scabbard, approximately 36 inches long, designed to cover a chainsaw bar. The Stihl logo is embossed on its surface, indicating its brand and quality.

Setup and Installation

The Stihl 36" Chainsaw Bar Scabbard Cover is designed for simple and quick application.

1. **Ensure Safety:** Before handling your chainsaw, ensure the engine is off, the chain brake is engaged, and the chain is cool. Always wear appropriate protective gloves.
2. **Align Scabbard:** Hold the scabbard with the open end facing the tip of the chainsaw bar.
3. **Slide On:** Carefully slide the scabbard over the chainsaw bar, guiding it along the length until it fully covers the bar and chain. Ensure the scabbard fits snugly over the entire cutting attachment.
4. **Verify Fit:** Confirm that the scabbard is securely in place and does not easily slip off. The scabbard should cover the entire length of the bar, protecting the chain and bar tip.

Operating Instructions

The scabbard's primary function is passive protection. No active operation is required beyond proper installation.

- **Transport:** Always use the scabbard when transporting your chainsaw to prevent accidental contact with the chain and to protect the bar from damage.

- **Storage:** Store your chainsaw with the scabbard in place to keep the bar and chain protected from environmental elements and to maintain safety in storage areas.

Maintenance

Regular maintenance of your scabbard ensures its longevity and effectiveness.

- **Cleaning:** Periodically wipe down the scabbard with a damp cloth to remove dirt, sawdust, and debris. For stubborn grime, a mild soap solution can be used. Ensure it is dry before re-applying to the chainsaw bar.
- **Inspection:** Regularly inspect the scabbard for any signs of cracks, damage, or excessive wear. A damaged scabbard may not provide adequate protection and should be replaced.
- **Storage:** When not in use, store the scabbard in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.

Troubleshooting

While the scabbard is a simple accessory, minor issues can arise.

- **Scabbard Does Not Fit:**
  Possible Cause: Incorrect scabbard length for your chainsaw bar.
  Solution: Verify that your chainsaw bar is 36 inches. This scabbard is specifically designed for 36-inch bars. If your bar is a different size, you will need a different scabbard.
- **Scabbard Slips Off Easily:**
  Possible Cause: Scabbard is worn or damaged, or not fully seated.
  Solution: Ensure the scabbard is pushed completely onto the bar. If it continues to slip, inspect for cracks or deformation. A worn scabbard may need replacement.

Specifications

Key specifications for the Stihl 36" Chainsaw Bar Scabbard Cover:

Model Number	0000-792-9179
ASIN	B07MDSPDDQ
Nominal Bar Length	36 inches
Item Weight	1 pound
Package Dimensions	36 x 5.5 x 1 inches

Warranty and Support

For specific warranty information regarding your Stihl 36" Chainsaw Bar Scabbard Cover, please refer to the documentation included with your purchase or visit the official Stihl website. Warranty terms and conditions may vary by region and retailer.
For product support, technical assistance, or to locate an authorized service dealer, please contact Stihl customer service directly or visit their official website. Always provide your product model number (0000-792-9179) and ASIN (B07MDSPDDQ) when seeking support.

© 2023 Stihl. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07MDSPDDQ

More documents and user manuals: **https://manuals.plus/**