Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SEGA MK001

Instruction Manual: Sega Project Diva Arcade Future Tone Hatsune Miku Super Premium Action Figure Dark Angel

Model: MK001 | Brand: SEGA

Introduction

This manual provides essential information for the proper setup, display, and care of your Hatsune Miku Super Premium Action Figure. Developed by Crypton Future Media, Hatsune Miku is a popular character known for her singing synthesizer application. This figure captures her iconic 'Dark Angel' design from the Project Diva Arcade Future Tone series. Please read through these instructions carefully to ensure the longevity and enjoyment of your collectible.

Setup

Your Hatsune Miku figure requires minor assembly. Follow these steps to correctly assemble and display your figure:

1. **Unboxing:** Carefully remove all components from the packaging. Ensure you have the main figure body, the display base, and any separate accessories (e.g., microphone, hair pieces if applicable).
2. **Attaching the Base:** Locate the peg(s) on the display base and the corresponding hole(s) on the figure's foot/feet. Gently align and insert the peg(s) into the hole(s). Apply even, gentle pressure until the figure is securely seated on the base. Do not force the connection.
3. **Attaching Accessories:** If your figure includes separate accessories like a microphone or specific hair sections, carefully attach them to their designated points on the figure. Refer to the product images for correct placement.
4. **Placement:** Place the assembled figure on a flat, stable surface away from direct sunlight, extreme temperatures, and high humidity to prevent damage or discoloration.



Figure fully assembled on its display base.

Operating (Display & Posing)

This action figure is designed for static display. While it is a collectible, you can adjust its pose slightly if it has articulated parts, though this specific model is primarily a fixed-pose statue. Handle with care during any adjustments.

- **Posing:** The figure is designed with a dynamic pose. Avoid attempting to bend or force parts that are not intended for articulation, as this may cause breakage.
- **Stability:** Always ensure the figure is securely attached to its base to prevent accidental falls.
- **Display Environment:** Display the figure in a stable location where it is unlikely to be knocked over. Keep it out of reach of small children and pets.



Side view of the figure, demonstrating its dynamic pose.

Maintenance

Proper maintenance will help preserve the appearance and condition of your figure.

- **Cleaning:** Dust the figure regularly with a soft, dry brush or a microfiber cloth. For stubborn dirt, lightly dampen the cloth with water (no harsh chemicals) and gently wipe the affected area. Avoid excessive moisture.
- **Storage:** If storing the figure, keep it in its original packaging or a protective container to prevent dust accumulation and physical damage. Store in a cool, dry place.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause paint fading and material degradation.
- **Temperature and Humidity:** Avoid displaying or storing the figure in areas with extreme temperature fluctuations or high humidity, which can affect the material integrity.



Close-up of the figure's face, showing intricate details that require careful cleaning.

Troubleshooting

Here are some common issues and their potential solutions:

Problem	Solution
Figure is unstable on its base.	Ensure the peg(s) are fully inserted into the corresponding hole(s) on the figure's foot/feet. Check for any debris in the hole.
Accessory does not fit.	Verify that you are attempting to attach the accessory to the correct location. Do not force it; gentle pressure should be sufficient. If it's a tight fit, ensure alignment.
Figure appears dusty or dirty.	Refer to the cleaning instructions in the Maintenance section. Use only soft, dry cloths or slightly dampened ones without harsh chemicals.

Specifications

- **Product Name:** Sega Project Diva Arcade Future Tone Hatsune Miku Super Premium Action Figure Dark Angel
- **Model Number:** MK001
- **Brand:** SEGA
- **Approximate Dimensions (L x W x H):** 5.5" x 2.7" x 9"
- **Item Weight:** 13.4 ounces
- **Officially Licensed:** Yes

© 2024 SEGA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07MJGDP1T

More documents and user manuals: **https://manuals.plus/**