ADESSO WKB-1600CB

Adesso WKB-1600CB TruForm Media Wireless Ergonomic Keyboard & Optical Mouse Combo User Manual

Your guide to setting up, operating, and maintaining your Adesso WKB-1600CB combo.

Introduction

Thank you for choosing the Adesso WKB-1600CB TruForm Media Wireless Ergonomic Keyboard & Optical Mouse Combo. This product is designed to provide a comfortable and efficient computing experience with its ergonomic split design, wireless connectivity, and multimedia features. This manual will guide you through the setup, operation, and maintenance of your new device.



Image: The Adesso WKB-1600CB ergonomic keyboard and optical mouse combo.

Package Contents

- Adesso TruForm Media Wireless Ergonomic Keyboard
- Adesso Wireless Optical Mouse
- USB Wireless Receiver

- User Manual

Setup

1. Installing Batteries

The keyboard requires 2 AAA batteries and the mouse requires 1 AA battery (not included). Locate the battery compartments on the underside of both the keyboard and the mouse. Insert the batteries, ensuring correct polarity (+/-).

2. Connecting the USB Receiver

Locate an available USB port on your computer. Plug the small USB wireless receiver into the USB port. Your computer should automatically detect and install the necessary drivers.

3. Powering On

Turn on the keyboard using the On/Off switch located on the underside. For the mouse, ensure batteries are installed; it will power on automatically when moved or a button is pressed. The devices are pre-paired with the receiver and should connect automatically.

Operating Instructions

Keyboard Features

The keyboard features a split, gently sloped design to promote a natural hand, wrist, and forearm position, reducing strain during extended use. The chiclet keycaps provide a comfortable and quiet typing experience.



Image: The ergonomic split design of the Adesso WKB-1600CB keyboard.

Multimedia Hotkeys: The keyboard includes 17 built-in hotkeys for quick access to internet and multimedia functions. These are located above the main key area and allow control over media playback, volume, and web browsing.



Image: Detailed view of the multimedia and internet hotkeys.

Mouse Features

The included optical mouse is designed for comfort and precision. It features an adjustable DPI switch, allowing you to change the cursor sensitivity to suit your needs.



Image: The Adesso wireless optical mouse.

DPI Adjustment: The mouse allows you to switch between 800, 1200, and 1600 DPI settings. Press the DPI button, usually located behind the scroll wheel, to cycle through the sensitivity levels.
Navigation Buttons: The mouse also includes two side buttons for convenient forward and backward navigation in web browsers or file explorers.



Image: Labeled diagram of the keyboard and mouse components, including multimedia hotkeys, DPI switch, and navigation buttons.

Maintenance

Cleaning

To clean your keyboard and mouse, use a soft, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid spraying liquids directly onto the devices or submerging them.

Battery Replacement

When the keyboard or mouse performance degrades, or if the low battery indicator (if present) illuminates, it is time to replace the batteries. Always use fresh batteries of the specified type (AAA for keyboard, AA for mouse).

Troubleshooting

Issue	Possible Solution
Keyboard/Mouse not responding	Ensure batteries are correctly installed and charged. Check if the keyboard's On/Off switch is in the 'On' position. Verify the USB receiver is securely plugged into a working USB port. Try plugging the receiver into a different USB port.
Intermittent connection	Move the keyboard and mouse closer to the USB receiver. Avoid placing the receiver near other wireless devices or large metal objects that may cause interference.
Mouse cursor erratic or not moving smoothly	Clean the optical sensor on the underside of the mouse. Ensure you are using the mouse on a suitable surface (not highly reflective or transparent). Try adjusting the DPI setting.

Issue	Possible Solution
Short battery life	Ensure the keyboard is turned off when not in use. Use high-quality alkaline batteries.

Specifications

Feature	Detail
Brand	ADESSO
Model Number	WKB-1600CB
Connectivity Technology	2.4 GHz RF Wireless
Operating System Compatibility	Windows 10, Windows 7, Windows 8
Keyboard Dimensions (LxWxH)	20.5 x 10.2 x 2.1 inches
Item Weight	3.05 pounds
Mouse DPI Settings	800 / 1200 / 1600 DPI
Power Source	Battery Powered (AAA for keyboard, AA for mouse)

Warranty Information

Adesso products are designed for reliability and performance. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Adesso website. Keep your purchase receipt as proof of purchase for any warranty claims.

Support

If you encounter any issues or have questions regarding your Adesso WKB-1600CB combo that are not covered in this manual, please visit the official Adesso support page or contact their customer service for assistance.
You can also visit the ADESSO Store on Amazon for more product information and resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question