Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit 764560997452

ZdalaMit Replacement Remote Control for Sceptre TVs

Brand: ZdalaMit | **Model:** 764560997452

Introduction

This manual provides instructions for the ZdalaMit Replacement Remote Control, designed for use with various Sceptre LED HDTV TV models. This remote control is pre-programmed and requires no additional setup or pairing with your television. Simply install batteries, and it is ready for immediate use.



Front view of the ZdalaMit Replacement Remote Control, showing all buttons and layout.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) AAA 1.5V alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

The remote control is now ready for use. No programming or pairing is required.



Back view of the remote control with the battery compartment open, showing where to insert two AAA batteries.

Operating Instructions

This remote control functions identically to the original Sceptre TV remote. Point the remote directly at your Sceptre TV's infrared sensor for optimal performance.

Key Functions

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** Directly select channels.
- **VOL+/-:** Adjusts the volume level.
- **CH+/-:** Changes channels up or down.
- **Mute:** Mutes or unmutes the TV audio.
- **Source:** Selects input sources (HDMI, AV, USB, etc.).
- **Menu:** Accesses the TV's main menu.
- **Guide:** Displays the electronic program guide (if available).
- **Enter:** Confirms selections in menus.
- **Arrow Buttons:** Navigate through menus and options.
- **Exit:** Exits current menu or screen.
- **CC (Closed Caption):** Toggles closed captions on or off.
- **Sleep:** Sets a sleep timer for the TV.
- **Fav (Favorite):** Accesses favorite channels list.
- **F.ADD/DEL:** Function for adding or deleting favorite channels.
- **Color Buttons (Red, Green, Yellow, Blue):** Specific functions depending on the TV model or on-screen prompts.

Compatible Sceptre TV Models

This replacement remote control is compatible with the following Sceptre LED HDTV TV models:

- E195BD-SR, E246BD-SMQK, E246BV-SR, E246BD-SR, X505BV-FSRC, X322BV-SR, U750CV-UMR
- E195BD-SRR, E195BV-SRR, X405BV-FSR, X505BV-FSR, U500CV-UMR, U505CV-UMR, X325BV-FSR
- E165BD-SS, E165WV-SS, E165WD-SS, X435BV-FSR, E168BV-SS, E168WD-SS, E168BD-SS
- U435CV-UMR, C550CV-UMR, E168WV-SS, X438BV-FSR, X322BV-SRR, C650CV-UMR, C658CV-UMR
- U515CV-UMR, E249BD-SR, U515CV-UMKR, X405BV-FSRR, X328BV-SR, X322BV-SRC, U758CV-UMR

If your specific Sceptre TV model is not listed, please consult the product listing or contact customer support to verify compatibility.

Specifications

Model Number	764560997452
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Product Dimensions	7 x 2 x 0.6 inches (17.8 x 5.1 x 1.5 cm)
Item Weight	1.41 ounces (40 grams)
Color	Black
Special Feature	Pre-Programmed, No Setup Required

Compatible Devices	Sceptre Televisions

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective range and pointing the remote directly at the TV.
- **Some buttons not working:**
  - Verify that the remote is compatible with your specific Sceptre TV model. While this remote is broadly compatible, some very specific TV functions might differ.
  - Clean the remote's surface and buttons with a soft, dry cloth to remove any dirt or debris that might be obstructing button presses.

Maintenance

- Keep the remote control dry. Avoid exposure to liquids.
- Do not expose the remote to extreme temperatures or direct sunlight.
- Clean the remote with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage.

Warranty and Support

For any questions regarding this product, including compatibility concerns or operational issues, please contact the seller or manufacturer directly. Information regarding specific warranty terms may be available from your point of purchase.

© 2023 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07MMCYTWT

More documents and user manuals: **https://manuals.plus/**