Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Steam and Go SAG806D

Steam & Go 10-in-1 Multi-Surface Steam Mop - Model SAG806D Instruction Manual

Brand: Steam and Go

Product Overview

The Steam & Go 10-in-1 Multi-Surface Steam Mop, Model SAG806D, is a versatile cleaning system designed for deep cleaning various surfaces using high-temperature steam. It functions as both a floor steam mop and a detachable handheld steamer, offering chemical-free sanitization for a cleaner and fresher home environment.

- **Deep Cleaning Power:** Utilizes high-temperature steam for professional-level cleaning without harsh chemicals, safe for homes with children and pets.
- **Dual Functionality:** Easily converts from a floor steam mop to a handheld steamer for cleaning hardwood, tile, countertops, grout, upholstery, and furniture.
- **Dual Tank Technology:** Features separate tanks for water and cleaning solutions, allowing for chemical-free sanitizing or enhanced cleaning with diluted detergent.
- **Quick Heating:** Heats up quickly to 350°F (180°C) for powerful cleaning, ready in approximately 30 seconds.
- **Continuous Steam:** Provides up to 15 minutes of continuous steam when the water tank is full.

What's Included

Your Steam & Go 10-in-1 Multi-Surface Steam Mop package includes the following components and accessories:



Image: A visual diagram labeling each part of the Steam & Go 10-in-1 Multi-Surface Steam Mop and its accessories.

1. Steamer Handle
2. Garment Steamer Attachment
3. Carpet Glider
4. Squeegee Attachment
5. Microfiber Mop Pads (2 included)
6. Metal Brush
7. Nylon Brush
8. Scraping Tool
9. Angled Nozzle
10. Straight Nozzle
11. Garment Steamer Cloth
12. Grout Brush
13. Water Filling Cup

14. Accessory Storage Bag

Setup

Follow these steps to assemble your Steam & Go Multi-Surface Steam Mop:

1. **Attach the Handle:** Insert the steamer handle into the main body until it clicks securely into place. Ensure the handle is fully extended and locked for comfortable use.
2. **Attach the Steam Head:** Align the steam head with the main body and push it firmly until it locks. For floor cleaning, attach a microfiber mop pad to the steam head using the Velcro strips.
3. **Fill the Water Tank:**
    - Locate the water tank cap on the main body.
    - Use the provided water filling cup to fill the upper tank with distilled water. Do not overfill.
    - For enhanced cleaning, fill the lower tank with a diluted cleaning solution (e.g., Steam & Go brand solution).

    Your browser does not support the video tag.

    Video: A demonstration of filling the water and detergent tanks on the Steam & Go mop.
4. **Power On:** Plug the power cord into a grounded electrical outlet. The indicator light will illuminate, signaling that the unit is heating up.
5. **Heat Up:** Allow approximately 30 seconds for the unit to reach its operating temperature. The indicator light will change or stop flashing when ready.

Operating Instructions

Your Steam & Go Multi-Surface Steam Mop is designed for efficient and effective cleaning. Always ensure the unit is properly assembled and filled before operation.

Using as a Floor Steam Mop:

1. **Select Steam Level:** Use the steam control knob on the handle to adjust the steam intensity according to the surface being cleaned. Lower settings for delicate surfaces, higher for tough stains.
2. **Begin Mopping:** Gently glide the steam mop over the floor surface. For best results, move slowly and steadily to allow the steam to penetrate and clean effectively.
3. **Detergent Spray (Optional):** If using cleaning solution, press the foot pedal on the steam head to spray detergent onto the floor as needed.
4. **Surface Compatibility:** This steam mop is suitable for sealed hardwood, tile, vinyl, and laminate floors. For carpets, attach the carpet glider.



Image: The Steam & Go mop in action on a tiled floor, demonstrating its steam cleaning capability.



Image: The Steam & Go mop with the carpet glider attachment cleaning a carpeted area.

Using as a Handheld Steamer:

1. **Detach Handheld Unit:** Press the release button to detach the handheld steamer from the main body.
2. **Attach Accessories:** Select the appropriate accessory for your cleaning task (e.g., grout brush for tile grout, garment steamer attachment for clothes, nylon brush for general scrubbing). Securely attach it to the handheld unit.
3. **Begin Steaming:** Direct the steam nozzle or attached accessory towards the surface to be cleaned. Move the unit slowly to allow steam to work effectively.



Image: The handheld steamer with a brush attachment cleaning a kitchen stovetop.



Image: The handheld steamer with a garment attachment smoothing wrinkles from a hanging shirt.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your Steam & Go Multi-Surface Steam Mop.

1. **Empty Water Tanks:** After each use, unplug the unit and allow it to cool. Empty any remaining water from both the upper and lower tanks.
2. **Clean Mop Pads:** Remove microfiber mop pads and wash them according to their care instructions (typically machine washable). Ensure they are completely dry before storing.
3. **Clean Accessories:** Rinse all accessories with water and allow them to air dry. Store them in the provided accessory bag.
4. **Descaling (Periodically):** If you notice reduced steam output or mineral buildup, descale the unit using a descaling solution or a mixture of white vinegar and water. Refer to the full instruction manual for detailed descaling procedures.
5. **Storage:** Store the steam mop in a cool, dry place. Wrap the power cord neatly around the cord wrap hooks on the handle.

Troubleshooting

If you encounter any issues with your Steam & Go Multi-Surface Steam Mop, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
No Steam Output	Water tank empty; unit not heated; mineral buildup.	Refill water tank; allow 30 seconds for heating; descale the unit.
Water Leaking	Tank cap not secured; overfilled tank; incorrect attachment.	Ensure tank cap is tight; do not overfill; check attachment is correctly fitted.
Reduced Steam Pressure	Mineral buildup; low water level.	Descale the unit; refill water tank.
Mop Pad Not Staying On	Worn Velcro; incorrect pad size.	Replace mop pad; ensure correct pad for model.

For further assistance, please contact Steam and Go customer support.

Specifications (Model: SAG806D)

Brand: Steam and Go

Model Name: SAG806D

Power Source: AC

Voltage: 110 Volts

Wattage: 1200 watts

Maximum Temperature: 350 Degrees Fahrenheit (180°C)

Item Weight: 5.2 Pounds

Tank Volume: 350 Milliliters

Item Dimensions (D x W x H): 11"D x 6"W x 50"H

Special Features: Adjustable Height, Carry Handle, Cord Wrap, Detachable Handheld Steamer, High Pressure Steam

Surface Recommendation: Floor, Floors, Tile (suitable for sealed hardwood, tile, vinyl, laminate, and carpet with glider)

Included Components: Steamer Handle, Garment Steamer Attachment, Carpet Glider, Squeegee Attachment, Microfiber Mop Pads, Metal Brush, Nylon Brush, Scraping Tool, Angled Nozzle, Straight Nozzle, Garment Steamer Cloth, Grout Brush, Water Filling Cup, Accessory Storage Bag.

Warranty and Support

The Steam & Go 10-in-1 Multi-Surface Steam Mop, Model SAG806D, typically comes with a **1-year limited warranty** from the date of purchase, covering manufacturing defects. For specific warranty details, claims, or technical support, please refer to the warranty card included in your product packaging or visit the official Steam and Go website.

For customer service inquiries, you may also contact Steam and Go directly. Contact information can usually be found on the product packaging or their official website.

Important: Always use genuine Steam and Go replacement parts and accessories to maintain warranty validity and ensure optimal performance.

© 2026 Steam and Go. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07MSFTF15

More documents and user manuals: **https://manuals.plus/**