Hatteker RFC-69001

Hatteker Cordless Hair Trimmer Pro Instruction Manual

Model: RFC-69001 | Brand: Hatteker

Introduction

This manual provides detailed instructions for the safe and effective use of your Hatteker Cordless Hair Trimmer Pro. Please read this manual thoroughly before first use and retain it for future reference. This versatile kit is designed for hair cutting and beard trimming, offering convenience and precision.



Image: Hatteker Cordless Hair Trimmer Pro with all included accessories, showcasing the main unit, charging dock, various guide combs, USB charging cable, power adapter, cleaning brush, and lubricating oil.

Safety Information

For your safety and to ensure proper operation, observe the following precautions:

- Always adjust the cutting length to 2.5mm before installing or removing the blade.
- Remove battery memory before changing the battery.
- Do not take out the battery while washing the hair clipper under water.
- Avoid submerging the hair clipper in water despite its waterproof design.
- Keep out of reach of children.
- Do not disassemble the unit beyond routine cleaning and blade replacement.

Package Contents

Verify that all items are present in your package:

- Hatteker Hair Trimmer Unit (Model: RFC-69001)
- Charging Dock
- USB Charging Cable
- Power Adapter
- Guide Combs: 3mm, 4-6mm, 7-9mm, 10-12mm, 16-18mm, 22-24mm
- Cleaning Brush
- Lubricating Oil
- Hair Comb



Image: A close-up view highlighting the key features of the Hatteker hair trimmer: ceramic cutting blade, whole body washable design, fine adjustment button for length control, LED indicating light for battery capacity, USB charging port, and internal lithium battery.

Setup

1. **Initial Charge:** Before first use, fully charge the trimmer. Connect the USB charging cable to the charging dock and the power adapter, then plug into a power outlet. Place the trimmer in the charging dock. The LCD display will show the charging progress. A full charge provides up to 2.5 hours of runtime.



Image: The Hatteker hair trimmer positioned on its charging dock, illustrating its Li-ion battery with a 90-minute full charge time and 2.5 hours of working time. Various USB charging methods are also depicted.

2. **Attaching Guide Combs:** Select the desired guide comb (e.g., 3mm, 4-6mm) based on your preferred hair length. Align the comb with the trimmer blade and push it firmly until it clicks into place.



Image: The Hatteker hair trimmer displaying its adjustable 5-degree tunable blade, which can be set from 0.5mm to 2.5mm, alongside a selection of 6 different guide combs ranging from 3mm to 24mm for various cutting lengths.

3. **Adjusting Cutting Length:** The trimmer features a fine adjustment button (rotary dial) on the body, allowing you to precisely set the cutting length from 0.5mm to 2.5mm. Rotate the dial to your desired setting. This adjustment works in conjunction with the attached guide comb.

Operating Instructions

1. **Power On/Off:** Press the power button located on the front of the trimmer to turn it on or off. The LCD display will illuminate, showing the remaining battery percentage.
2. **Using the Trimmer:**
    - For hair cutting, move the trimmer against the direction of hair growth.
    - For beard trimming, use shorter strokes and follow the contours of your face.
    - The ceramic titanium blade is designed for all hair types and stays sharp longer.



Image: A collage of four images demonstrating the practical use of the Hatteker hair trimmer for both hair and beard grooming, showing different angles and techniques.

3. **One-Key Lock:** To prevent accidental activation, press and hold the power button for a few seconds to activate the lock function. The lock symbol will appear on the LCD display. Repeat the action to unlock.

Maintenance

1. **Cleaning the Blades:** The trimmer is whole body waterproof. After each use, detach the blade by pushing it forward (ensure the length adjustment is at 2.5mm before detaching). Rinse the blades under running water to remove hair clippings. Use the provided cleaning brush for stubborn debris.



Image: A hand holding the Hatteker hair trimmer under running water, illustrating its 100% waterproof capability for easy cleaning.

2. **Lubricating the Blades:** After cleaning and drying, apply a small drop of the provided lubricating oil to the blades. Run the trimmer for a few seconds to distribute the oil evenly. This helps maintain blade sharpness and smooth operation.
3. **Storage:** Store the trimmer and all accessories in a dry, cool place.

Troubleshooting

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is low or depleted.	Charge the trimmer fully using the provided charger.
Trimmer is not cutting effectively.	Blades are dull or clogged with hair.	Clean the blades thoroughly and apply lubricating oil. Ensure the blade is properly attached.
Trimmer makes unusual noise.	Blades may need lubrication or are misaligned.	Lubricate the blades. Check if the blade is correctly attached.
LCD display is locked.	One-Key Lock feature is activated.	Press and hold the power button for a few seconds to unlock.

Specifications

- **Model Number:** RFC-69001
- **Blade Material:** Ceramic Titanium
- **Power Source:** Battery Powered (1 A battery included)
- **Battery Type:** Rechargeable Lithium-ion
- **Run Time:** Up to 2.5 hours

- **Charging:** USB Quick-Charge
- **Waterproof:** Whole Body Waterproof
- **Display:** LCD (Battery capacity, Lock Symbol)
- **Product Dimensions:** 4.13 x 10.12 x 11.69 inches; 1.15 Pounds
- **Manufacturer:** Hatteker
- **Country of Origin:** China

Warranty and Support

This product is sold by Hatteker and fulfilled by Amazon. For any issues or support, please contact the seller directly through your Amazon order history. The product typically comes with a 30-day return policy for refund or replacement, subject to Amazon's terms and conditions.
For further assistance, please refer to the official Hatteker website or contact their customer support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question