Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Keurig K-Mini

Keurig K-Mini Single Serve Coffee Maker Instruction Manual

Model: K-Mini | Brand: Keurig

Introduction

The Keurig K-Mini single serve coffee maker in Studio Gray offers a compact design, less than 5 inches wide, making it suitable for various spaces. This brewer is designed for ease of use, allowing you to prepare fresh, delicious coffee in minutes. It accommodates K-Cup pods for brew sizes between 6-12oz and features a single-cup reservoir and cord storage for convenience.

Setup

1. **Unboxing:** Carefully remove all packaging materials from the coffee maker.
2. **Placement:** Place the brewer on a stable, level surface.
3. **Power Connection:** Plug the brewer into a grounded outlet. The cord storage feature allows for tidy countertops.



Image: Rear view of the Keurig K-Mini showing the integrated cord storage compartment.

4. **Initial Rinse:**
   - Lift the handle to open the K-Cup pod holder.
   - Pour fresh water into the reservoir, filling it to the MAX line.
   - Place a large mug (at least 12oz) on the drip tray.
   - Lower the handle and press the brew button. Do not insert a K-Cup pod.
   - Discard the hot water. The brewer is now ready for use.



Image: Side view of the Keurig K-Mini with the water reservoir lid open, showing water being poured in.

Operating Instructions

1. **Add Water:** Pour fresh water into the single-serve reservoir. Fill between the MIN (6oz) and MAX (12oz) lines, corresponding to your desired brew size.
2. **Insert K-Cup Pod:** Lift the handle to open the K-Cup pod holder. Place a K-Cup pod into the holder. Lower the handle completely to puncture the pod.



Image: Top view of the Keurig K-Mini with the handle lifted and a K-Cup pod placed in the holder.

3. **Place Mug:** Place a mug on the drip tray. If using a travel mug, remove the drip tray to accommodate taller mugs (up to 7.0 inches).



Image: Front view of the Keurig K-Mini with the drip tray removed to fit a tall travel mug.

4. **Brew:** Press the illuminated brew button. The button will flash while brewing and remain solid when complete.

Maintenance

Cleaning the Drip Tray

- The drip tray can be easily removed for cleaning. Simply slide it out from the base of the brewer.

- Wash the drip tray and its cover with warm, soapy water. Rinse thoroughly and dry before reattaching.

Descaling

Regular descaling helps maintain the brewer's performance and extends its lifespan. The frequency depends on water hardness. Refer to the full Keurig descaling instructions for your specific model.

- The brewer may indicate when descaling is needed (e.g., a descaling light).
- Use a Keurig descaling solution or a vinegar solution as per manufacturer guidelines.
- Perform several rinse cycles with fresh water after descaling to remove any residual solution.

Troubleshooting

Issue	Possible Cause	Solution
Brewer not turning on	Not plugged in, power outage, faulty outlet.	Ensure brewer is securely plugged into a working, grounded outlet. Check circuit breaker.
No water dispensing / Brew button not lighting up	Insufficient water in reservoir, handle not fully lowered.	Fill reservoir with fresh water. Ensure handle is firmly lowered.
Coffee tastes weak or watery	Too much water for pod size, K-Cup pod not properly punctured.	Use less water for a stronger brew. Ensure K-Cup pod is correctly seated and punctured.
Coffee grounds in cup	K-Cup pod puncture needle clogged or damaged.	Clean the K-Cup pod holder and exit needle. Refer to the full manual for detailed cleaning instructions.
Brewer is loud during operation	Normal operating noise, air in water lines.	Some noise is normal. If excessively loud, perform a water-only brew cycle to clear air.

Specifications

- **Brand:** Keurig
- **Model Name:** K-Mini Coffee Maker
- **Color:** Studio Gray
- **Product Dimensions:** 11.3"D x 4.5"W x 12.1"H
- **Item Weight:** 4.6 pounds
- **Special Features:** Removable Drip Tray, Automatic Shut-Off, Portable, Removable Tank, Reusable Filter Compatible
- **Coffee Maker Type:** Drip Coffee Machine
- **Coffee Input Type:** K-Cup Pods, Ground Coffee (with My K-Cup Universal Reusable Coffee Filter, sold separately)
- **Voltage:** 120 Volts
- **Brew Sizes:** 6-12 oz



Image: Diagram illustrating the dimensions of the Keurig K-Mini coffee maker.

Warranty and Support

For warranty information, product registration, or technical support, please visit the official Keurig website or contact Keurig customer service. Keep your purchase receipt for warranty claims.

- **Online Support:** Visit www.keurig.com
- **Customer Service:** Refer to your product packaging or the official website for contact numbers.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07N3G8GRY

More documents and user manuals: **https://manuals.plus/**