NIXON A105

Nixon Sentry Leather Watch User Manual

Model: A105 | Brand: NIXON

Product Overview

The Nixon Sentry Leather A105 watch combines classic aesthetics with modern design. Featuring a timeless 42mm case and subtle hour markers, this watch is built for durability and style. It is equipped with a reliable Japanese quartz movement and offers water resistance up to 100 meters.



Image: Front view of the Nixon Sentry Leather A105 watch, showcasing its dark green dial, silver-tone case, and brown leather strap. The dial features minimalist hour markers and a date/day display at the 3 o'clock position.

Setup Guide

Before wearing your new Nixon Sentry Leather watch, you may need to set the time and date. Follow these steps for initial setup:

1. **Unscrew the Crown:** The crown (the knob on the side of the watch) is a triple gasket screw-down type for water resistance. Gently unscrew it counter-clockwise until it pops out to the first position.
2. **Set the Date and Day:** Pull the crown out to the second position. Turn the crown clockwise or counter-clockwise to adjust the date and day. Note that the day changes between two languages.
3. **Set the Time:** Pull the crown out to the third and final position. Turn the crown to set the correct time. Ensure you set the AM/PM correctly, as the date/day will change around midnight.
4. **Secure the Crown:** Once the time and date are set, push the crown back in and screw it clockwise tightly against the case to ensure water resistance.



Image: Side profile of the Nixon Sentry Leather A105 watch, highlighting the textured crown used for setting the time and date. The robust stainless steel case is also visible.

Operating Instructions

Your Nixon Sentry Leather watch is designed for daily wear and features a reliable 3-hand Japanese quartz movement with day and date functions. Once set, the watch operates continuously.

- **Timekeeping:** The watch displays hours, minutes, and seconds via three hands. The quartz movement ensures accurate timekeeping.
- **Day and Date Display:** The day and date windows automatically advance at midnight. If the watch stops, you may need to reset these functions as described in the Setup Guide.
- **Water Resistance:** This watch is water resistant up to 100 meters (10 ATM). This makes it suitable for showering, swimming, and snorkeling. However, it is not recommended for diving. Always ensure the crown is fully screwed in before exposing the watch to water. Avoid operating the crown while the watch is wet.

Care and Maintenance

Proper care will extend the life and maintain the appearance of your Nixon Sentry Leather watch.

- **Cleaning the Case:** Wipe the watch case and crystal with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, but ensure the crown is tightly closed. Rinse thoroughly with clean water and dry immediately.
- **Leather Strap Care:** The full-grain leather strap is durable but can be affected by moisture, sweat, and direct sunlight. Avoid prolonged exposure to water. If the strap gets wet, dry it gently with a soft cloth and allow it to air dry completely away from direct heat. Condition the leather periodically with a suitable leather conditioner to prevent drying and cracking.
- **Battery Replacement:** The watch is powered by a quartz battery. When the watch stops, it likely needs a battery replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is properly maintained.
- **Storage:** When not in use, store your watch in a cool, dry place, away from direct sunlight and extreme temperatures.



Image: The Nixon Sentry Leather A105 watch worn on a wrist, demonstrating its fit and appearance during use. This image highlights the watch's design in a real-world context.

Troubleshooting

If you encounter issues with your Nixon Sentry Leather watch, consider the following common problems and solutions:

- **Watch Not Running:**
  - Check if the crown is fully pushed in and screwed down. The watch will not run if the crown is pulled out.
  - The battery may be depleted. A quartz watch typically requires a battery replacement every 2-3 years.
- **Date/Day Not Changing:**
  - Ensure the time is set correctly, especially the AM/PM cycle. The date/day changes around midnight.
  - If the watch has stopped and restarted, you may need to manually advance the date/day as per the Setup Guide.
- **Condensation Under Crystal:**
  - This indicates a breach in the water resistance. Ensure the crown was fully screwed down when exposed to water.
  - Seek professional service immediately to prevent damage to the movement.

For issues not covered here, please contact Nixon customer support or a certified watch repair center.

Technical Specifications

Feature	Detail
Model Number	A105
Movement	3-hand Japanese Quartz (Miyota) with Day and Date
Case Diameter	42 mm
Case Material	Custom Solid Stainless Steel
Crystal	Hardened Mineral Crystal
Crown	Triple Gasket Crown with Enamel Fill
Caseback	Stainless Steel Screw Down Caseback
Water Resistance	100 meters / 10 ATM
Strap Material	23 mm Full Grain Leather
Clasp	Stainless Steel Buckle
Shipping Dimensions	12.7 x 12.19 x 8.38 cm
Item Weight	181 grams



Image: The back of the Nixon Sentry Leather A105 watch, featuring engraved details such as 'NIXON', 'NEVER BE LATE', 'THE SENTRY LEATHER', '100M STAINLESS STEEL', 'JAPAN MOVEMENT', and 'H15-S'.

Warranty and Support

Nixon watches are manufactured to the highest quality standards. This product comes with a manufacturer's warranty that covers defects in materials and workmanship under normal use. The specific terms and duration of the warranty may vary by region and purchase location. Please refer to the warranty card included with your watch or visit the official Nixon website for detailed warranty information.

For technical support, service, or warranty claims, please contact Nixon customer service through their official website or authorized service centers. Ensure you have your proof of purchase and the watch's model number (A105) ready when contacting support.

Important: Any unauthorized repair or alteration to the watch may void the warranty.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question