Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ozark Trail FT-SW250

Ozark Trail FT-SW250 LED Flashlight User Manual

Model: FT-SW250 (567267589)

1. Introduction

Thank you for choosing the Ozark Trail FT-SW250 LED Flashlight. This durable and versatile flashlight is designed to provide reliable illumination for various outdoor and indoor activities. With its two brightness settings, adjustable angle, and foldable design, it is an essential tool for camping, emergencies, and everyday use. Please read this manual carefully to ensure proper use and maintenance of your flashlight.

2. Safety Information

- Do not shine the flashlight directly into eyes, as this may cause temporary vision impairment.
- Keep out of reach of children.
- Do not attempt to disassemble or modify the flashlight. This will void the warranty and may cause damage or injury.
- Ensure batteries are inserted with correct polarity (+/-). Incorrect insertion can cause damage to the device or battery.
- Remove batteries if the flashlight will not be used for an extended period to prevent leakage.
- Dispose of used batteries according to local regulations.

3. Package Contents

Please check the package for the following items:

- Ozark Trail FT-SW250 LED Flashlight
- Battery (pre-installed or separate, depending on packaging)

4. Product Features



Ozark Trail FT-SW250 LED Flashlight Overview:
This image displays the Ozark Trail FT-SW250 LED Flashlight, showcasing its robust design. The flashlight features a dark gray and black body, with a textured grip area and a prominent power button near the head. The head of the flashlight has a distinct, ruggedized design, and the main body includes a textured section, likely for enhanced grip or heat dissipation. The overall appearance suggests a durable and functional tool.

- **High Brightness:** Up to 250 lumens of powerful LED light.
- **Dual Light Settings:** Choose between 250 lumens for maximum illumination or 100 lumens for extended battery life.
- **Adjustable Angle & Rotating Stand:** Direct light precisely where needed with the flexible design.
- **Foldable Design:** Compact and easy to store or transport.
- **Durable Construction:** Made from aluminum for long-lasting performance.
- **Efficient LED Bulbs:** Provides consistent light output with long lifespan and low heat generation.

5. Setup and Battery Installation

Your Ozark Trail FT-SW250 LED Flashlight is powered by a battery (included). Follow these steps to install or replace the battery:

1. Locate the battery compartment cap, typically at the rear or side of the flashlight.
2. Unscrew or open the battery compartment.
3. Insert the battery(ies) according to the polarity indicators (+ and -) inside the compartment.
4. Securely close the battery compartment cap.

Note: Ensure the battery is fully charged before first use for optimal performance.

6. Operation

Operating your flashlight is simple:

- **Power On/Off:** Press the power button once to turn the flashlight on. Press it again to turn it off.
- **Change Brightness Settings:** While the flashlight is on, press the power button repeatedly to cycle through the

available brightness modes (250 lumens, 100 lumens, Off).

- **Adjusting Angle:** The flashlight features an adjustable head or body section. Gently pivot or rotate the designated part to change the direction of the light beam.
- **Using the Rotating Stand:** If equipped, extend the integrated stand and rotate it to position the flashlight for hands-free operation.

7. Maintenance and Care

To ensure the longevity and optimal performance of your flashlight, follow these maintenance tips:

- **Cleaning:** Wipe the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Care:** If the flashlight will not be used for an extended period (e.g., several months), remove the battery to prevent potential leakage and corrosion.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** While durable, avoid dropping the flashlight from significant heights to prevent internal damage.

8. Troubleshooting

If you encounter issues with your Ozark Trail FT-SW250 LED Flashlight, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery is dead or incorrectly inserted.	Replace battery or check polarity.
Light is dim.	Battery is low.	Replace battery.
Light flickers.	Loose battery connection or low battery.	Ensure battery is secure. Replace battery if needed.

9. Specifications

Feature	Specification
Model Number	567267589 (FT-SW250)
Brightness	250 Lumens (High), 100 Lumens (Low)
Light Source	LED
Power Source	Battery Powered
Material	Aluminum
Color	Black, Gray
Dimensions (L x W x H)	8 x 2.5 x 2.5 inches
Item Weight	7 ounces

Feature	Specification

10. Warranty and Support

Ozark Trail products are manufactured to high-quality standards. For specific warranty information or technical support, please refer to the warranty card included with your purchase or visit the official Ozark Trail website. You may also contact customer service using the contact information provided on the product packaging.
Please retain your proof of purchase for any warranty claims.

© 2023 Ozark Trail. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NBSSTKG

More documents and user manuals: **https://manuals.plus/**