KEXIN USB 3.0 Flash Drive 64 GB 10 Pack

KEXIN USB 3.0 Flash Drive 64 GB 10 Pack Instruction Manual

Model: USB 3.0 Flash Drive 64 GB 10 Pack

1. Product Overview

The KEXIN USB 3.0 Flash Drive 64 GB 10 Pack provides portable data storage. These drives are designed for transferring and storing various digital files, including documents, images, videos, and music. Each drive features a 360° rotating metal cover to protect the USB connector.



Image 1.1: KEXIN USB 3.0 Flash Drive 64 GB 10 Pack. This image displays ten individual KEXIN USB 3.0 flash drives, each with a black body and a silver rotating metal cover. One drive is shown in an open position, highlighting the blue USB 3.0 connector.

2. Setup and Initial Use

The KEXIN USB 3.0 Flash Drives are designed for plug-and-play operation, requiring no special software installation for basic functionality.

2.1 Connecting the Flash Drive

1. Locate an available USB port on your computer or compatible device.
2. Rotate the metal cover of the flash drive to expose the USB connector.
3. Insert the USB connector firmly into the USB port. The drive should be recognized automatically by your operating

system.



Image 2.1: Flash Drive Connected to a Laptop. This image shows a KEXIN USB 3.0 flash drive plugged into the side USB port of a silver laptop, demonstrating the ease of connection.

2.2 LED Indicator

The flash drive is equipped with an LED indicator that illuminates during data transfer, confirming active operation.

Your browser does not support the video tag.

Video 2.1: KEXIN USB Flash Drive Features. This video demonstrates the KEXIN USB 3.0 flash drive's 360-degree swivel design, keychain compatibility, USB 3.0 interface, Grade A+ chip, LED indicator during data transfer, and its use across various devices like PCs, cars, and laptops for office, meeting, home, and entertainment purposes.

3. Operating Instructions

3.1 Data Transfer

Once connected, the flash drive will appear as a removable storage device in your computer's file explorer (Windows) or Finder (Mac OS). You can transfer files by dragging and dropping them to and from the drive, or by using copy-paste functions.

3.2 Compatibility

The KEXIN USB 3.0 Flash Drives are compatible with a wide range of devices and operating systems, including:

- Windows 7 / 8 / 10 / Vista / XP / 2000 / ME / NT
- Linux
- Mac OS
- Laptops, Desktop Computers, Tablets
- TVs, Gaming Consoles, Car Audio Systems



Image 3.1: Device Compatibility. This image illustrates the KEXIN USB 3.0 flash drive's compatibility with various devices, including desktops, notebooks, audio systems, and televisions, represented by icons.

Your browser does not support the video tag.

Video 3.1: KEXIN USB 3.0 Flash Drive Overview. This video highlights the KEXIN USB 3.0 flash drive's features such as high quality, durability, sensitivity, and fast transmission. It shows the drive being used for various applications like storing files, and its compatibility with

different devices and environments.

4. Maintenance and Care

- **Safe Removal:** Always use the "Safely Remove Hardware" option (Windows) or drag the drive to the Trash (Mac OS) before physically disconnecting the flash drive to prevent data corruption.
- **Physical Protection:** The 360° rotating metal cover helps protect the USB connector from dust and physical damage when not in use.
- **Storage Conditions:** Store the flash drives in a cool, dry place. Avoid extreme temperatures and direct sunlight.
- **Cleaning:** If necessary, gently wipe the exterior of the flash drive with a soft, dry cloth. Do not use liquid cleaners.



Image 4.1: 360° Rotation Feature. This image demonstrates the 360-degree rotating design of the KEXIN USB 3.0 flash drive, indicating how the metal cover swivels to protect the USB connector.

5. Troubleshooting

Problem	Possible Cause	Solution
Drive not recognized by computer.	Loose connection. Faulty USB port. Driver issue (less common for plug-and-play). Drive format incompatibility.	Ensure the drive is fully inserted into the USB port. Try a different USB port on your computer. Try the drive on another computer to rule out a device-specific issue. Check Device Manager (Windows) or System Information (Mac) to see if the drive is detected. If the drive is new and not recognized, it might need to be formatted. Refer to your operating system's documentation for formatting instructions. **Note: Formatting will erase all data on the drive.**
Slow data transfer speeds.	Connected to a USB 2.0 port instead of USB 3.0. Transferring many small files. System resource limitations.	Ensure the drive is connected to a blue-colored USB 3.0 port for optimal speed. Transferring large files generally results in faster overall speeds than many small files. Close unnecessary applications to free up system resources.
Data corruption or errors.	Improper removal of the drive. Physical damage.	Always use the "Safely Remove Hardware" option before disconnecting. If data corruption persists, the drive may be faulty.

6. Specifications

Feature	Detail
Brand	KEXIN
Memory Storage Capacity	64 GB (per drive)
Hardware Interface	USB 3.0
Read Speed	Up to 100 MB/s (typical, actual speeds may vary)
Write Speed	800 (Note: This value lacks units and may represent a specific internal metric or a peak value. Actual write speeds can vary.)
Connectivity Technology	USB
Color	Black
Product Dimensions (LxWxH)	2.2 x 0.8 x 0.4 inches
Item Weight	4.2 ounces (for the 10-pack)
Operating System Compatibility	Windows 7/8/10/Vista/XP/2000/ME/NT, Linux, Mac OS
Special Feature	360° swivel design, LED indicator

Feature	Detail

Note on Write Speed: The provided write speed value of "800" lacks units and may represent a specific internal metric or a peak value. Actual write speeds can vary based on file type, system configuration, and other factors.

7. Warranty and Support

KEXIN products are designed for reliability. For support inquiries or to report issues, please refer to the contact information provided with your purchase or visit the official KEXIN website.

7.1 Data Recovery Plans

Optional data recovery plans are available for purchase separately to protect your stored data. These plans are offered by third-party providers and are not included with the standard product purchase.

- 3-year Photo and Data Recovery Plan
- 2-year Photo and Data Recovery Plan

For details on these plans, please consult the respective plan providers or the product listing where they are offered.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question