Mediacom MCI 3300 Pro

MediaCom MCI 3300 Pro DVD Karaoke Player User Manual

Model: MCI 3300 Pro | Brand: Mediacom

Product Overview

The MediaCom MCI 3300 Pro is a versatile DVD Karaoke Player designed for home entertainment. It features a multi-function DVD player with USB and SD card slots, enabling playback from various media. The system includes two wireless microphones for enhanced vocal performance and a song recording function via the USB interface. It supports a wide range of song genres and offers user-friendly song selection and search capabilities.



Image: The MediaCom MCI 3300 Pro DVD Karaoke Player, featuring the main unit, two wireless microphones, and the UHF receiver.

Package Contents

Verify that all items are present in the package:

- MediaCom MCI 3300 Pro DVD Karaoke Player Unit
- 2 x Wireless Microphones
- UHF Wireless Microphone Receiver
- Power Adapter
- Audio/Video Cables
- User Manual (this document)

Setup Guide

1. Unpacking and Placement

Carefully remove all components from the packaging. Place the karaoke player unit on a stable, flat surface with adequate ventilation. Ensure there is enough space around the unit for proper airflow. Avoid placing it near heat sources or in direct sunlight.

2. Connecting the Player

1. **Power Connection:** Connect the power adapter to the DC IN port on the rear of the karaoke player, then plug the adapter into a standard electrical outlet.
2. **Audio/Video Connection:** Connect the audio/video output ports (RCA or HDMI, depending on your model and TV) on the karaoke player to the corresponding input ports on your television or audio receiver. Ensure correct color matching for RCA cables (Red for Right Audio, White for Left Audio, Yellow for Video).
3. **Microphone Receiver Connection:** Connect the UHF wireless microphone receiver to the dedicated microphone input jacks on the karaoke player unit. Ensure the receiver is powered on and its antennas are extended for optimal signal reception.



Image: Close-up of the MediaCom MCI 3300 Pro DVD Karaoke Player, highlighting the front panel controls and input ports.

Operating Instructions

1. Basic Playback

1. **Power On:** Press the POWER button on the front panel or remote control to turn on the unit.
2. **Insert Disc:** Gently insert a DVD karaoke disc into the disc tray. The player will automatically load and display the disc menu.
3. **USB/SD Playback:** Insert a USB drive or SD card into the respective slot. Use the INPUT/MODE button to select USB or SD mode. Navigate through files using the remote control.

2. Microphone Usage

1. **Powering Microphones:** Ensure batteries are inserted correctly into the wireless microphones and power them on.
2. **Adjusting Volume:** Use the 'MIC VOL' knob on the player's front panel or the remote control to adjust the microphone volume.
3. **Echo Control:** Use the 'ECHO' knob to add or reduce the echo effect for vocals.

3. Song Selection and Search

The system offers user-friendly song selection. You can search for songs by:

- **Artist:** Search for songs by your favorite artists.
- **Language:** Filter songs by language.
- **Song Title:** Enter keywords from the song title.
- **Songbook:** Refer to the provided songbook for direct song codes.

4. Recording Function

The MCI 3300 Pro allows you to record your vocal performances. To record:

1. **Insert USB Drive:** Ensure a USB flash drive is inserted into the USB port.
2. **Start Recording:** While singing, press the 'RECORD' button on the remote control or front panel.
3. **Stop Recording:** Press the 'STOP' button to end the recording. Your performance will be saved to the USB drive.

Maintenance

1. Cleaning the Unit

To maintain the appearance and functionality of your karaoke player:

- Wipe the exterior surfaces with a soft, dry cloth.
- For stubborn marks, slightly dampen the cloth with water and a mild detergent, then wipe dry immediately.
- Do not use abrasive cleaners, solvents, or chemical sprays.

2. Disc Care

Handle discs by their edges to avoid fingerprints. Clean discs with a soft, lint-free cloth, wiping from the center outwards. Store discs in their cases to prevent scratches and dust accumulation.

3. Storage

If storing the unit for an extended period, disconnect it from power, remove batteries from microphones and remote

control, and store in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Refer to the table below for common issues and their solutions:

Problem	Possible Solution
No power	Check if the power adapter is securely connected to the unit and the electrical outlet. Ensure the outlet is functional.
No sound output	Verify audio cables are correctly connected to the TV/receiver. Check the volume levels on the karaoke player and your TV/audio system. Ensure the correct input source is selected on your TV/receiver.
No microphone sound	Ensure microphones are powered on and have fresh batteries. Check if the wireless receiver is connected and powered. Adjust microphone volume on the player.
Disc not playing/reading	Ensure the disc is clean and free of scratches. Verify the disc format is supported (DVD). Try a different disc.
USB/SD card not recognized	Ensure the USB drive/SD card is properly inserted. Check if the file format on the drive/card is supported by the player. Try a different USB drive/SD card.

Specifications

- **Model:** MCI 3300 Pro
- **Brand:** Mediacom
- **Media Format:** DVD
- **Connectivity:** USB Port, SD Card Slot
- **Microphones:** 2 Wireless Microphones included
- **Special Features:** Song Recording Function, Echo Control, User-friendly Song Selection
- **Compatible Devices:** Smartphones, Tablets, Laptops, PCs (for media playback via USB/SD)
- **Power Source:** Battery Powered (for microphones), AC Power (for main unit)
- **Item Weight:** Approximately 5.1 Kilograms
- **Package Dimensions:** Approximately 50.2 x 34.4 x 15.8 cm

Warranty and Support

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including warranty period and coverage details. For technical support, service, or inquiries regarding your MediaCom MCI 3300 Pro DVD Karaoke Player, please contact Mediacom customer service through their official website or the contact information provided in your product documentation.

For the most up-to-date support information, please visit the official Mediacom website or consult your purchase receipt.

© 2024 Mediacom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question