Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Victrola VTA-75

Victrola Liberty 5-in-1 Bluetooth Record Player User Manual

Model: VTA-75

Your guide to setup, operation, and maintenance.

1. Introduction

Thank you for purchasing the Victrola Liberty 5-in-1 Bluetooth Record Player. This versatile audio system combines vintage aesthetics with modern functionality, allowing you to enjoy your favorite music through vinyl records, Bluetooth streaming, FM radio, and USB playback. This manual provides essential information for safe operation, setup, and maintenance of your new device. Please read it thoroughly before use and retain it for future reference.

2. Important Safety Information

- **Power Source:** Use only the specified power adapter. Ensure the voltage matches your local power supply.
- **Water and Moisture:** Do not expose the unit to rain, moisture, or dripping/splashing liquids. Keep away from water sources.
- **Ventilation:** Ensure adequate ventilation. Do not block any ventilation openings. Maintain a minimum distance around the unit for proper airflow.
- **Heat:** Do not place near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the unit from the wall outlet before cleaning. Use a soft, dry cloth only. Do not use liquid cleaners or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Placement:** Place the unit on a stable, flat surface. Avoid placing it in direct sunlight or areas with excessive dust, vibration, or mechanical shock.
- **Stylus Protection:** Always replace the stylus protective cap when the unit is not in use to prevent damage.

3. Package Contents

Verify that all items listed below are included in your package:

- Victrola Liberty 5-in-1 Bluetooth Record Player (Main Unit)
- Detachable Stand Legs (4)

- 45 RPM Adapter
- Power Adapter
- User Manual (this document)

4. Product Overview

Familiarize yourself with the various components of your Victrola Liberty record player.

Front and Top View



Figure 4.1: Front view of the Victrola Liberty Record Player with the lid open, showcasing the turntable, control panel, and integrated speaker. The unit is mounted on its four detachable legs.

1. **Dust Cover/Lid:** Protects the turntable when not in use.
2. **Turntable Platter:** Where records are placed for playback.

3. **Spindle:** Holds the record in place on the platter.
4. **45 RPM Adapter:** Used for playing 7-inch records with large center holes.
5. **Tonearm:** Holds the stylus and tracks the record grooves.
6. **Stylus (Needle):** The component that reads the record grooves.
7. **Cue Lever:** Raises and lowers the tonearm gently.
8. **Speed Selector:** Allows selection of 33 1/3, 45, or 78 RPM playback speeds.
9. **Function Knob:** Selects input mode (Phono, Bluetooth IN, FM, USB, AUX).
10. **Volume Knob:** Adjusts the master volume.
11. **Control Buttons:** Play/Pause, Skip Forward/Backward (for USB/Bluetooth), FM Scan.
12. **USB Port:** For USB drive playback and recording.
13. **Built-in Stereo Speakers:** Integrated audio output.

Rear View



Figure 4.2: Rear view of the Victrola Liberty Record Player, highlighting the RCA Line Out ports and the FM antenna connection. The unit is shown on its stand.

1. **RCA Line Out:** Connects to external amplifiers or powered speakers.
2. **FM Antenna:** For improved FM radio reception.
3. **Power Input:** Connects to the provided power adapter.
4. **AUX Input:** 3.5mm jack for connecting external audio devices.
5. **Headphone Jack:** For private listening.

5. Setup

5.1 Unpacking and Placement

1. Carefully remove the unit from its packaging.
2. Place the unit on a stable, level surface. Ensure there is enough space around the unit for ventilation.
3. If using the stand, attach the four legs securely to the bottom of the main unit. Ensure they are tightened properly for stability.
4. Remove any protective packaging materials from the turntable platter and tonearm.



Figure 5.1: Dimensions of the Victrola Liberty Record Player, illustrating its size for both tabletop and stand configurations. The unit measures approximately 17.1 inches wide, 15.7 inches deep, and 11 inches high (tabletop) or 27.6 inches high (on stand).

5.2 Power Connection

Connect the provided power adapter to the DC IN jack on the rear of the unit, then plug the adapter into a wall outlet.

5.3 Initial Tonearm Setup

Before playing a record, ensure the tonearm is unlocked from its rest. Remove the clear plastic stylus protector from the needle by gently pulling it forward.

6. Operating Instructions

6.1 Power On/Off

Rotate the **Volume Knob** clockwise to turn the unit ON. Rotate it counter-clockwise until it clicks to turn the unit OFF.

6.2 Playing Records (Phono Mode)

1. Rotate the **Function Knob** to select "PHONO" mode.
2. Lift the dust cover.
3. Place a record on the turntable platter. If playing a 7-inch record, place the 45 RPM adapter on the spindle first.
4. Select the appropriate speed (33 1/3, 45, or 78 RPM) using the **Speed Selector** switch.
5. Gently lift the tonearm using the **Cue Lever**.
6. Move the tonearm over the desired starting point of the record.
7. Lower the tonearm slowly onto the record using the **Cue Lever**. The record will begin to play.
8. Adjust the volume using the **Volume Knob**.
9. When the record finishes, the turntable will automatically stop spinning (Auto-Stop feature). Lift the tonearm, return it to its rest, and engage the tonearm lock.

6.3 Bluetooth Input (Streaming to the Player)

1. Rotate the **Function Knob** to select "BLUETOOTH IN" mode. The Bluetooth indicator light will flash.
2. Enable Bluetooth on your external device (e.g., smartphone, tablet) and search for "Victrola Liberty".
3. Select "Victrola Liberty" to pair. Once paired, the Bluetooth indicator light will stop flashing and remain solid.
4. You can now play music from your device through the record player's speakers. Use your device's controls for track selection and the record player's **Volume Knob** for volume adjustment.

6.4 Bluetooth Output (VinylStream - Streaming from the Player)

The Victrola Liberty can stream audio from Phono, AUX, or USB modes to external Bluetooth speakers or headphones.

1. Ensure your external Bluetooth speaker/headphones are in pairing mode.
2. Select the desired input mode on the Victrola Liberty (PHONO, AUX, or USB).
3. Press and hold the **Bluetooth OUT** button (if available, or refer to specific button for Bluetooth output) on the record player. The Bluetooth OUT indicator will flash.
4. The record player will search for and connect to the nearest available Bluetooth audio device. Once connected, the indicator will become solid.
5. Audio from the selected source will now play through your external Bluetooth device.

6.5 FM Radio Operation

1. Rotate the **Function Knob** to select "FM" mode.
2. Extend the FM antenna on the rear of the unit for optimal reception.
3. Press the **SCAN** button to automatically scan and tune to available FM stations.
4. Use the **Skip Forward**/**Backward** buttons to manually tune to specific frequencies or navigate between scanned stations.

5. Adjust the volume using the **Volume Knob**.

6.6 USB Playback and Recording

1. **USB Playback:**
    - Insert a USB flash drive into the **USB Port**.
    - Rotate the **Function Knob** to select "USB" mode.
    - The unit will automatically begin playing compatible audio files (MP3, WAV).
    - Use the **Play/Pause** and **Skip Forward/Backward** buttons to control playback.
2. **USB Recording (from Vinyl):**
    - Insert a USB flash drive into the **USB Port**.
    - Select "PHONO" mode and begin playing a record as described in section 6.2.
    - Press the **RECORD** button (often indicated by a microphone icon or "REC"). The recording indicator will illuminate.
    - To stop recording, press the **RECORD** button again. The recorded audio file will be saved to the USB drive.

6.7 Auxiliary Input (AUX IN)

Connect an external audio device (e.g., MP3 player, smartphone) to the **AUX IN** jack using a 3.5mm audio cable (not included). Rotate the **Function Knob** to select "AUX" mode. Audio from the connected device will play through the record player's speakers.

6.8 RCA Line Output

To connect your Victrola Liberty to an external amplifier or powered speakers, use an RCA cable (not included) to connect the **RCA Line Out** ports on the rear of the unit to the corresponding input on your external audio system.

7. Maintenance

7.1 Cleaning the Unit

- Always unplug the unit from the power outlet before cleaning.
- Use a soft, dry cloth to wipe the exterior surfaces. Do not use abrasive cleaners, waxes, or solvents.
- Gently dust the turntable platter and tonearm with a soft brush or lint-free cloth.

7.2 Stylus Care

- The stylus is a delicate component. Handle it with extreme care.
- Avoid touching the stylus tip with your fingers.
- Clean the stylus periodically using a soft brush, brushing gently from back to front.
- Replace the stylus when you notice a degradation in sound quality or visible wear. Replacement styli are available from Victrola or authorized dealers.

7.3 Record Care

- Handle records by their edges to avoid touching the grooves.
- Store records vertically in their sleeves in a cool, dry place.
- Clean records regularly with a dedicated record cleaning brush or solution to remove dust and static.

8. Troubleshooting

Problem	Possible Cause	Solution
No power	Power adapter not connected; outlet not active.	Ensure power adapter is securely connected to the unit and a working wall outlet.
No sound from speakers	Volume too low; incorrect function mode; external speakers connected via Bluetooth OUT.	Increase volume. Select correct function mode. If using Bluetooth OUT, sound will play from external device.
Record skipping	Dirty or scratched record; dirty or worn stylus; unit not level.	Clean record. Clean or replace stylus. Ensure unit is on a stable, level surface.
Bluetooth not pairing	Device too far; incorrect mode; device already paired to another unit.	Ensure device is within range. Select "BLUETOOTH IN" mode. Disconnect from other Bluetooth devices.
Poor FM reception	Antenna not extended; weak signal.	Fully extend the FM antenna. Try repositioning the unit or antenna.
USB playback issues	Incompatible file format; USB drive not properly inserted.	Ensure files are MP3 or WAV. Reinsert USB drive. Try a different USB drive.

9. Specifications

Feature	Detail
Model Name	VTA-75
Brand	Victrola
Product Dimensions	15 x 13.6 x 27.6 inches (with stand)
Item Weight	14 pounds
Material	Plastic, Wood
Playback Speeds	33 1/3, 45, 78 RPM
Connectivity	Bluetooth IN, Bluetooth OUT (VinylStream), FM Radio, USB Playback/Recording, AUX IN, RCA Line Out
Included Components	Turntable, Detachable Stand Legs, 45 RPM Adapter, Power Adapter

10. Warranty and Support

Victrola products are designed and manufactured to the highest quality standards. For detailed warranty information, please refer to the warranty card included with your product or visit the official Victrola website. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Victrola customer service through their official website or the contact information provided in your product packaging.

Online Support: www.victrola.com/support

© 2025 Victrola. All rights reserved. Victrola and Liberty are trademarks of Victrola.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NDX4N1V

More documents and user manuals: **https://manuals.plus/**